

Help for the re-creation of unreadable barcodes

To start this process you need to :

- have installed at least one voting machine
- have a smartcard reader correctly connected to the president machine
- have a smartcard which will be activated as a recovery card to cast a new vote in the voting machine
- a ballot with a barcode that is unreadable

To perform a recovery vote you need to:

1. Complete the code printed on the ballot of which the barcode is unreadable. This is the first code just below the barcode.
2. Complete the code of the vote printed on the ballot of which the barcode is unreadable. This is the second code below the barcode.
3. Insert a smartcard into the reader.
4. Click on 'activate card'
5. Go to the voting machine with the card and the unreadable ballot.
6. Perform the same vote as the one on the unreadable ballot. If the vote is not completely identical as printed on the ballot, it will be impossible to register this as a valid vote in the president machine.
7. Scan by means of the barcode reader the barcode of the newly printed ballot.
8. Repeat this process for all ballots with unreadable barcodes.
9. When you are ready, click on the red cross in the upper right part of the screen.