

ARM926EJ-S™ Based 32-bit Microprocessor

NUC980 U-Boot v2016.11 User Manual

The information described in this document is the exclusive intellectual property of Nuvoton Technology Corporation and shall not be reproduced without permission from Nuvoton.

Nuvoton is providing this document only for reference purposes of NUC980 microcontroller based system design. Nuvoton assumes no responsibility for errors or omissions.

All data and specifications are subject to change without notice.

For additional information or questions, please contact: Nuvoton Technology Corporation.

www.nuvoton.com

1 OVERVIEW	5
2 U-BOOT CONFIGURATION	6
2.1 Edit Configuration File	6
2.2 Menu Configuration	14
3 DIRECTORY STRUCTURE	15
4 COMPILE U-BOOT	17
4.1 Compile Command.....	17
4.2 Output File after Compilation	17
4.3 Main U-Boot Link Address.....	17
4.4 SPL U-Boot Link Address.....	18
5 ADD SPI NOR FLASH AND DISABLE NAND CONFIGURATION	19
5.1 Enable SPI Configuration in nuc980_evb.h.....	19
5.2 Disable SPL.....	19
5.3 Enable NUC980 SPI Driver.....	19
5.4 Enable Legacy SPI Flash Interface Support	19
5.5 Enable sf/spi Command and Disable NAND Command	19
6 ADD SPI NOR FLASH CONFIGURATION (NAND FLASH ALSO ENABLED)	21
6.1 Enable SPI Configuration in nuc980_evb.h.....	21
6.2 Enable NUC980 SPI Driver.....	21
6.3 Enable sf/spi Command	21
6.4 Enable Legacy SPI Flash Interface Support	21
7 ADD SPI NAND CONFIGURATION	22
7.1 Enable SPI Configuration in nuc980_evb.h.....	22
7.2 Update Environment Size in nuc980_evb.h	22
7.3 Enable NUC980 SPI Driver.....	22
7.4 Enable SPI NAND Flash Interface Support.....	22
8 ADD SD0 CONFIGURATION.....	23
8.1 Update nuc980_evb.h to Set Environment Variable in SD0	23
8.2 Generate NUC980 Default Configuration	23
8.3 Adjust Configuration by Menuconfig.....	23
8.4 Disable SPL.....	23
8.5 Disable NAND Command and Enable MMC Command	23
8.6 Enable MMC Related Configuration	23

8.7 Disable NAND driver configuration	24
9 ADD SD1 CONFIGURATION.....	25
9.1 Update nuc980_evb.h to Set Environment Variable in SD1	25
9.2 Generate NUC980 Default Configuration	25
9.3 Adjust Configuration by Menuconfig	25
9.4 Disable SPL.....	25
9.5 Disable NAND Command and Enable MMC Command	25
9.6 Enable MMC Related Configuration	25
9.7 Disable NAND Driver Configuration	26
10 U-BOOT COMMAND	27
10.1 Bootm Command.....	27
10.2 Go Command	28
10.3 Network Relative Command	28
10.4 Nand Flash Commands.....	31
10.5 SPI Flash Commands	34
10.6 SPI NAND Flash Commands.....	35
10.7 Memory Commands.....	36
10.8 USB Commands	38
10.9 Environment Variable Commands	43
10.10 MMC Commands	44
10.11 MTD Commands.....	47
10.12 UBI Commands.....	48
10.13 YAFFS2 Commands.....	51
11 ENVIRONMENT VARIABLES	54
11.1 Environment Variables Configuration	54
11.2 Default Environment Variables	54
11.3 Command Script.....	54
11.4 New Added Environment Variable	55
12 MKIMAGE TOOL	56
12.1 Use mkimage to Generate Linux Kernel Image.....	56
12.2 Checksum Calculation (SHA-1 or crc32)	56
13 WATCHDOG TIMER	58
13.1 Watchdog Timer Configuration	58

13.2	Watchdog Timer Environment Variables	58
13.3	Watchdog Timer Period	58
14	GPIO	59
14.1	NUC980 GPIO	59
14.2	GPIO Driver Interface	59
14.3	Example	60
15	NETWORK TEST ENVIRONMENT	61
15.1	Set Static IP Address	61
15.2	TFTP and DHCP Server	65
16	SPEED UP SPI FLASH BOOT	68
16.1	Speed up SPI	68
16.2	Calculate Checksum of Linux Kernel Image by SHA-1	68
17	NAND FLASH PAGE SIZE AND ECC TYPE.....	69
17.1	Config 6/7 for Page Size.....	69
17.2	Config 8/9 for ECC Type.....	69
18	REVISION HISTORY	70

1 OVERVIEW

The U-Boot utility is a multi-platform, open-source, universal boot-loader with comprehensive support for loading and managing boot images, such as the Linux kernel. It supports the following features:

- Network download: TFTP, BOOTP, DHCP
- Serial download: s-record, binary (via Kermit)
- Flash management: erase, read, update, yaffs2
- Flash types: SPI Flash, NAND Flash
- Memory utilities: dump, compare, copy, write
- Interactive shell: commands with scripting features

The NUC980 U-Boot version v2016.11 can be downloaded from <http://www.denx.de/wiki/U-Boot/SourceCode>

For more detailed description of U-Boot, please visit U-Boot official website: <http://www.denx.de/wiki/view/DULG/UBoot>

2 U-BOOT CONFIGURATION

U-Boot supports two ways for configuration. One is modifying the definitions in configuration file, and the other is menu configuration.

2.1 Edit Configuration File

U-Boot is configurable by modifying the definitions in configuration file.

The NUC980 configuration file is located in include/configs/nuc980_evb.h

Below are the definitions in nuc980_evb.h.

```
#define EXT_CLK          12000000      /* 12 MHz crystal */

#define CONFIG_SYS_TEXT_BASE          0xE00000

#define CONFIG_SYS_LOAD_ADDR          0x8000

#define CONFIG_SYS_HZ                  1000
#define CONFIG_SYS_MEMTEST_START      0xA00000
#define CONFIG_SYS_MEMTEST_END        0xB00000

#define CONFIG_ARCH_CPU_INIT
#undef CONFIG_USE_IRQ

#define CONFIG_CMDLINE_TAG      1      /* enable passing of ATAGs      */
#define CONFIG_SETUP_MEMORY_TAGS 1
#define CONFIG_INITRD_TAG      1

#define CONFIG_CMD_TIMER
/* #define CONFIG_NUC980_HW_CHECKSUM */
```

- EXT_CLK: External crystal clock frequency
- CONFIG_SYS_TEXT_BASE: U-Boot text base address
- CONFIG_SYS_LOAD_ADDR: the load address for downloading image
- CONFIG_SYS_HZ: timer frequency
- CONFIG_SYS_MEMTEST_START: start address of memory test
- CONFIG_SYS_MEMTEST_END: end address of memory test
- CONFIG_CMD_TIMER: Use timer relative command
- CONFIG_NUC980_HW_CHECKSUM: Use SHA-1 to calculate the checksum of Linux kernel (otherwise, use crc32 to calculate checksum), It should cooperate with mkimage tool, Please reference chapter 12.2 .

```
#define CONFIG_SYS_USE_SPIFLASH
#define CONFIG_SYS_USE_NANDFLASH
#define CONFIG_SYS_NO_FLASH      // that is, no *NOR* flash
```

```
#define CONFIG_ENV_IS_IN_NAND
/*#define CONFIG_ENV_IS_IN_SPI_FLASH */
/*#define CONFIG_ENV_IS_IN_MMC */

#define CONFIG_BOARD_EARLY_INIT_F
#define CONFIG_BOARD_LATE_INIT

#define CONFIG_HW_WATCHDOG

#define CONFIG_SYS_BOOTM_LEN          0x1000000 /* 16MB max kernel size
*/

/*#define CONFIG_DISPLAY_CPUINFO */

#define CONFIG_BOOTDELAY              3

#define CONFIG_SYS_SDRAM_BASE        0
#define CONFIG_NR_DRAM_BANKS         2      /* there are 2 sdram banks for nuc980
*/
#define CONFIG_SYS_INIT_SP_ADDR      0xBC008000

#define CONFIG_BAUDRATE               115200
#define CONFIG_SYS_BAUDRATE_TABLE    {115200, 57600, 38400}

/*#define CONFIG_NUC980_EMAC1*/
/*#define CONFIG_CMD_NET */
#define CONFIG_ETHADDR                00:00:00:11:66:88
#define CONFIG_SYS_RX_ETH_BUFFER      16 // default is 4, set to 16 here.

/*#undef CONFIG_SYS_ICACHE_OFF */
/*#undef CONFIG_SYS_DCACHE_OFF */
/*#define CONFIG_SYS_ICACHE_OFF*/
#define CONFIG_SYS_DCACHE_OFF
```

- CONFIG_SYS_USE_SPIFLASH: Use SPI flash
- CONFIG_SYS_USE_NANDFLASH: Use NAND flash
- CONFIG_ENV_IS_IN_NAND: Environment variables are stored in NAND flash
- CONFIG_ENV_IS_IN_SPI_FLASH: Environment variables are stored in SPI flash
- CONFIG_ENV_IS_IN_MMC: Environment variables are stored in eMMC
- CONFIG_HW_WATCHDOG: Enable hardware watchdog timer function (Enable CONFIG_NUC980_WATCHDOG at the same time)
- CONFIG_SYS_BOOTM_LEN: Maximum kernel size

- CONFIG_DISPLAY_CPUINFO: Display CPU relative information
- CONFIG_BOOTDELAY: default boot delay time
- CONFIG_SYS_INIT_SP_ADDR: the stack pointer during system initialization
- CONFIG_BAUDRATE: UART baud rate
- CONFIG_NUC980_EMAC0: Use NUC980 EMAC0
- CONFIG_NUC980_EMAC1: Use NUC980 EMAC1
- CONFIG_NUC980_ETH: Support NUC980 Ethernet
- CONFIG_NUC980_PHY_ADDR: PHY address
- CONFIG_CMD_NET: support network relative commands
- CONFIG_ETHADDR: MAC address
- CONFIG_SYS_RX_ETH_BUFFER: the number of Rx Frame Descriptors
- CONFIG_SYS_ICACHE_OFF: Disable I-Cache
- CONFIG_SYS_DCACHE_OFF: Disable D-Cache

```

/*
 * BOOTP options
 */
#if 1
#define CONFIG_BOOTP_BOOTFILESIZE      1
#define CONFIG_BOOTP_BOOTPATH          1
#define CONFIG_BOOTP_GATEWAY           1
#define CONFIG_BOOTP_HOSTNAME          1
#define CONFIG_BOOTP_SERVERIP /* tftp serverip not overruled by dhcp server */
#endif

/*
 * Command line configuration.
 */
#if 0
#include <config_cmd_default.h>

#undef CONFIG_CMD_LOADS
#undef CONFIG_CMD_SOURCE
#endif

#define CONFIG_CMD_PING      1
#define CONFIG_CMD_DHCP      1
#define CONFIG_CMD_JFFS2     1

```



```
#ifndef CONFIG_SYS_USE_SPIFLASH
#undef CONFIG_CMD_IMLS /*=====> SPI only */
#undef CONFIG_CMD_JFFS2
#endif
```

- CONFIG_BOOTP_SERVERIP: TFTP server IP not overruled by DHCP server.
- CONFIG_CMD_PING: Use ping command
- CONFIG_CMD_DHCP: Use DHCP command
- CONFIG_CMD_JFFS2: Support JFFS2 command

```
#ifndef CONFIG_SYS_USE_NANDFLASH
#define CONFIG_NAND_NUC980
#define CONFIG_CMD_NAND 1
#define CONFIG_CMD_UBI 1
#define CONFIG_CMD_UBIFS 1
#define CONFIG_CMD_MTDPARTS 1
#define CONFIG_MTD_DEVICE 1
#define CONFIG_MTD_PARTITIONS 1
#define CONFIG_RBTREE 1
#define CONFIG_LZO 1
#define MTDIDS_DEFAULT "nand0=nand0"
#define MTDPARTS_DEFAULT "mtdparts=nand0:0x200000@0x0(u-boot),0x1400000@0x200000(kernel),-(user)"
#define MTD_ACTIVE_PART "nand0,2"
#define CONFIG_CMD_NAND_YAFFS2 1
#define CONFIG_YAFFS2 1
#define CONFIG_SYS_MAX_NAND_DEVICE 1
#define CONFIG_SYS_NAND_BASE 0xB000D000
#ifdef CONFIG_ENV_IS_IN_NAND
#define CONFIG_ENV_OFFSET 0x80000
#define CONFIG_ENV_SIZE 0x10000
#define CONFIG_ENV_SECT_SIZE 0x20000
#define CONFIG_ENV_RANGE (4 * CONFIG_ENV_SECT_SIZE) /* Env range : 0x80000 ~ 0x100000 */
#define CONFIG_ENV_OVERWRITE
#endif
#endif#define CONFIG_SYS_NAND_U_BOOT_OFFS (0x100000) /* offset to RAM U-Boot image */

#define CONFIG_SPL_TEXT_BASE 0x200
#define CONFIG_SPL_STACK 0xBC008000

#ifdef CONFIG_NAND_SPL
```

```

/* base address for uboot */
#define CONFIG_SYS_PHY_UBOOT_BASE      (CONFIG_SYS_SDRAM_BASE + 0xE00000)

#define CONFIG_SYS_NAND_U_BOOT_DST      CONFIG_SYS_PHY_UBOOT_BASE      /*
NUB load-addr */
#define CONFIG_SYS_NAND_U_BOOT_START    CONFIG_SYS_NAND_U_BOOT_DST      /*
NUB start-addr */

#define CONFIG_SYS_NAND_U_BOOT_SIZE      (500 * 1024)      /* Size of RAM U-
Boot image */

/* NAND chip page size */
#define CONFIG_SYS_NAND_PAGE_SIZE        2048
/* NAND chip block size */
#define CONFIG_SYS_NAND_BLOCK_SIZE        (128 * 1024)
/* NAND chip page per block count */
#define CONFIG_SYS_NAND_PAGE_COUNT        64

#endif //CONFIG_NAND_SPL

```

- CONFIG_NAND_NUC980: Enable NUC980 NAND function
- CONFIG_CMD_NAND: Use nand command
- CONFIG_MTD_DEVICE: Enable MTD device
- CONFIG_MTD_PARTITIONS: Enable MTD partition
- CONFIG_CMD_UBI: Enable UBI
- CONFIG_CMD_UBIFS: Enable UBIFS file system
- CONFIG_CMD_MTDPARTS: Use MTD partition command.
- CONFIG_RBTREE: Enable the configuration UBI need
- CONFIG_LZO: Enable the configuration UBI need
- MTDIDS_DEFAULT: Set MTD ID name, it needs to be the same as Linux kernel.
- MTDPARTS_DEFAULT: MTD partition configuration
- CONFIG_SYS_MAX_NAND_DEVICE: Maximum NAND device
- CONFIG_SYS_NAND_BASE: NAND controller base address
- CONFIG_ENV_OFFSET: flash offset address that environment variables are stored.
- CONFIG_ENV_SIZE: The space reserved for environment variables
- CONFIG_ENV_SECT_SIZE: The sector size of flash that environment variables are stored.
- CONFIG_ENV_RANGE: The range of environment variables, from CONFIG_ENV_OFFSET to CONFIG_ENV_OFFSET + CONFIG_ENV_RANGE. (When the block is a bad block, U-Boot will store environment variables to next block.)

- CONFIG_SYS_NAND_U_BOOT_OFFSETS: The NAND flash offset address that U-Boot is stored.
- CONFIG_SPL_TEXT_BASE: SPL U-Boot text base address
- CONFIG_SPL_STACK: SPL U-Boot stack address
- CONFIG_SYS_UBOOT_SIZE: U-Boot total space (code + data + heap)
- CONFIG_SYS_PHY_UBOOT_BASE: U-Boot execution address
- CONFIG_SYS_NAND_U_BOOT_SIZE: U-Boot image size
- CONFIG_SYS_NAND_PAGE_SIZE: NAND flash page size
- CONFIG_SYS_NAND_BLOCK_SIZE: NAND flash block size
- CONFIG_SYS_NAND_PAGE_COUNT: The page count per NAND flash block

```
/* SPI flash test code */
#ifdef CONFIG_SYS_USE_SPIFLASH
#define CONFIG_NUC980_SPI      1
#define CONFIG_CMD_SPI         1
#define CONFIG_CMD_SF          1
#define CONFIG_SPI             1
#define CONFIG_SPI_FLASH       1
/*#define CONFIG_SPI_FLASH_MACRONIX 1 */
#define CONFIG_SPI_FLASH_WINBOND 1
/*#define CONFIG_SPI_FLASH_EON 1 */
/*#define CONFIG_SPI_FLASH_SPANSION 1 */
/*#define CONFIG_SPI_FLASH_USE_4K_SECTORS*/
#define CONFIG_SPI_FLASH_BAR
#ifdef CONFIG_ENV_IS_IN_SPI_FLASH
#define CONFIG_ENV_OFFSET      0x80000
#define CONFIG_ENV_SIZE        0x10000
#define CONFIG_ENV_SECT_SIZE   0x10000
#define CONFIG_ENV_OVERWRITE
#endif
#endif
```

- CONFIG_CMD_SF: Use SPI flash sf command.
- CONFIG_SPI_FLASH_MACRONIX: Use MACRONIX SPI flash
- CONFIG_SPI_FLASH_WINBOND: Use Winbond SPI flash
- CONFIG_SPI_FLASH_EON: Use EON SPI flash
- CONFIG_SPI_FLASH_SPANSION: Use Spansion SPI flash
- According to your platform, enable one of them (MACRONIX/WINBOND/EON/SPANSION)
- CONFIG_ENV_OFFSET: The offset of flash that environment variables are stored
- CONFIG_ENV_SIZE: The space reserved for environment variables

```
#define CONFIG_SYS_PROMPT      "U-Boot> "
#define CONFIG_SYS_CBSIZE      256
#define CONFIG_SYS_MAXARGS     16
#define CONFIG_SYS_PBSIZE      (CONFIG_SYS_CBSIZE +
sizeof(CONFIG_SYS_PROMPT) + 16)
#define CONFIG_SYS_LONGHELP    1
#define CONFIG_CMDLINE_EDITING 1
#define CONFIG_AUTO_COMPLETE
#define CONFIG_SYS_HUSH_PARSER
#define CONFIG_SYS_PROMPT_HUSH_PS2 "> "
```

- CONFIG_SYS_PROMPT: Show prompt message
- CONFIG_SYS_LONGHELP: Display detailed help message.
- CONFIG_CMDLINE_EDITING: Permit command line editing.

```
/* Following block is for MMC support */
#define CONFIG_NUC980_MMC
#define CONFIG_CMD_FAT
#define CONFIG_MMC
#define CONFIG_GENERIC_MMC
#define CONFIG_DOS_PARTITION
#define CONFIG_NUC980_SD_PORT0
// #define CONFIG_NUC980_EMMC /* Don't enable eMMC(CONFIG_NUC980_EMMC)
and NAND(CONFIG_NAND_NUC980) at the same time! */
#ifdef CONFIG_ENV_IS_IN_MMC
#define CONFIG_SYS_MMC_ENV_DEV 2
#define CONFIG_ENV_OFFSET      0x80000
#define CONFIG_ENV_SIZE        0x10000
#define CONFIG_ENV_SECT_SIZE   512
#define CONFIG_ENV_OVERWRITE
#endif
```

- CONFIG_NUC980_MMC: Compile NUC980 driver
- CONFIG_CMD_FAT: Support FAT command
- CONFIG_MMC: Support MMC
- CONFIG_GENERIC_MMC: Support generic MMC
- CONFIG_DOS_PARTITION: Support DOS partition
- CONFIG_NUC980_SD_PORT0: Support SD port 0
- CONFIG_NUC980_EMMC: Support eMMC
- CONFIG_SYS_MMC_ENV_DEV: The MMC device number that environment variables stored
- CONFIG_ENV_OFFSET: Environment variables offset
- CONFIG_ENV_SIZE: Environment variables size

- CONFIG_ENV_SECT_SIZE: Environment variables sector size

```
/* Following block is for EHCI support*/
#if 1
#define CONFIG_CMD_USB
#define CONFIG_CMD_FAT
#define CONFIG_USB_STORAGE
#define CONFIG_USB_EHCI
#define CONFIG_USB_EHCI_NUC980
#define CONFIG_EHCI_HCD_INIT_AFTER_RESET
#define CONFIG_DOS_PARTITION
#endif
```

- CONFIG_CMD_USB: Support USB command
- CONFIG_CMD_FAT: Support FAT command
- CONFIG_USB_STORAGE: Support USB storage
- CONFIG_USB_EHCI: Support USB 2.0
- CONFIG_USB_EHCI_NUC980: Support NUC980 USB 2.0
- CONFIG_DOS_PARTITION: Support DOS partition

```
#define CONFIG_NUC980_GPIO

/*
 * Size of malloc() pool
 */
#define CONFIG_SYS_MALLOC_LEN (1024*1024)

#define CONFIG_STACKSIZE (32*1024) /* regular stack */


#endif
```

- CONFIG_NUC980_GPIO: Enable GPIO function
- CONFIG_SYS_MALLOC_LEN: The space reserved for malloc
- CONFIG_STACKSIZE: Stack size.

2.2 Menu Configuration


U-Boot v2016.11 supports menu configuration by command “make menuconfig”.

```
# make menuconfig
```



3 DIRECTORY STRUCTURE

The directory structure of U-Boot source code is as below.



- api: U-Boot machine/arch independent API for external apps
- arch: This directory contains CPU relative source code.
- The CPU relative source code of NUC980 is under arch/arm/cpu/arm926ejs/nuc980.
- board: This directory contains board relative source code.
- The board relative source code of NUC980 is under board/nuvoton/nuc980_evb.
- cmd: This directory contains miscellaneous U-Boot command
- common: This directory contains U-Boot command and other common source code.
- configs: This directory contains default configuration of vendors.
- disk: This directory contains disk partition related source code.
- doc: This directory contains miscellaneous README document.
- drivers: This directory contains miscellaneous driver source code.
- The driver relative source code of NUC980 is under directory drivers. For instance the Ethernet driver is under drivers/net/nuc980_eth.c
- dts: This directory contains two files, Makefile and Kconfig for device tree.
- If device tree configuration, CONFIG_OF_CONTROL, is enabled, the Makefile builds the

internal U-Boot fdt. See doc/README.fdt-control for more details.

- examples: This directory contains some examples. For instance, mips.lds is the linker script file for MIPS.
- fs: This directory contains miscellaneous file systems. For instance, FAT, yaffs2.
- include: This directory contains header file and configuration file. NUC980 configuration file is under include/configs/nuc980_evb.h
- lib: This directory contains miscellaneous library.
- Licenses: This directory contains GPL relative document.
- net: This directory contains network relative source code. For instance, tftp.c, ping.c,
- post: Supply a default implementation for post_hotkeys_pressed() for boards without hotkey support.
- scripts: contains sources for various helper programs used throughout
- the kernel for the build process.
- test: This directory contains some test programs. See test/README for more details.
- tools: This directory contains some tools. For instance, mkimage is the tool to make a image.

4 COMPILE U-BOOT

4.1 Compile Command

Clean all object code.

```
# make distclean
```

Generate default configuration

```
# make nuc980_defconfig
```

Start compilation.

```
# make
```

4.2 Output File after Compilation

If you compile successfully, you can get Main U-Boot and SPL U-Boot:

Main U-Boot : Full function U-Boot

SPL U-Boot : Move Main U-Boot from NAND Flash to DDR and boot Main U-Boot

SPL U-Boot: It's only for NAND boot; SPI boot and eMMC boot need Main U-Boot only.

Main U-Boot and SPL U-Boot are generated in root directory and sub-directory spl:

Main U-Boot files are generated in root directory.

- u-boot - Elf executable file (for download with GDB or IDE)
- u-boot.bin - binary file (You can use Nu-Writer to burn it to NAND/SPI Flash, eMMC)
- u-boot.map –Linker memory map file

SPL U-Boot files are generated in sub-directory spl

- u-boot-spl - Elf executable file (for download with GDB or IDE)
- u-boot-spl.bin - binary file (You can use Nu-Writer to burn it to NAND/SPI Flash, eMMC)
- u-boot-spl.map –Linker memory map file

4.3 Main U-Boot Link Address

Main U-Boot link address is defined in include/configs/nuc980_evb.h.

```
#define CONFIG_SYS_TEXT_BASE 0xE00000
```

The default setting of U-Boot link address is 0xE00000

If boot mode is NAND Boot, please also modify the definition in include/configs/nuc980_evb.h

```
#define CONFIG_SYS_PHY_UBOOT_BASE (CONFIG_SYS_SDRAM_BASE + 0xE00000)
```

4.4 SPL U-Boot Link Address

SPL U-Boot link address is defined in include/configs/nuc980_evb.h

Default address is 0x200, if you want to modify it to other address, please find the following code segment, and replace 0x200 with new address.

```
#define CONFIG_SPL_TEXT_BASE    0x200
```

5 ADD SPI NOR FLASH AND DISABLE NAND CONFIGURATION

In default configuration, NAND is enabled and SPI is disabled. If user's platform has SPI NOR Flash but without NAND Flash, user has to update include/configs/nuc980_evb.h and use "make menuconfig" to update configurations for supporting SPI NOR Flash.

5.1 Enable SPI Configuration in nuc980_evb.h

Edit include/configs/nuc980_evb.h. Enable definition "CONFIG_SYS_USE_SPIFLASH" and disable definition "CONFIG_SYS_USE_NANDFLASH".

Set environment variables in SPI Flash by enabling definition "CONFIG_ENV_IS_IN_SPI_FLASH" and disabling definition "CONFIG_ENV_IS_IN_NAND".

```
#define CONFIG_SYS_USE_SPIFLASH
/*#define CONFIG_SYS_USE_NANDFLASH */
/* #define CONFIG_ENV_IS_IN_NAND */
#define CONFIG_ENV_IS_IN_SPI_FLASH
```

5.2 Disable SPL

By "make menuconfig", disable SPL.

```
-> SPL / TPL ---->
[ ] SPL
```

5.3 Enable NUC980 SPI Driver

By "make menuconfig", enable NUC980 SPI driver and select SPI in Quad mode or Normal mode.

```
-> Device Drivers
-> SPI Support
    [*] NUC980 SPI driver
        select NUC980 SPI in Quad mode or Normal mode (Quad mode) ---->
```

5.4 Enable Legacy SPI Flash Interface Support

By "make menuconfig", enable SPI Flash interface support and SPI Flash Bank/Extend address support. Besides, select SPI Flash per your DEV board. Below is an example that Winbond SPI Flash support.

```
-> Device Drivers
-> SPI Flash Support
    [*] Legacy SPI Flash Interface support
    [*] SPI flash Bank/Extended address register support
    [*] winbond SPI flash support
```

5.5 Enable sf/spi Command and Disable NAND Command

By "make menuconfig", enable sf/spi command and disable nand command.

```
-> Command line interface
-> Device access commands
```

```
[ ] nand
    [*] sf
    [*] ssbi
```

6 ADD SPI NOR FLASH CONFIGURATION (NAND FLASH ALSO ENABLED)

In default configuration, NAND is enabled and SPI is disabled. Update include/configs/nuc980_evb.h and use “make menuconfig” to update configurations for supporting SPI NOR Flash.

6.1 Enable SPI Configuration in nuc980_evb.h

Edit include/configs/nuc980_evb.h. Enable definition “CONFIG_SYS_USE_SPIFLASH”.

Set environment variables in SPI Flash by enabling definition “CONFIG_ENV_IS_IN_SPI_FLASH” and disabling definition “CONFIG_ENV_IS_IN_NAND”.

```
#define CONFIG_SYS_USE_SPIFLASH
/* #define CONFIG_ENV_IS_IN_NAND */
#define CONFIG_ENV_IS_IN_SPI_FLASH
```

6.2 Enable NUC980 SPI Driver

By “make menuconfig”, enable NUC980 SPI driver and select SPI in Quad mode or Normal mode.

```
-> Device Drivers
-> SPI Support
    [*] NUC980 SPI driver
        Select NUC980 SPI in Quad mode or Normal mode (Quad mode) ---->
```

6.3 Enable sf/spi Command

By “make menuconfig”, enable sf/spi command.

```
-> Command line interface
-> Device access commands
    [*] sf
    [*] sspi
```

6.4 Enable Legacy SPI Flash Interface Support

By “make menuconfig”, enable SPI Flash interface support and SPI Flash Bank/Extend address support. Besides, select SPI Flash per your DEV board. Below is an example that Winbond SPI flash support.

```
-> Device Drivers
-> SPI Flash Support
    [*] Legacy SPI Flash Interface support
    [*] SPI flash Bank/Extended address register support
    [*] winbond SPI flash support
```

7 ADD SPI NAND CONFIGURATION

In default configuration, SPI is disabled. Update include/configs/nuc980_evb.h and use “make menuconfig” to update configurations for supporting SPI.

7.1 Enable SPI Configuration in nuc980_evb.h

Edit include/configs/nuc980_evb.h. Enable definition “CONFIG_SYS_USE_SPIFLASH”.

```
#define CONFIG_SYS_USE_SPIFLASH
#define CONFIG_ENV_IS_IN_NAND
```

7.2 Update Environment Size in nuc980_evb.h

Edit include/configs/nuc980_evb.h. Update definition “CONFIG_ENV_SIZE” to 0x20000.

```
#ifdef CONFIG_ENV_IS_IN_NAND
#define CONFIG_ENV_OFFSET      0x80000
#define CONFIG_ENV_SIZE        0x20000
#define CONFIG_ENV_SECT_SIZE    0x20000
```

7.3 Enable NUC980 SPI Driver

By “make menuconfig”, enable NUC980 SPI driver and select SPI in Quad mode or Normal mode.

```
-> Device Drivers
-> SPI Support
    [*] NUC980 SPI driver
        select NUC980 SPI in Quad mode or Normal mode (Quad mode) --->
```

7.4 Enable SPI NAND Flash Interface Support

By “make menuconfig”, enable SPI Flash interface support and SPI flash Bank/Extend address support. Enable SPI NAND support and select SPI NAND flash per your DEV board. Below is an example that Winbond SPI NAND flash support.

```
-> Device Drivers
-> SPI Flash Support
    [*] Legacy SPI Flash Interface support
    [*] SPI flash Bank/Extended address register support
    [*] SPI NAND flash support
        Select SPI NAND Flash (winbond SPI NAND flash support) --->
```

8 ADD SD0 CONFIGURATION

In default configuration, SD0 is disabled. Update include/configs/nuc980_evb.h and use “make menuconfig” to update configurations for supporting SD0.

8.1 Update nuc980_evb.h to Set Environment Variable in SD0

Edit include/configs/nuc980_evb.h. Disable definition “CONFIG_SYS_USE_NANDFLASH”.

Set environment variables in SD0 by enabling definition “CONFIG_ENV_IS_IN_MMC” and disabling definition “CONFIG_ENV_IS_IN_NAND”.

```
/*#define CONFIG_SYS_USE_SPIFLASH */  
/*#define CONFIG_SYS_USE_NANDFLASH */  
/*#define CONFIG_ENV_IS_IN_NAND */  
/*#define CONFIG_ENV_IS_IN_SPI_FLASH */  
#define CONFIG_ENV_IS_IN_MMC
```

8.2 Generate NUC980 Default Configuration

Clean all object code.

```
# make distclean
```

Generate default configuration

```
# make nuc980_defconfig
```

8.3 Adjust Configuration by Menuconfig

Enter menuconfig.

```
# make menuconfig
```

8.4 Disable SPL

By “make menuconfig”, disable SPL.

```
-> SPL / TPL ---->  
[ ] SPL
```

8.5 Disable NAND Command and Enable MMC Command

By “make menuconfig”, disable NAND command and enable MMC command.

```
-> Command line interface  
-> Device access commands  
    [*] mmc  
    [ ] nand
```

8.6 Enable MMC Related Configuration

By “make menuconfig”, enable MMC related support.

```
-> Device Drivers  
-> MMC Host controller Support  
    -> NUC980 MMC support (NUC980_MMC [=y])
```

```

[*] Enable MMC support
[*] Generic MMC support
[*] NUC980 MMC support
[ ] NUC980 SD1 support (SD Host Port F)
[*] NUC980 SD0 support (FMI Port C)

```

8.7 Disable NAND driver configuration

By “make menuconfig”, disable NUC980 NAND support.

```

-> Device Drivers
-> NAND Device Support
[ ] NUC980 NAND support

```


9 ADD SD1 CONFIGURATION

In default configuration, SD1 is disabled. Update include/configs/nuc980_evb.h and use “make menuconfig” to update configurations for supporting SD1.

9.1 Update nuc980_evb.h to Set Environment Variable in SD1

Edit include/configs/nuc980_evb.h. Disable definition “CONFIG_SYS_USE_NANDFLASH”.

Set environment variables in SD1 by enabling definition “CONFIG_ENV_IS_IN_MMC” and disabling definition “CONFIG_ENV_IS_IN_NAND”.

```
/*#define CONFIG_SYS_USE_SPIFLASH */
/*#define CONFIG_SYS_USE_NANDFLASH */
/*#define CONFIG_ENV_IS_IN_NAND */
/*#define CONFIG_ENV_IS_IN_SPI_FLASH */
#define CONFIG_ENV_IS_IN_MMC
```

9.2 Generate NUC980 Default Configuration

Clean all object code.

```
# make distclean
```

Generate default configuration

```
# make nuc980_defconfig
```

9.3 Adjust Configuration by Menuconfig

Enter menuconfig.

```
# make menuconfig
```

9.4 Disable SPL

By “make menuconfig”, disable SPL.

```
-> SPL / TPL ---->
[ ] SPL
```

9.5 Disable NAND Command and Enable MMC Command

By “make menuconfig”, disable NAND command and enable MMC command.

```
-> Command line interface
-> Device access commands
    [*] mmc                                [ ] nand
```

9.6 Enable MMC Related Configuration

By “make menuconfig”, enable MMC related support.

```
-> Device Drivers
-> MMC Host controller Support
    -> NUC980 MMC support (NUC980_MMC [=y])
        [*] Enable MMC support
```

```
[*] Generic MMC support
[*] NUC980 MMC support
[*]   NUC980 SD1 support (SD Host Port F)
[ ]   NUC980 SD0 support (FMI Port C)
```

9.7 Disable NAND Driver Configuration

By “make menuconfig”, disable NUC980 NAND support.

```
-> Device Drivers
-> NAND Device Support
    [ ]   NUC980 NAND support
```

10 U-BOOT COMMAND

U-boot provides a powerful command line interface which may be accessed through a terminal emulator connected to the target board's serial port. For example type "help" at the command prompt will print a list of all the available commands:

```
U-Boot> help
0      - do nothing, unsuccessfully
1      - do nothing, successfully
?      - alias for 'help'
base   - print or set address offset
bdinfo - print Board Info structure
boot   - boot default, i.e., run 'bootcmd'
bootd  - boot default, i.e., run 'bootcmd'
...
```

For most commands, you do not need to type in the full command name; instead it is sufficient to type a few characters. For instance, help can be abbreviated as h. Almost all U-Boot commands expect numbers to be entered in hexadecimal input format. (Exception: for historical reasons, the sleep command takes its argument in decimal input format.)

10.1 Bootm Command

Since Linux kernel image is stored in network, NAND, SPI, USB, or MMC, user can download Linux kernel to DDR by those storage relative command, then boot Linux kernel by bootm command.

Hence, bootm command is used to boot Linux kernel or other application program.

bootm command format is as below:

```
U-Boot> help bootm
bootm - boot application image from memory

Usage:
bootm [addr [arg ...]]
    - boot application image stored in memory
      passing arguments 'arg ...'; when booting a Linux kernel,
      'arg' can be the address of an initrd image
```

Suppose Linux kernel has been downloaded to DDR address 0x7fc0, then user can boot Linux kernel by bootm command.

```
U-Boot> bootm 0x7fc0
## Booting kernel from Legacy Image at 00007fc0 ...
Image Name:
Image Type:   ARM Linux Kernel Image (uncompressed)
Data Size:    1639744 Bytes = 1.6 MiB
Load Address: 00007FC0
Entry Point:  00008000
Verifying Checksum ... OK
XIP Kernel Image ... OK
```

OK

starting kernel ...

10.2 Go Command

- go: start application

```
U-Boot> help go
go - start application at address 'addr'
```

Usage:

```
go addr [arg ...]
    - start application at address 'addr'
      passing 'arg' as arguments
```

Below example is to start an application program that has been downloaded to DDR 0x100000

```
U-Boot> go 0x100000
## Starting application at 0x00100000 ...
```

Hello world!

10.3 Network Relative Command

- ping

Transmit ICMP ECHO_REQUEST packet to network host

```
U-Boot> help ping
ping - send ICMP ECHO_REQUEST to network host
```

Usage:

```
ping pingAddress
```

```
U-Boot>
```

Before using this command, you have to set variables ipaddr that is the IP address of your platform.

Below is an example that set IP address of NUC980 to 192.168.0.101 and ping a remote PC whose IP address is 192.168.0.100

```
U-Boot> setenv ipaddr 192.168.0.101
U-Boot> ping 192.168.0.100
Using emac device
host 192.168.0.100 is alive
U-Boot>
```

- tftp

Download image via network using TFTP protocol.

```
U-Boot> help tftp
tftpboot - boot image via network using TFTP protocol

Usage:
tftpboot [loadAddress] [[hostIPAddr:]bootfilename]
U-Boot>
```

Before using this command, you have to set variables ipaddr and serverip.

Below is an example to download a Linux kernel image by TFTP protocol. First, set IP address of NUC980 and TFTP server to 192.168.0.101 and 192.168.0.100 respectively. Second, download Linux kernel image to address 0x200000 by TFTP protocol. Third, boot Linux kernel by command bootm.

```
U-Boot> setenv ipaddr 192.168.0.101
U-Boot> setenv serverip 192.168.0.100
U-Boot> tftp 0x7fc0 vmlinux.ub
Using emac device
TFTP from server 192.168.0.100; our IP address is 192.168.0.101
Filename 'vmlinux.ub'.
Load address: 0x7FC0
Loading: *#####
#####
887.7 KiB/s
done
Bytes transferred = 1639808 (190580 hex)
U-Boot> bootm 0x7FC0
## Booting kernel from Legacy Image at 007FC0 ...
Image Name:
Image Type: ARM Linux Kernel Image (uncompressed)
Data Size: 1639744 Bytes = 1.6 MiB
Load Address: 00007FC0
Entry Point: 00008000
Verifying Checksum ... OK
Loading Kernel Image ... OK
OK

Starting kernel ...
```

- dhcp

Download image via network using DHCP/TFTP protocol

```
U-Boot> help dhcp
dhcp - boot image via network using DHCP/TFTP protocol

Usage:
dhcp [loadAddress] [[hostIPAddr:]bootfilename]
U-Boot>
```

Below is an example to download Linux kernel image to address 0x7fc0 by DHCP/TFTP protocol. You don't have to set ipaddr for your platform, since DHCP server will assign an IP for you.

```
U-Boot> dhcp 0x7fc0 vmlinux.ub
BOOTP broadcast 1
*** Unhandled DHCP Option in OFFER/ACK: 7
*** Unhandled DHCP Option in OFFER/ACK: 7
DHCP client bound to address 192.168.0.102
Using emac device
TFTP from server 192.168.0.100; our IP address is 192.168.0.102; sending
through gateway 192.168.0.100
Filename 'vmlinux.ub'.
Load address: 0x7fc0
Loading: *#####
          #####
          1 MiB/s
done
Bytes transferred = 1639808 (190580 hex)
U-Boot> bootm 0x7fc0
## Booting kernel from Legacy Image at 00007fc0 ...
   Image Name:
   Image Type:   ARM Linux Kernel Image (uncompressed)
   Data Size:    1639744 Bytes = 1.6 MiB
   Load Address: 00007FC0
   Entry Point:  00008000
   Verifying Checksum ... OK
   XIP Kernel Image ... OK
OK

Starting kernel ...
```

- bootp
Download image via network using BOOTP/TFTP protocol

```
U-Boot> help bootp
bootp - boot image via network using BOOTP/TFTP protocol
```

```
Usage:
bootp [loadAddress] [[hostIPAddr:]bootfilename]
U-Boot>
```

Below is an example to download Linux kernel image to address 0x7fc0 by BOOTP/TFTP protocol. You don't have to set ipaddr for your platform, since DHCP server will assign an IP for you.

```
U-Boot> bootp 0x7fc0 vmlinux.ub
BOOTP broadcast 1
*** Unhandled DHCP Option in OFFER/ACK: 7
*** Unhandled DHCP Option in OFFER/ACK: 7
DHCP client bound to address 192.168.0.102
Using emac device
TFTP from server 192.168.0.100; our IP address is 192.168.0.102; sending
through gateway 192.168.0.100
Filename 'vmlinux.ub'.
Load address: 0x7fc0
Loading: *#####
          #####
          1 MiB/s
done
Bytes transferred = 1639808 (190580 hex)
U-Boot> bootm 0x7fc0
## Booting kernel from Legacy Image at 00007fc0 ...
   Image Name:
   Image Type:   ARM Linux Kernel Image (uncompressed)
   Data Size:    1639744 Bytes = 1.6 MiB
   Load Address: 00007FC0
   Entry Point:  00008000
   Verifying Checksum ... OK
   XIP Kernel Image ... OK
OK

Starting kernel ...
```

10.4 Nand Flash Commands

- nand: NAND Sub-system

U-Boot supports NAND Flash relative commands, including nand info/device/erase/read/write.

Command format is as below:

```
U-Boot> help nand
```

```
nand - NAND sub-system

Usage:
nand info - show available NAND devices
nand device [dev] - show or set current device
nand read - addr off|partition size
nand write - addr off|partition size
    read/write 'size' bytes starting at offset 'off'
    to/from memory address 'addr', skipping bad blocks.
nand read.raw - addr off|partition [count]
nand write.raw - addr off|partition [count]
    Use read.raw/write.raw to avoid ECC and access the flash as-is.
nand erase[.spread] [clean] off size - erase 'size' bytes from offset 'off'
    with '.spread', erase enough for given file size, otherwise,
    'size' includes skipped bad blocks.
nand erase.part [clean] partition - erase entire mtd partition'
nand erase.chip [clean] - erase entire chip'
nand bad - show bad blocks
nand dump[.oob] off - dump page
nand scrub [-y] off size | scrub.part partition | scrub.chip
    really clean NAND erasing bad blocks (UNSAFE)
nand markbad off [...] - mark bad block(s) at offset (UNSAFE)
nand biterr off - make a bit error at offset (UNSAFE)
U-Boot>
```

Below example show NAND Page size/OOB size/Erase size information by nand info/device command.

```
U-Boot> nand info

Device 0: nand0, sector size 128 KiB
  Page size      2048 b
  OOB size       64 b
  Erase size    131072 b
U-Boot> nand device

Device 0: nand0, sector size 128 KiB
  Page size      2048 b
  OOB size       64 b
  Erase size    131072 b
U-Boot>
```



```
nand erase.chip erase whole chip.
U-Boot> nand erase.chip

NAND erase.chip: device 0 whole chip
99% complete.Erasing at 0x7fe0000 -- 100% complete.
OK
U-Boot>
```

Below is an example to write a Linux kernel image to NAND Flash. The Linux kernel image is allocated at DDR 0x500000 and its size is 0x190580 bytes. User will write it to NAND Flash offset 0x200000; then, read the Linux kernel image back to DDR 0x7fc0. At last, use command, bootm, to boot Linux kernel image.

```
U-Boot> nand write 0x500000 0x200000 0x190580

NAND write: device 0 offset 0x200000, size 0x190580
1639808 bytes written: OK
U-Boot> nand read 0x7FC0 0x200000 0x190580

NAND read: device 0 offset 0x200000, size 0x190580
1639808 bytes read: OK
U-Boot> bootm 0x7FC0
## Booting kernel from Legacy Image at 007FC0 ...
Image Name:
Image Type:   ARM Linux Kernel Image (uncompressed)
Data Size:    1639744 Bytes = 1.6 MiB
Load Address: 00007FC0
Entry Point:  00008000
Verifying Checksum ... OK
Loading kernel Image ... OK
OK

Starting kernel ...
```

- nboot: boot from NAND device

Command format is as below:

```
U-Boot> help nboot
nboot - boot from NAND device
```

```
Usage:
nboot [partition] | [[[loadAddr] dev] offset]
U-Boot>
```

Below example uses nboot to read Linux kernel image from NAND Flash offset 0x200000 to DDR address 0x7fc0. Then boot Linux kernel by command bootm.

```
U-Boot> nboot 0x7fc0 0 0x200000

Loading from nand0, offset 0x200000
  Image Name:
  Image Type:   ARM Linux Kernel Image (uncompressed)
  Data Size:    1639744 Bytes = 1.6 MiB
  Load Address: 00007FC0
  Entry Point:  00008000
U-Boot> bootm 0x7fc0
## Booting kernel from Legacy Image at 00007fc0 ...
  Image Name:
  Image Type:   ARM Linux Kernel Image (uncompressed)
  Data Size:    1639744 Bytes = 1.6 MiB
  Load Address: 00007FC0
  Entry Point:  00008000
  Verifying Checksum ... OK
  XIP Kernel Image ... OK
OK

starting kernel ...
```

10.5 SPI Flash Commands

U-Boot supports SPI Flash relative commands including sf probe/read/write/erase/update. The command format is as below.

```
U-Boot> help sf
sf - SPI flash sub-system

Usage:
sf probe [[bus:]cs] [hz] [mode]    - init flash device on given SPI bus and
chip select
sf read addr offset len - read `len' bytes starting at `offset' to memory
at `addr'
sf write addr offset len - write `len' bytes from memory at `addr' to flash
at `offset'
```

```
sf erase offset [+]len - erase `len' bytes from `offset' `+len' round up
`len' to block size
sf update addr offset len - erase and write `len' bytes from memory at
`addr' to flash at `offset'
U-Boot>
```

Note that you have to run command, sf probe, first before using sf read/write/erase/update.

You can designate SPI speed in argument of sf probe. Below is an example to set SPI clock to 30 MHz.

```
U-Boot> sf probe 0 30000000
```

Below is an example to read a Linux kernel image from SPI Flash. First, use “sf probe” command to set SPI clock to 30 MHz. Then, “sf read” command read Linux kernel image stored at SPI Flash offset 0x200000 to DDR 0x7fc0. Finally, use command, bootm, to boot Linux kernel image.

```
U-Boot> sf probe 0 30000000
SF: Detected EN25QH16-104HIP with page size 64 KiB, total 16 MiB
U-Boot> sf read 0x7FC0 0x200000 0x190580
U-Boot> bootm 0x7FC0
## Booting kernel from Legacy Image at 007FC0 ...
   Image Name:
   Image Type:   ARM Linux Kernel Image (uncompressed)
   Data Size:    1639744 Bytes = 1.6 MiB
   Load Address: 00007FC0
   Entry Point:  00008000
   Verifying Checksum ... OK
   Loading Kernel Image ... OK
OK

Starting kernel ...
```

10.6 SPI NAND Flash Commands

U-Boot supports SPI NAND Flash. Use command “nand” to read Kernel from SPI NAND and use command “bootm” to boot Linux kernel image.

```
U-Boot> nand read 0x7FC0 0x200000 0x190580

NAND read: device 0 offset 0x200000, size 0x190580
1639808 bytes read: OK
U-Boot> bootm 0x7FC0
## Booting kernel from Legacy Image at 007FC0 ...
   Image Name:
   Image Type:   ARM Linux Kernel Image (uncompressed)
```

```
Data Size: 1639744 Bytes = 1.6 MiB
Load Address: 00007FC0
Entry Point: 00008000
Verifying Checksum ... OK
Loading Kernel Image ... OK
OK

Starting kernel ...
```

10.7 Memory Commands

- md: Memory display.

```
U-Boot> help md
md - memory display

Usage:
md [.b, .w, .l] address [# of objects]
U-Boot>
```

Below is an example to display the memory content from address 0x10000 to 0x100ff.

```
U-Boot> md 0x1000
00001000: bffbcbf5c 5ffb56ff fcff5f41 ff67760b \....V._A_...vg.
00001010: fcd227e3 dffefeeb 70cf7cb3 dbefc7cb .'.....|.p....
00001020: fbda3e3b eb3e9ebb aa3abc95 e5fbbb2f ;>....>...:/...
00001030: ffbbb319 effe9d7d bfbeeb09 ff7b4f31 ....}.....10{.
00001040: f7bf3973 eaff296c e6fce35e 6fffc7d7f s9..l)..^.....o
00001050: cfd28a65 8cd69f2b efecce87 677f3b8f e...+.....;.g
00001060: def67b1d deff7ece 3ffd4003 ffbf32c2 .{...~...@.?.2..
00001070: feef5b67 ffdfa2e6 b7ffe1d3 efffb707 g[.....
00001080: ed2fee4b 6fd852b9 cbf765dd 796dc3de K./..R.o.e....my
00001090: ff9fcff9 ef7bae38 efb0aff3 f8fdf324 ....8.{.....$...
000010a0: fda577b7 cfbbbecc d5936aa0 088f362f .w.....j../6..
000010b0: ff6bae5a beff9df1 eadded74 3de9fd3d Z.k.....t...=..=
000010c0: dbff79bf 6f32ccf1 89bfa6b1 fbafeebf .y....2o.....
000010d0: 77f5b6cd bd7fe7fc 6e2366f2 dff7a5fc ...w.....f#n....
000010e0: f9ff160b edba6d61 fbf88f79 ffef7b76 ....am..y...v{..
000010f0: 3efabd8c fbfaebe2 6f7d807a ffae9ace ...>....z.}o....
U-Boot>
```

- mw: Memory write

```
U-Boot> help mw
mw - memory write (fill)

Usage:
mw [.b, .w, .l] address value [count]
U-Boot>
```

Below is an example to write 4 words 0s to address 0x10000.

```
U-Boot> mw 0x10000 0 4
U-Boot>
```

Display the memory content of address 0x10000. The first 4 words of address 0x10000 are 0s.

```
U-Boot> md 0x10000
00010000: 00000000 00000000 00000000 00000000 .....
00010010: e58c3004 e59c3008 e0843003 e58c3008 .0...0...0...0..
00010020: e1a01105 e1a03305 e0613003 e0833005 .....3...0a..0..
00010030: e1a02103 e0632002 e1a02102 e0862002 .!... c..!... ..
00010040: e58282d0 e58242d4 e59f3220 e0831001 .....B.. 2.....
00010050: e5913110 e58232d8 e58262c8 e3a0300c .1...2...b...0..
00010060: e58232b4 e59f321c e5823014 e254a000 .2...2...0....T.
00010070: 0a00006e e1a02305 e0422105 e0822005 n....#...!B.. ..
00010080: e1a03102 e0623003 e1a03103 e0863003 .1...0b..1...0..
00010090: e59342d8 e51b0038 eb015a3f e1a03000 .B..8...?Z...0..
000100a0: e59f01e4 e1a01004 e1a0200a eb007cc5 ..... |..
000100b0: ea00005e e2813040 e1a03183 e083300e ^...@0...1...0..
000100c0: e0863003 e2832004 e5822000 e5832008 .0... .. .. ..
000100d0: e08c3001 e283308e e1a03103 e0863003 .0...0...1...0..
000100e0: e2833004 e5837000 e2811001 e2800001 .0...p.....
000100f0: e3500005 1afffffe e1a03305 e0433105 ..P.....3...1C.
U-Boot>
```

- cmp: Memory compare.

```
U-Boot> help cmp
cmp - memory compare

Usage:
cmp [.b, .w, .l] addr1 addr2 count
```

```
U-Boot>
```

Below is an example to compare 64 words of address 0x8000 with address 0x9000.

```
U-Boot> cmp 0x8000 0x9000 64
word at 0x00008000 (0xe321f0d3) != word at 0x00009000 (0xe59f00d4)
Total of 0 word(s) were the same
U-Boot>
```

- mtest: simple RAM read/write test

```
U-Boot> help mtest
mtest - simple RAM read/write test

Usage:
mtest [start [end [pattern [iterations]]]]
U-Boot>
```

Below is an example to test RAM read/write from address 0xa00000 to address 0xb00000 0x20 (32) iterations.

```
U-Boot> mtest 0xa00000 0xb00000 5a5a5a5a 20
Testing 00a00000 ... 00b00000:
Iteration:      32Pattern A5A5A5A5  writing...           Reading...Tested
32 iteration(s) with 0 errors.
U-Boot>
```

10.8 USB Commands

- usb: USB sub-system

```
usb: USB sub-system

U-Boot> help usb
usb - USB sub-system

Usage:
usb start - start (scan) USB controller
usb reset - reset (rescan) USB controller
usb stop [f] - stop USB [f]=force stop
usb tree - show USB device tree
usb info [dev] - show available USB devices
usb storage - show details of USB storage devices
usb dev [dev] - show or set current USB storage device
usb part [dev] - print partition table of one or all USB storage devices
usb read addr blk# cnt - read `cnt' blocks starting at block `blk#'
```

```

    to memory address `addr'
usb write addr blk# cnt - write `cnt' blocks starting at block `blk#'
    from memory address `addr'
U-Boot>

```

- usb reset

```

U-Boot> usb reset
(Re)start USB...
USB0:   USB EHCI 0.95
scanning bus 0 for devices... 2 USB Device(s) found
       scanning usb for storage devices... 1 Storage Device(s) found
U-Boot>

```

- usb start

```

U-Boot> usb start
(Re)start USB...
USB0:   USB EHCI 0.95
scanning bus 0 for devices... 2 USB Device(s) found
       scanning usb for storage devices... 1 Storage Device(s) found
U-Boot>

```

- usb tree

```

U-Boot> usb tree
USB device tree:
 1 Hub (480 Mb/s, 0mA)
 | u-boot EHCI Host Controller
 |
 |+-2 Mass Storage (480 Mb/s, 200mA)
      Kingston DT 101 II 0019E000B4955B8C0E0B0158
U-Boot>

```

- usb info

```

U-Boot> usb info
1: Hub,   USB Revision 2.0
 - u-boot EHCI Host Controller
 - Class: Hub

```

```

- PacketSize: 64 Configurations: 1
- Vendor: 0x0000 Product 0x0000 Version 1.0
  Configuration: 1
- Interfaces: 1 Self Powered 0mA
  Interface: 0
- Alternate Setting 0, Endpoints: 1
- Class Hub
- Endpoint 1 In Interrupt MaxPacket 8 Interval 255ms

2: Mass Storage, USB Revision 2.0
- Kingston DT 101 II 0019E000B4955B8C0E0B0158
- Class: (from Interface) Mass Storage
- PacketSize: 64 Configurations: 1
- Vendor: 0x0951 Product 0x1613 Version 1.0
  Configuration: 1
- Interfaces: 1 Bus Powered 200mA
  Interface: 0
- Alternate Setting 0, Endpoints: 2
- Class Mass Storage, Transp. SCSI, Bulk only
- Endpoint 1 In Bulk MaxPacket 512
- Endpoint 2 Out Bulk MaxPacket 512

U-Boot>

```

● usb storage

```

U-Boot> usb storage
Device 0: Vendor: Kingston Rev: PMAP Prod: DT 101 II
          Type: Removable Hard Disk
          Capacity: 3875.0 MB = 3.7 GB (7936000 x 512)

U-Boot>

```

● usb dev

```

U-Boot> usb dev

USB device 0: Vendor: Kingston Rev: PMAP Prod: DT 101 II
              Type: Removable Hard Disk
              Capacity: 3875.0 MB = 3.7 GB (7936000 x 512)

U-Boot>

```


- usb part

```
U-Boot> usb part
```

```
Partition Map for USB device 0 -- Partition Type: DOS
```

Part	Start Sector	Num Sectors	UUID	Type
1	8064	7927936	1dfc1dfb-01	0b Boot

```
U-Boot>
```

- usb read: read `cnt` blocks starting at block `blk#` to memory address `addr`.
- usb write: write `cnt` blocks starting at block `blk#` from memory address `addr`.

Below is an example that write device 0 block #2, 1 block from 0x10000, and read back device 0 block #2, 1 block to 0x20000. Then compare the memory content of 0x10000 and 0x20000 with 1 block (512 bytes).

```
U-Boot> usb write 0x10000 2 1
```

```
USB write: device 0 block # 2, count 1 ... 1 blocks write: OK
```

```
U-Boot> usb read 0x20000 2 1
```

```
USB read: device 0 block # 2, count 1 ... 1 blocks read: OK
```

```
U-Boot>
```

```
U-Boot> cmp 0x10000 0x20000 80
```

```
Total of 128 word(s) were the same
```

```
U-Boot>
```

- usbboot: boot from USB device

```
U-Boot> help usb boot
```

```
usbboot - boot from USB device
```

```
Usage:
```

```
usbboot loadAddr dev:part
```

```
U-Boot>
```

Before using usbboot, you have to write Linux kernel image into USB device.

It can be achieved by command, usb write. However, user has to know the start block(sector) number where Linux kernel image put to. The following uses command, USB part to show the partition map of USB device 0.

```
U-Boot> usb part
```

```
Partition Map for USB device 0 -- Partition Type: DOS
```

Part	Start Sector	Num Sectors	UUID	Type
1	8064	7927936	1dfc1dfb-01	0b Boot

U-Boot>

The start sector (block) number is 369 (0x171). Therefore, command, usb write, is used to write Linux kernel image to device 0 block # 369(0x171). The block count can be computed as below.

The Linux kernel image is downloaded at 0x200000. It can be downloaded by ICE or TFTP or other tools. And the Linux kernel size is 1639808 bytes. $1639808/512 = 3202.75$. So, it needs 3203 (0xc83) blocks to store the Linux kernel.

```
U-Boot> usb write 0x200000 1f80 c83
```

```
USB write: device 0 block # 8064, count 3203 ... 3203 blocks write: OK
```

U-Boot>

Now, the Linux kernel is stored in device 0 block # 369(0x171). So, user can load Linux kernel from USB device 0 partition 1 by command, usbboot.

```
U-Boot> usbboot 0x7fc0 0:1
```

```
Loading from usb device 0, partition 1: Name: usbda1 Type: U-Boot
```

```
Image Name:
```

```
Image Type: ARM Linux Kernel Image (uncompressed)
```

```
Data Size: 1639744 Bytes = 1.6 MiB
```

```
Load Address: 00007FC0
```

```
Entry Point: 00008000
```

```
U-Boot> bootm 0x7fc0
```

```
## Booting kernel from Legacy Image at 00007fc0 ...
```

```
Image Name:
```

```
Image Type: ARM Linux Kernel Image (uncompressed)
```

```
Data Size: 1639744 Bytes = 1.6 MiB
```

```
Load Address: 00007FC0
```

```
Entry Point: 00008000
```

```
Verifying Checksum ... OK
```

```
XIP Kernel Image ... OK
```

```
OK
```

```
Starting kernel ...
```

Besides, U-Boot supports command fatls and fatload that can access USB device files from file system. Below is an example that lists USB device file by command fatls and loads USB device file by command fatload.

```
U-Boot> fatls usb 0:1
```

```
1639808 vmlinux.ub
```

```
1 file(s), 0 dir(s)
```

```

U-Boot>
U-Boot> fatload usb 0:1 0x7fc0 vmlinux.ub
reading vmlinux.ub
1639808 bytes read in 90 ms (17.4 MiB/s)
U-Boot>
U-Boot> bootm 0x7fc0
## Booting kernel from Legacy Image at 00007fc0 ...
   Image Name:
   Image Type:   ARM Linux Kernel Image (uncompressed)
   Data Size:    1639744 Bytes = 1.6 MiB
   Load Address: 00007fc0
   Entry Point:  00008000
   Verifying Checksum ... OK
   XIP Kernel Image ... OK
OK

starting kernel ...

```

10.9 Environment Variable Commands

- setenv: set environment variables

```

U-Boot> help setenv
setenv - set environment variables

Usage:
setenv [-f] name value ...
    - [forcibly] set environment variable 'name' to 'value ...'
setenv [-f] name
    - [forcibly] delete environment variable 'name'
U-Boot>

```

Below is an example to set environment variable, ipaddr, to 192.168.0.101

And use command, echo, to show the value of ipaddr.

```

U-Boot> setenv ipaddr 192.168.0.101
U-Boot> echo $ipaddr
192.168.0.101
U-Boot>

```

- saveenv: save environment variables to persistent storage.

```
U-Boot> help saveenv
saveenv - save environment variables to persistent storage

Usage:
saveenv
U-Boot>
```

- env: environment handling commands

```
U-Boot> help env
env - environment handling commands

Usage:
env default [-f] -a - [forcibly] reset default environment
env default [-f] var [...] - [forcibly] reset variable(s) to their default
values
env delete [-f] var [...] - [forcibly] delete variable(s)
env edit name - edit environment variable
env export [-t | -b | -c] [-s size] addr [var ...] - export environment
env import [-d] [-t | -b | -c] addr [size] - import environment
env print [-a | name ...] - print environment
env run var [...] - run commands in an environment variable
env save - save environment
env set [-f] name [arg ...]

U-Boot>
```

10.10 MMC Commands

- mmc : MMC sub-system

U-Boot support MMC relative command, include read/write/erase/list/dev.

The command format is as below.

```
U-Boot> help mmc
mmc - MMC sub system

Usage:
mmc read addr blk# cnt
mmc write addr blk# cnt
mmc erase blk# cnt
mmc rescan
mmc part - lists available partition on current mmc device
```

```
mmc dev [dev] [part] - show or set current mmc device [partition]
mmc list - lists available devices
U-Boot>
```

mmc list : list all mmc device

```
U-Boot> mmc list
mmc: 0
mmc: 1
U-Boot>
```

NUC980 supports mmc device including SD port 0 and eMMC.

User can modify following two definitions in nuc980_evb.h according to your platform.

```
#define CONFIG_NUC980_SD_PORT0
#define CONFIG_NUC980_EMMC
```

The default setting enables SD port 0. Since eMMC and NAND can not be used at the same time, NAND is disabled by default setting.

If SD port 0 and eMMC are all enabled, mmc device numbers are as below:

Device number 0 is SD port 0

Device number 1 is eMMC

If your platform supports eMMC (doesn't support SD port 0), you have to disable the definition CONFIG_NUC980_SD_PORT0 in nuc980_evb.h

The command, mmc list, can see the following result:

```
U-Boot> mmc list
mmc: 0
U-Boot>
```

Device number 0 is eMMC

Following example is user sets current device to device 0 (SD port 0) by "mmc dev" command.

Use "mmc erase" command to erase SD card block 0x30 and 0x31, and copy data from DDR address 0x8000 to SD card block 0x30 and 0x31, then read SD card block 0x30 and 0x31 to DDR 0x500000. Finally compare the data in DDR address 0x8000 with address 0x500000 to validate SD access.

```
U-Boot> mmc dev 0
mmc0 is current device
U-Boot> mmc erase 0x30 2

MMC erase: dev # 0, block # 48, count 2 ... 2 blocks erase: OK
U-Boot> mmc write 0x8000 0x30 2

MMC write: dev # 0, block # 48, count 2 ... 2 blocks write: OK
U-Boot> mmc read 0x500000 0x30 2

MMC read: dev # 0, block # 48, count 2 ... 2 blocks read: OK
U-Boot> cmp.b 0x8000 0x500000 0x400
```

```
Total of 1024 byte(s) were the same
```

```
U-Boot>
```

Following example is user sets current device to device 1 (eMMC) by “mmc dev” command.

Use “mmc erase” command to erase SD card block 1024 to 2047, and copy data from DDR address 0x8000 to SD card block 1024 ~ 2047, then read SD card block 1024 ~ 2047 to DDR 0x500000. Finally compare the data in DDR address 0x8000 with address 0x500000 to validate SD access.

```
U-Boot> mmc dev 1
mmc1(part 0) is current device
U-Boot> mmc erase 0x400 0x400

MMC erase: dev # 1, block # 1024, count 1024 ... 1024 blocks erase: OK
U-Boot> mmc write 0x8000 0x400 0x400

MMC write: dev # 1, block # 1024, count 1024 ... 1024 blocks write: OK
U-Boot> mmc read 0x500000 0x400 0x400

MMC read: dev # 1, block # 1024, count 1024 ... 1024 blocks read: OK
U-Boot> cmp.b 0x8000 0x500000 0x4000
Total of 16384 byte(s) were the same
U-Boot>
```

User can access SD/eMMC card by “mmc” command. Besides, user can access the files in SD/eMMC card by “fatls” and “fatload” command.

Following example use “fatls” command to list the file in SD port 0, then “fatload” command to read Linux kernel image (vmlinux.ub) to DDR address 0x7fc0, finally boot Linux kernel by “bootm” command.

```
U-Boot> fatls mmc 0
 1639808  vmlinux.ub
         0   4gsd.txt

2 file(s), 0 dir(s)

U-Boot> fatload mmc 0 0x7fc0 vmlinux.ub
reading vmlinux.ub
1639808 bytes read in 301 ms (5.2 MiB/s)
U-Boot> bootm 0x7fc0
## Booting kernel from Legacy Image at 00007fc0 ...
   Image Name:
   Image Type:   ARM Linux Kernel Image (uncompressed)
   Data Size:    1639744 Bytes = 1.6 MiB
   Load Address: 00007fc0
   Entry Point:  00008000
```

```
Verifying Checksum ... OK
XIP Kernel Image ... OK
OK

Starting kernel ...
```

10.11 MTD Commands

- mtdparts : define Flash/NAND partitions

U-Boot supports MTD partition relative command, including add/del/list.

```
U-Boot> help mtd
mtdparts - define flash/nand partitions

Usage:
mtdparts
    - list partition table
mtdparts delall
    - delete all partitions
mtdparts del part-id
    - delete partition (e.g. part-id = nand0,1)
mtdparts add <mtd-dev> <size>[@<offset>] [<name>] [ro]
    - add partition
mtdparts default
    - reset partition table to defaults
-----
this command uses three environment variables:
'partition' - keeps current partition identifier
partition := <part-id>
<part-id> := <dev-id>,part_num
'mtdids' - linux kernel mtd device id <-> u-boot device id mapping
mtdids=<idmap>[,<idmap>,...]
<idmap> := <dev-id>=<mtd-id>
<dev-id> := 'nand' | 'nor' | 'onenand' <dev-num>
<dev-num> := mtd device number, 0...
<mtd-id> := unique device tag used by linux kernel to find mtd device
(mtd->name)
'mtdparts' - partition list
mtdparts=mtdparts=<mtd-def>[;<mtd-def>...]
<mtd-def> := <mtd-id>:<part-def>[,<part-def>...]
<mtd-id> := unique device tag used by linux kernel to find mtd device
(mtd->name)
```

```

<part-def> := <size>[@<offset>][<name>][<ro-flag>]
<size>      := standard linux memsize OR '-' to denote all remaining space
<offset>    := partition start offset within the device
<name>      := '(' NAME ')'
<ro-flag>   := when set to 'ro' makes partition read-only (not used, passed
to kernel)
U-Boot>

```

mtdparts command set NAND flash partition table. The default partition setting is defined in nuc980_evb.h. The default setting sets MTD partition ID to nand0, and three partitions including u-boot, kernel and user.

The first partition: u-boot, start from address 0x0, size is 0x200000.

The second partition: kernel, start from address 0x200000, size is 0x1400000.

The third partition: user, start from address 0x1600000, size is the rest space.

```

#define MTDIDS_DEFAULT "nand0=nand0"
#define MTDPARTS_DEFAULT "mtdparts=nand0:0x200000@0x0(u-
boot),0x1400000@0x200000(kernel),-(user)"

```

mtdparts lists all the mtd partitions.

```

U-Boot> mtdparts
device nand0 <nand0>, # parts = 3
#: name          size          offset          mask_flags
0: u-boot        0x00100000      0x00000000      0
1: kernel        0x01400000      0x00100000      0
2: user          0x06b00000      0x01500000      0
active partition: nand0,0 - (u-boot) 0x00100000 @ 0x00000000
defaults:
mtdids   : nand0=nand0
mtdparts: mtdparts=nand0:0x100000@0x0(u-boot),0x1400000@0x100000(kernel),-
(user)
U-Boot>

```

10.12 UBI Commands

- ubi : ubi commands

U-Boot supports UBI relative command, including info/create/read/write.

```

U-Boot> help ubi
ubi - ubi commands
Usage:
ubi part [part] [offset]
- Show or set current partition (with optional VID header offset)
ubi info [l[ayout]] - Display volume and ubi layout information
ubi create[vol] volume [size] [type] - create volume name with size

```



```
ubi write[vol] address volume size - Write volume from address with size
ubi read[vol] address volume [size] - Read volume to address with size
ubi remove[vol] volume - Remove volume
```

[Legends]

volume: character name

size: specified in bytes

type: s[tatic] or d[ynamic] (default=dynamic)

U-Boot>

ubi part : Display or set current partition

```
U-Boot> ubi part user
```

Creating 1 MTD partitions on "nand0":

```
0x000001500000-0x000008000000 : "mtd=2"
```

```
UBI: attaching mtd1 to ubi0
```

```
UBI: physical eraseblock size: 131072 bytes (128 KiB)
```

```
UBI: logical eraseblock size: 126976 bytes
```

```
UBI: smallest flash I/O unit: 2048
```

```
UBI: VID header offset: 2048 (aligned 2048)
```

```
UBI: data offset: 4096
```

```
UBI: attached mtd1 to ubi0
```

```
UBI: MTD device name: "mtd=2"
```

```
UBI: MTD device size: 107 MiB
```

```
UBI: number of good PEBs: 855
```

```
UBI: number of bad PEBs: 1
```

```
UBI: max. allowed volumes: 128
```

```
UBI: wear-leveling threshold: 4096
```

```
UBI: number of internal volumes: 1
```

```
UBI: number of user volumes: 1
```

```
UBI: available PEBs: 17
```

```
UBI: total number of reserved PEBs: 838
```

```
UBI: number of PEBs reserved for bad PEB handling: 8
```

```
UBI: max/mean erase counter: 6/4
```

U-Boot>

ubi info : display capacity and ubi information

```
U-Boot> ubi info 1
```

```
UBI: volume information dump:
```

```
UBI: vol_id 0
```

```
UBI: reserved_pebs 826
```

```
UBI: alignment 1
```

```
UBI: data_pad 0
```

```

UBI: vol_type      3
UBI: name_len      9
UBI: usable_leb_size 126976
UBI: used_ebs      826
UBI: used_bytes    104882176
UBI: last_eb_bytes 126976
UBI: corrupted     0
UBI: upd_marker    0
UBI: name          nandflash

UBI: volume information dump:
UBI: vol_id        2147479551
UBI: reserved_pebs 2
UBI: alignment     1
UBI: data_pad      0
UBI: vol_type      3
UBI: name_len      13
UBI: usable_leb_size 126976
UBI: used_ebs      2
UBI: used_bytes    253952
UBI: last_eb_bytes 2
UBI: corrupted     0
UBI: upd_marker    0
UBI: name          layout volume

```

U-Boot>

ubifsmount : mount ubifs volume

U-Boot> help ubifsmount

ubifsmount - mount UBIFS volume

Usage:

ubifsmount <volume-name>

- mount 'volume-name' volume

U-Boot> ubifsmount ubi0:nandflash

UBIFS: mounted UBI device 0, volume 0, name "nandflash"

UBIFS: mounted read-only

UBIFS: file system size: 103485440 bytes (101060 KiB, 98 MiB, 815 LEBS)

UBIFS: journal size: 5206016 bytes (5084 KiB, 4 MiB, 41 LEBS)

UBIFS: media format: w4/r0 (latest is w4/r0)

UBIFS: default compressor: LZ0

UBIFS: reserved for root: 5114338 bytes (4994 KiB)

```
U-Boot>
```

ubifsls : list files in a directory

```
U-Boot> help ubifsls
```

ubifsls - list files in a directory

Usage:

```
ubifsls [directory]
```

- list files in a 'directory' (default '/')

```
U-Boot> ubifsls
```

```
<DIR>          160  Thu Jan 01 00:08:09 1980  tt
```

```
U-Boot>
```

ubifsumount : unmount UBIFS volume

```
U-Boot> help ubifsumount
```

ubifsumount - unmount UBIFS volume

Usage:

```
ubifsumount      - unmount current volume
```

```
U-Boot> ubifsumount
```

Unmounting UBIFS volume nandflash!

```
U-Boot>
```

10.13 YAFFS2 Commands

- yaffs : yaffs commands

U-Boot supports YAFFS commands, including mount/list/mkdir/rmdir/rd/w.

Format is as below:

```
U-Boot> help
```

ydevconfig- configure yaffs mount point

ydevls - list yaffs mount points

yls - yaffs ls

ymkdir - YAFFS mkdir

ymount - mount yaffs

ymv - YAFFS mv

yrd - read file from yaffs

yrdm - read file to memory from yaffs

yrm - YAFFS rm

yrmdir - YAFFS rmdir

ytrace - show/set yaffs trace mask

yumount - unmount yaffs

ywr - write file to yaffs

ywrm - write file from memory to yaffs

ydevconfig configure YAFFS mount point

```
U-Boot> ydevconfig
Bad arguments: ydevconfig mount_pt mtd_dev start_block end_block
U-Boot> ydevconfig nand 0 0xb0 0x3ff
Configures yaffs mount nand: dev 0 start block 176, end block 1023 using
inband tags
```

ydevls list YAFFS mount points

```
U-Boot> ydevls
nand          0 0x000b0 0x003ff using inband tags, not mounted
```

ymount mount YAFFS

```
U-Boot> ymount
Bad arguments: ymount mount_pt
U-Boot> ymount nand
Mounting yaffs2 mount point nandnand
U-Boot> ydevls
nand          0 0x000b0 0x003ff using inband tags, free 0x6573800
```

yls list the content of YAFFS file system, a mount point is a directory, previous example nand is a directory

```
U-Boot> yls
Bad arguments: yls [-l] dir
U-Boot> yls -l nand
lost+found          2032      2 directory
```

ymkdir make a directory

```
U-Boot> ymkdir nand/test
U-Boot> yls -l nand
test                2032    257 directory
lost+found          2032      2 directory
```

yrmdir delete a directory

```
U-Boot> yrmdir nand/test
U-Boot> yls -l nand
lost+found          2032      2 directory
```

ywr / ywrm write a file / save a block of memory to a file

```
U-Boot> ywr nand/wr.bin 0x55 100
writing value (55) 100 times to nand/wr.bin... done
U-Boot> ywrm nand/wrm.bin 0xe00000 0x1000
U-Boot> yls -l nand
wrm.bin             4096    259 regular file
wr.bin              256    258 regular file
lost+found          2032      2 directory
```

yrd / yrdm read a file / read a file to memory

```
U-Boot> yrd nand/wr.bin
Reading file nand/wr.bin
Done
U-Boot> yrdm nand/wrm.bin 0x200000
Copy nand/wrm.bin to 0x00200000... [DONE]
```

yrm delete a file

```
U-Boot> yls -l nand
wrm.bin                4096    259 regular file
wr.bin                 256     258 regular file
lost+found             2032      2 directory
U-Boot> yrm nand/wr.bin
U-Boot> yls -l nand
wrm.bin                4096    259 regular file
lost+found             2032      2 directory
```

yumount unmounts YAFFS

```
U-Boot> yumount nand
Unmounting yaffs2 mount point nand
U-Boot> ydevls
nand          0 0x000b0 0x003ff using inband tags, not mounted
```

11 ENVIRONMENT VARIABLES

11.1 Environment Variables Configuration

Environment variables can store in NAND Flash, SPI Flash or eMMC, and user can modify below three definitions in nuc980_evb.h:

- CONFIG_ENV_IS_IN_NAND: environment variables are stored in NAND Flash
- CONFIG_ENV_IS_IN_SPI_FLASH: environment variables are stored in SPI Flash
- CONFIG_ENV_IS_IN_MMC: environment variables are stored in eMMC

Note that only one of them can be defined.

User can configure the Flash offset address environment variables stored and the space reserved for environment variables in nuc980_evb.h:

- CONFIG_ENV_OFFSET: the Flash offset address environment variables stored
- CONFIG_ENV_SIZE: the space reserved for environment variables

11.2 Default Environment Variables

U-Boot has some default environment variables. If the variables are not stored in Flash, U-Boot will assign default value to the variables.

Below are the default environment variables.

- baudrate

Console baudrate, the value is from CONFIG_BAUDRATE in nuc980_evb.h

- bootdelay

It's the boot delay time when U-Boot run the command script in bootcmd. Its unit is second. Before it is countdown to 0, hit any key to stop running script in bootcmd.

- ethact

It sets which Ethernet interface state is active, since nuc980 ethernet driver set device name to emac, ethact can be set to emac only.

- ethaddr

Ethernet MAC address. ethaddr value is from CONFIG_ETHADDR in nuc980_evb.h

- stderr

Set stderr, default value is serial

- stdin

Set stdin, default value is serial

- stdout

Set stdout, default value is serial

11.3 Command Script

Below are script relative commands

- bootcmd

Whenever U-Boot boots up, U-Boot executes the script in bootcmd.

Following example set bootcmd as: read Linux kernel from SPI Flash offset 0x200000 to DDR address 0x7fc0, and boot Linux kernel.

Remember to save the environment variables to Flash.

```
U-Boot> setenv bootcmd sf probe 0 50000000\; sf read 0x7fc0 0x200000
0x190580\; bootm 0x7fc0
U-Boot> saveenv
Saving Environment to SPI Flash...
SF: Detected EN25QH16-104HIP with page size 64 KiB, total 16 MiB
Erasing SPI flash...Writing to SPI flash...done
U-Boot>
```

- bootargs

This argument will be passed to Linux kernel. Below example is to pass the bootargs about NAND MTD partition to Linux kernel. Finally, remember to save environment variables to NAND Flash.

```
U-Boot> setenv bootargs "root=/dev/ram0 console=ttyS0,115200n8
rdinit=/sbin/init mem=64M mtdparts=nand0:0x200000@0x0(u-
boot),0x1400000@0x200000(kernel),-(user)"
U-Boot> saveenv
Saving Environment to NAND...
Erasing Nand...
Erasing at 0xe0000 -- 100% complete.
Writing to Nand... done
U-Boot>
```

NOTE: If you have set the U-Boot environment variables, that user should select the "Command line partition table parsing" in the kernel device setting. And then, the parameters will be passed into kernel.

```
Device Drivers --->
-* Memory Technology Device (MTD) support --->
    <*> Command line partition table parsing
```

11.4 New Added Environment Variable

NUC980 U-Boot adds below new environment variable.

- watchdog: Enable or disable watchdog timer function.

```
U-Boot> setenv watchdog mode
```

The parameter "mode" can be on or off.

on: watchdog timer function enabled

off: watchdog timer function disabled

For instance, disable watchdog function

```
U-Boot> setenv watchdog off
```

Enable watchdog function

```
U-Boot> setenv watchdog on
```

Remember save the environment variables to Flash.

```
U-Boot> saveenv
```

12 MKIMAGE TOOL

U-Boot supports a number of different image formats that can be downloaded, saved to Flash and executed. The types of such image files supported by U-Boot, include:

- Linux Kernel
- Script files
- Standalone binaries
- RAM disk images

These images are often referred to as an ".ub" files, as that is the file extension name that is often used to name them.

12.1 Use mkimage to Generate Linux Kernel Image

The mkimage tool is located in tools/mkimage. Below is an example to encapsulate an ARM Linux kernel binary file (980image). Linux kernel download address is 0x7fc0 and execution address is 0x8000.

```
u-boot/tools# ./mkimage -A arm -O linux -T kernel -a 0x7fc0 -e 0x8000 -d
980image 980image.ub
Image Name:
Created:      Fri Aug  8 14:38:39 2014
Image Type:   ARM Linux Kernel Image (uncompressed)
Data Size:    1639744 Bytes = 1601.31 kB = 1.56 MB
Load Address: 00007FC0
Entry Point:  00008000
```

- A: set CPU architecture to arm
- O: set operating system to linux
- T: set image type to kernel
- a: set load address to 0x7fc0
- e: set entry point to 0x8000
- d: set image data from 980image

12.2 Checksum Calculation (SHA-1 or crc32)

mkimage tool calculates the checksum of Linux kernel image and puts it in the header.

The command "bootm" also calculates the checksum of Linux kernel image loaded to DDR and compares the checksum with the value in header of Linux kernel image. If they are different, it shows the error message "Verifying Checksum ... Bad Data CRC" and stop booting Linux kernel. If they are the same, it shows the message "Verifying Checksum ... OK" and continues to boot Linux kernel. The default option of mkimage tool is using software crc32 to calculate the checksum of Linux kernel image. It's time-consuming. If you want to speed up booting Linux kernel, you can use hardware SHA-1 to calculate the checksum of Linux kernel.

NUC980 adds a new parameter "-S" to calculate Linux kernel checksum.

The original checksum calculation method of mkimage tool is crc32, NUC980 provides another option, SHA-1, below is an example uses SHA-1 to calculate Linux kernel checksum. Add option "-S sha1". Remember to enable CONFIG_NUC980_HW_CHECKSUM in nuc980_evb.h

```
u-boot/tools# ./mkimage -A arm -O linux -T kernel -S sha1 -a 0x7fc0 -e 0x8000 -d 980image 980image.ub
```

Image Name:

Created: Fri Aug 8 14:39:47 2014

Image Type: ARM Linux Kernel Image (uncompressed)

Data Size: 1639744 Bytes = 1601.31 kB = 1.56 MB

Load Address: 00007FC0

Entry Point: 00008000

-A: set CPU architecture to arm

-O: set operating system to linux

-T: set image type to kernel

-a: set load address to 0x7fc0

-e: set entry point to 0x8000

-S: set checksum calculation to sha1

-d: set image data from 980image

If you select crc32 to calculate Linux kernel checksum, below is an example : Added an option "-S crc32". Remember to disable CONFIG_NUC980_HW_CHECKSUM in nuc980_evb.h

```
u-boot/tools# ./mkimage -A arm -O linux -T kernel -S crc32 -a 0x7fc0 -e 0x8000 -d 980image 980image.ub
```

Image Name:

Created: Fri Aug 8 14:39:47 2014

Image Type: ARM Linux Kernel Image (uncompressed)

Data Size: 1639744 Bytes = 1601.31 kB = 1.56 MB

Load Address: 00007FC0

Entry Point: 00008000

-A: set CPU architecture to arm

-O: set operating system to linux

-T: set image type to kernel

-a: set load address to 0x7fc0

-e: set entry point to 0x8000

-S: set checksum calculation to crc32

-d: set image data from 980image

13 WATCHDOG TIMER

13.1 Watchdog Timer Configuration

Modify below definition in nuc980_evb.h to enable NUC980 watchdog timer function.

```
#define CONFIG_HW_WATCHDOG
```

Remark the definition will disable NUC980 watchdog timer function.

13.2 Watchdog Timer Environment Variables

When NUC980 watchdog timer configuration is enabled, user can set environment variable "watchdog" to "off" or "0", the watchdog timer function will be disabled without modifying configuration file or recompilation.

```
U-Boot> setenv watchdog off  
U-Boot> saveenv
```

Set environment variable "watchdog" to "on" will enable watchdog timer function again.

```
U-Boot> setenv watchdog on  
U-Boot> saveenv
```

After modifying the environment variable "watchdog", remember to use command "saveenv" to save variable "watchdog" to Flash.

If the configuration of watchdog timer in nuc980_evb.h is disabled, it is meaningless to modify environment variable "watchdog".

13.3 Watchdog Timer Period

When Watchdog timer function is enabled and system is idle more than 14 seconds, Watchdog timer will reset system. Whenever user enters a command (input Enter key), the idle time will be reset to 0.

14 GPIO

U-Boot GPIO can be used for LED.

NUC980 U-Boot provides the function to set GPIO. User can access GPIO by NUC980 GPIO driver interface.

14.1 NUC980 GPIO

NUC980 GPIO port includes port A ~ port J, each port has 16 pins.

Note that GPIO port C pin 15 and GPIO port J pin 5~15 are reserved, please do not use them.

The NUC980 U-Boot assigns each pin a GPIO number; for instance, GPIO port A pin 0 number is GPIO_PA0, GPIO port B pin 2 number is GPIO_PB2

User has to pass GPIO number when calling NUC980 GPIO driver function.

14.2 GPIO Driver Interface

The NUC980 provides following GPIO APIs:

```
int gpio_request(unsigned gpio, const char *label);
int gpio_direction_input(unsigned gpio);
int gpio_direction_output(unsigned gpio, int value);
int gpio_get_value(unsigned gpio);
int gpio_set_value(unsigned gpio, int value);
```

The first parameter of each API is GPIO number.

- `gpio_request`

Confirm GPIO is in used or not, the second parameter is not used, you can fill in 0.

If the designated GPIO pin is switched to other function (not GPIO), there will be error message.

For instance, when using GPIO port D0, and calling `gpio_request()`:

```
gpio_request(GPIO_PD0, NULL);
```

If port D0 is switched to other function, you will get below error message.

[`gpio_request`] Please Check GPIO pin [96], multi-function pins = 0x6

- `gpio_direction_input`

Set GPIO pin to input mode.

- `gpio_direction_output`

Set GPIO pin to output mode and output value.

- `gpio_get_value`

Read GPIO pin value

- `gpio_set_value`

Set GPIO pin output value.

14.3 Example

Below example sets GPIO port G0 ~ port G5 output value to 0x101010.


```
gpio_request(GPIO_PG0, NULL);  
gpio_direction_output(GPIO_PG0, 0);  
gpio_request(GPIO_PG1, NULL);  
gpio_direction_output(GPIO_PG1, 1);  
gpio_request(GPIO_PG2, NULL);  
gpio_direction_output(GPIO_PG2, 0);  
gpio_request(GPIO_PG3, NULL);  
gpio_direction_output(GPIO_PG3, 1);  
gpio_request(GPIO_PG4, NULL);  
gpio_direction_output(GPIO_PG4, 0);  
gpio_request(GPIO_PG5, NULL);  
gpio_direction_output(GPIO_PG5, 1);
```

15 NETWORK TEST ENVIRONMENT


A PC that has static IP address and installed with TFTP/DHCP server application is required.

15.1 Set Static IP Address


- Choose Local Area Connection (under Control Panel -> Network and Internet -> Network Connections)




- Click Properties



- Choose Internet Protocol Version 4 (TCP/IPv4)




- Set static IP address



15.2 TFTP and DHCP Server


There is a free, open source application, TFTPD32, which includes TFTP and DHCP server. It can be downloaded by following URL

<http://www.jounin.net/tftp-server-for-windows.html>



Click Settings to set TFTP server and DHCP server.

Set base directory for TFTP server.



Set DHCP pool definitions. Below is an example to set IP pool start from 192.168.0.102

Tftpd32: Settings

GLOBAL | TFTP | DHCP | SYSLOG

DHCP Pool definition

IP pool start address: 192.168.0.102

Size of pool: 4

Lease (minutes): 2880

Boot File:

DHCP Options

Def. router (Opt 3): 192.168.0.100

Mask (Opt 1): 192.168.0.255

DNS Servers (Opt 6):

WINS server (Opt 44):

NTP server (Opt 42):

SIP server (Opt 120):

Domain Name (15):

Additional Option: 0

DHCP Settings

☒ Ping address before assignation

☒ Persistent leases

☐ Double answer if relay detected

☐ Bind DHCP to this address: 127.0.0.1

OK Default Help Cancel

16 SPEED UP SPI FLASH BOOT

In SPI Flash boot, U-Boot uses the command “sf read” to read Linux kernel from SPI Flash to DDR , and uses the command “bootm” to boot Linux kernel. There are two methods to shorten the SPI Flash boot up time including speed up SPI and calculate checksum of Linux kernel image by SHA-1.

16.1 Speed up SPI

Set SPI clock to higher rate can speed up SPI.

Below is an example that uses “sf probe” command to set SPI clock to 50 MHz.

```
U-Boot> sf probe 0 50000000
SF: Detected w25Q128 with page size 4 KiB, total 16 MiB
U-Boot>
```

16.2 Calculate Checksum of Linux Kernel Image by SHA-1

The command “bootm” calculates the checksum of Linux kernel by hardware can also shorten boot time. Please reference 12.2 that introduce how-to use SHA-1 to calculate checksum to speed up booting Linux kernel.

17 NAND FLASH PAGE SIZE AND ECC TYPE

U-Boot gets NAND Flash page size and ECC type by scanning NAND ID table in NAND initialization. If you use a NAND Flash that is not supported in the ID table, or the page size and ECC type mismatch with ID table, you can use Power-on setting switch on EVB to overwrite them.

17.1 Config 6/7 for Page Size

Config 7 = 0, Config 6 = 0 set NAND Flash page size to 2K Byte.

Config 7 = 0, Config 6 = 1 set NAND Flash page size to 4K Byte.

Config 7 = 1, Config 6 = 0 set NAND Flash page size to 8K Byte.

17.2 Config 8/9 for ECC Type

Config 9 = 0, Config 8 = 0 set NAND Flash ECC type to no ECC.

Config 9 = 0, Config 8 = 1 set NAND Flash ECC type to BCH T12.

Config 9 = 1, Config 8 = 0 set NAND Flash ECC type to BCH T24.

18 REVISION HISTORY

Date	Revision	Description
2019.6.26	1.00	Initially issued.

Important Notice

Nuvoton Products are neither intended nor warranted for usage in systems or equipment, any malfunction or failure of which may cause loss of human life, bodily injury or severe property damage. Such applications are deemed, "Insecure Usage".

Insecure usage includes, but is not limited to: equipment for surgical implementation, atomic energy control instruments, airplane or spaceship instruments, the control or operation of dynamic, brake or safety systems designed for vehicular use, traffic signal instruments, all types of safety devices, and other applications intended to support or sustain life.

All Insecure Usage shall be made at customer's risk, and in the event that third parties lay claims to Nuvoton as a result of customer's Insecure Usage, customer shall indemnify the damages and liabilities thus incurred by Nuvoton.

*Please note that all data and specifications are subject to change without notice.
All the trademarks of products and companies mentioned in this datasheet belong to their respective owners.*