

---

# Qspice - Command Reference Guide by KSKelvin

KSKelvin Kelvin Leung

Created on 8-4-2023


Last update on 12-21-2023

---

## .four THD Computation

# .four THD Computation

- Syntax: `.four FREQ [HARMONICS] [PERIODS] expr1 [expr2 [expr3 [...]]]`
  - FREQ : fundamental frequency
  - HARMONICS : number of harmonics to compute (Default HARMONICS=9)
  - PERIODS : number of period to be used to compute THD
  - expr1 : expression (e.g. V(out), I(V1) etc...)
- [HARMONICS]
  - Number of harmonics to compute



```
pulse 0 1 0 1n 1n {0.5/frq} {1/frq}
.param frq=1K
.tran {50/frq}
.plot V(sgl)
.four 1K 19 V(sgl)
```

```
.four 1k 19 v(sgl):
Magnitude of Fundamental(RMS): 0.450158
```

Harmonic	Frequency	Magnitude	Phase
1	1.000e+03	1.000e+00	0.00°
2	2.000e+03	5.890e-06	-90.00°
3	3.000e+03	3.333e-01	-0.00°
4	4.000e+03	5.890e-06	-90.00°
5	5.000e+03	2.000e-01	-0.01°
6	6.000e+03	5.890e-06	-89.99°
7	7.000e+03	1.429e-01	-0.01°
8	8.000e+03	5.890e-06	-89.99°
9	9.000e+03	1.111e-01	-0.01°
10	1.000e+04	5.890e-06	-89.99°
11	1.100e+04	9.091e-02	-0.02°
12	1.200e+04	5.890e-06	-89.99°
13	1.300e+04	7.692e-02	-0.02°
14	1.400e+04	5.890e-06	-89.99°
15	1.500e+04	6.667e-02	-0.02°
16	1.600e+04	5.890e-06	-89.99°
17	1.700e+04	5.882e-02	-0.02°
18	1.800e+04	5.890e-06	-89.99°
19	1.900e+04	5.263e-02	-0.03°

```
THD = 45.686% (48.3398%)
```


# .four THD Computation

Qspice : THD - basic.qsch

## • .four THD

- [HARMONICS] and [PERIODS] is not necessary input parameters
- Magnitude and phase are normalized component equal 1 and 0 degree
- To compare FFT, FFT is to plot magnitude in RMS
  - Therefore, it requires to calculate with  $\text{Magnitude} * \text{Magnitude of Fundamental (RMS)}$  in .four to match calculation in FFT
  - In waveform viewer, right click, select FFT

sgl  
V1  
pulse 0 1 0 1n 1n {0.5/frq} {1/frq}  
.param frq=1K  
.tran {50/frq}  
.plot V(sgl)  
.four 1K V(sgl)



rms of harmonic 1 (fundamental)

Output Window

```
.four 1k v(sgl):  
Magnitude of Fundamental(RMS): 0.450158
```

Harmonic	Frequency	Magnitude	Phase
1	1.000e+03	1.000e+00	0.00°
2	2.000e+03	2.239e-05	-90.00°
3	3.000e+03	3.333e-01	-0.00°
4	4.000e+03	2.239e-05	-90.00°
5	5.000e+03	2.000e-01	-0.01°
6	6.000e+03	2.239e-05	-90.00°
7	7.000e+03	1.429e-01	-0.01°
8	8.000e+03	2.239e-05	-90.00°
9	9.000e+03	1.111e-01	-0.02°

THD = 42.8795% (48.337%)

Simulation Post Process

Calculate V(sgl),rms from .four into FFT chart

Harmonic 1 :  $\text{Magnitude} * \text{RMS} = 1.000e+0 * 0.45 = 0.45$

Harmonic 2 :  $\text{Magnitude} * \text{RMS} = 2.239e-5 * 0.45 = 0.00001$

Harmonic 3 :  $\text{Magnitude} * \text{RMS} = 3.333e-1 * 0.45 = 0.15$

⋮

# Compare Qspice and LTspice .four log

## Qspice

```
.four 1k v(sgl):
```

Magnitude of Fundamental(RMS): 0.450158

Harmonic	Frequency	Magnitude	Phase
1	1.000e+03	1.000e+00	0.00°
2	2.000e+03	2.239e-05	-90.00°
3	3.000e+03	3.333e-01	-0.00°
4	4.000e+03	2.239e-05	-90.00°
5	5.000e+03	2.000e-01	-0.01°
6	6.000e+03	2.239e-05	-90.00°
7	7.000e+03	1.429e-01	-0.01°
8	8.000e+03	2.239e-05	-90.00°
9	9.000e+03	1.111e-01	-0.02°

THD = 42.8795% (48.337%)

Equivalent  
(for order e-05, error  
between simulator can  
be expected)

## LTspice

Fourier Component in LTspice .four is Peak

Qspice :  $\text{Magnitude} * \text{RMS} * \sqrt{2} = 1 * 0.450158 * \sqrt{2} = 0.6366$

Fourier components of V(sgl)  
DC component:0.500001

Harmonic Number	Frequency [Hz]	Fourier Component	Normalized Component	Phase [degree]	Normalized Phase [deg]
1	1.000e+3	6.366e-1	1.000e+0	90.00°	0.00°
2	2.000e+3	2.239e-6	3.142e-6	0.00°	-90.00°
3	3.000e+3	2.122e-1	3.333e-1	90.00°	0.00°
4	4.000e+3	2.000e-6	3.142e-6	0.00°	-90.00°
5	5.000e+3	1.273e-1	2.000e-1	90.00°	0.00°
6	6.000e+3	2.000e-6	3.142e-6	0.00°	-90.00°
7	7.000e+3	9.095e-2	1.429e-1	90.00°	0.00°
8	8.000e+3	2.000e-6	3.142e-6	0.00°	-90.00°
9	9.000e+3	7.074e-2	1.111e-1	90.00°	0.00°

Partial Harmonic Distortion: 42.880402%

Total Harmonic Distortion: 48.342146%

.inc  
Include File

# Include File (.inc) : HELP > Schematic Capture > Simulator > Include File (.inc)


## Qspice : INC demo.qsch

- Include File

- To include a file to execute by simulator
- This allow to simplify schematic for directive or reuse purpose


- Example

- This example use .inc to include a file called QspiceScript.txt
- This script can
  - Calculate .func
  - Define .plot
  - Calculate .meas



### QspiceScript.txt

```
.func dVOUT() d(V(out))  
.plot dVOUT()  
.plot V(out) V(in)  
.meas Vo_pk max V(out)  
.meas tau find time when V(out)=0.63*Vo_pk
```



Output Window

```
.meas vo_pk max v(out) :  
9.99976 (at Time=0.05)  
.meas tau find time when v(out)=0.63*vo_pk :  
0.004674 0.004674
```


`.libpath`

Include a Directory  
into the Library File  
Search Path



# .libpath Include a Directory into the Library File Search Path


- .libpath
  - Syntax : .libpath <directory>
  - Search path for library .lib and include .inc directive
  - Search path priority
    1. Absolute path in .lib and .include
    2. Current working directory
    3. .libpath directories
    4. Qspice installation directory
      - Normal Install Path : C:\Program Files\QSPICE
- If .libpath is used, .lib or .inc must after .libpath in netlist
  - Therefore, recommend to use Ctrl-Enter method after .libpath to add .lib / .inc to ensure this sequence



```
.dc Vce 0 10 0.01 Ib list 0.01 0.1 0.4 1 2
```

```
.libpath C:\QspiceKSKelvin\Qspice Common Library  
.lib "KSKelvin_standard (from ltwiki).bjt"
```

```
.plot Ic(Q1)
```



.meas

Measure Statements

# Available Syntax for .meas


## HELP > Simulator > Command Reference > Measure(.meas)

---

- Syntax: .meas NAME find EXPRESSION1 at EXPRESSION2
  - Syntax: .meas NAME find EXPRESSION1 when EXPRESSION2=EXPRESSION3
  - Syntax: .meas NAME find EXPRESSION1 when EXPRESSION2=EXPRESSION3 td=5n cross=10
  - Syntax: .meas NAME find EXPRESSION1 when EXPRESSION2=EXPRESSION3 cross=last
  - Syntax: .meas NAME deriv EXPRESSION1 at EXPRESSION2
  - Syntax: .meas NAME trig EXPRESSION1=EXPRESSION2
  - Syntax: .meas NAME targ EXPRESSION1=EXPRESSION2
  - Syntax: .meas NAME trig EXPRESSION1=EXPRESSION2 targ EXPRESSION3=EXPRESSION4
  - Syntax: .meas NAME trig EXPRESSION1=EXPRESSION2 rise=1 targ EXPRESSION1=EXPRESSION2 rise=11
  - Syntax: .meas NAME avg|max|min|pp|rms|integ EXPRESSION1
  - Syntax: .meas NAME avg|max|min|pp|rms|integ EXPRESSION1 from EXPRESSION2 to EXPRESSION3
  - Syntax: .meas NAME avg|max|min|pp|rms|integ EXPRESSION1 trig EXPRESSION2=EXPRESSION3 targ EXPRESSION4=EXPRESSION5
  - Syntax: .meas NAME four FREQ EXPRESSION [...]
  - Syntax: .meas NAME fra FREQ INPUT OUTPUT [...]
-

# Example of .meas in .ac analysis

Qspice : meas ac demo 01.qsch



```
.param fn = 1K
.param wn = 2*pi*fn
.param z = 0.2
Laplace=wn^2/(s^2+2*z*wn*s+wn^2)
```


```
.ac dec 100 100 1e4
.plot V(out)
```

## Support 6 types of measure

avg/ave : average  
max : maximum  
min : minimum  
pp : peak to peak  
rms : root mean square  
integ : integral

```
.meas gainpeak max dB(V(out))
.meas freq@+5dB find frequency WHEN dB(V(out))=5 cross=2
.meas phase@2kHz find phase(V(out)) WHEN frequency=2K
```


```
|.meas gainpeak max db(v(out)) :
( 8.13428, -0.350754) (at Frequency=954.993)
.meas phase@2khz find phase(v(out)) when frequency=2k:
( -165.064, 0) 2000
.meas freq@+5db find frequency when db(v(out))=5 cross=2:
( 1150.32, 0) 1150.32
```



phase@2kHz find phase  
at frequency is 2kHz

# Example of .meas in .ac analysis for Q-factor

Qspice : meas - Q of LCR Resonant.qsch



```
.param L=10μ  
.param C=1μ  
.param R=0.2
```

```
.ac dec 1000 1 1G  
.options LISTPARAM  
.plot V(out)
```

Series RLC:

$$Q = \frac{1}{R} \sqrt{\frac{L}{C}}$$

Q formula of Series RLC

```
.param Qcal 1/R*(L/C)**0.5
```

Q calculation from Bandwidth (BW) and Center Frequency (fo) :  $Q = f_o / BW$

```
.meas Vmax max mag(V(out))
```

```
.meas fo FIND frequency WHEN mag(V(out))=Vmax
```


```
.meas fL FIND frequency WHEN mag(V(out))=Vmax/sqrt(2) rise=1
```

```
.meas fH FIND frequency WHEN mag(V(out))=Vmax/sqrt(2) fall=last
```

```
.meas BW fH-fL
```

```
.meas Q fo/BW
```

[1] Add this option  
to display parameter  
evaluations result in  
output window



Output Window

```
--- Parameter Evaluations ---  
TEMP      = 27      "CKTTEMP"  
L          = 10μ     "10μ"  
C          = 1μ      "1μ"  
R          = 200M    "0.2"  
QCAL      = 15.8114  "1/R*(L/C)**0.5"  
  
C:\Qspice\KSKelvin\01 User Guide and Script\01 Qspice Refer  
Total elapsed time: 0.129028 seconds.
```

In simulation, it has .param calculation results


Output Window

```
.meas vmax max mag(v(out)) :  
  ( 0.999914, 0) (at Frequency=50350.1)  
.meas fo find frequency when mag(v(out))=vmax:  
  ( 50350.1, 0) 50350.1  
.meas fL find frequency when mag(v(out))=vmax/sqrt(2) rise=1:  
  ( 48762.4, 0) 48762.4  
.meas fH find frequency when mag(v(out))=vmax/sqrt(2) fall=last:  
  ( 51946.8, 0) 51946.8  
.meas bw fH-fL:  
  ( 3184.36, 0) 1e+09  
.meas q fo/bw:  
  ( 15.8117, 0) 1e+09
```

In post process, it has .meas calculation results

# Example of .meas in .ac analysis

Qspice : meas tran demo 01.qsch



```
pulse 0 10 0 10n 10n 25µ 50µ
```

```
.tran 20m
```

```
.options MAXSTEP=0.1µ
```

Trick : If at=1m is removed, it return measurement at Tstop

```
.mease out@1ms V(out) at=1m
```

```
.mease out_steady avg V(out) from 19m to 20m
```



```
.mease Tr find Time when V(out)=0.9*out_steady
```

```
.meas Pin avg V(in)*-I(V1) from 19m to 20m
```

```
.meas Pout avg V(out)*I(R1) from 19m to 20m
```


```
.meas %error (Pin-Pout)/Pout*100
```

```
|.mease out@1ms v(out) at=1m:
    6.74785    0.001
.mease out_steady avg v(out) from 19m to 20m:
    5.00264
.mease tr find time when v(out)=0.9*out_steady:
    0.000562296 0.000562296
.meas pin avg v(in)*-i(v1) from 19m to 20m:
    5.00497
.meas pout avg v(out)*i(r1) from 19m to 20m:
    5.00528
.meas %error (pin-pout)/pout*100:
    -0.0061396    0.02
```



# .meas with trig and targ for time different calculation

Qspice : meas tran demo 02.qsch



.meas a2 trig V(signal)=0.8 cross=2  
[time different from 2<sup>nd</sup> crossing  
V(signal)=0.8 to end of simulation]

.meas a1 trig V(signal)=0.5  
[time different from V(signal)=0.5 to end of  
simulation]


.meas b1 targ V(signal)=-0.2  
[time different from V(signal)=-0.2  
to start of simulation]

.meas c1 trig V(signal)=-0.4 rise=1 targ V(signal)=-0.8 fall=2  
[time different from 1<sup>st</sup> rising of V(signal)=-0.4 to 2<sup>nd</sup> falling of  
V(signal)=-0.8]

# .meas with four (fourier component)

Qspice : meas fourier demo 01.qsch

```
.func rms2pk(in) in*sqrt(2)
```



```
.tran 5/1K
```

```
.plot V(sgl)
```

THD Total Harmonic Distortion

```
.four 1K V(sgl)
```

Fourier component with .meas

```
.meas xx four 1K V(sgl)
```

```
.meas |xx| abs(xx)
```

THD (.four)

.meas with four


```
.four 1k v(sgl):|
Magnitude of Fundamental(RMS): 0.999922
Harmonic Frequency Magnitude Phase
1 1.000e+03 1.000e+00 0.00°
2 2.000e+03 3.498e-08 105.41°
3 3.000e+03 5.996e-01 0.00°
4 4.000e+03 1.713e-08 64.78°
5 5.000e+03 1.996e-01 -0.00°
6 6.000e+03 1.341e-08 35.02°
7 7.000e+03 1.292e-06 -8.50°
8 8.000e+03 2.028e-08 -30.72°
9 9.000e+03 2.366e-07 -5.73°
```

```
THD = 63.1981%(63.1981%)
```

```
.meas xx four 1k v(sgl):
(1.54886e-07, -0.999999)
.meas |xx| abs(xx):
0.999999 0.005
```

Fourier component is a complex number (re+j\*im)


Magnitude (rms) can be calculated with abs()





# .meas with four (fourier component) [also with .step]

Qspice : meas fourier demo 02.qsch



```
.step dec param Vamp 100m 10 2
.tran 2m
.plot V(X)
```

THD Total Harmonic Distortion


```
.four 1K V(X)
```

Fourier component with .meas

```
.meas xx four 1K V(x) format : complex number
```

```
.meas |xx| abs(xx) convert complex to magnitude
```

```
.meas xx four 1k v(x) :
0 (-7.73763e-08, -0.0707086)
1 (-2.48947e-07, -0.223511)
2 (-3.44697e-06, -0.551818)
3 (-7.78738e-06, -0.698485)
4 ( 2.254e-06, -0.797766)
.meas |xx| abs(xx) :
0 0.0707086 0.002
1 0.223511 0.002
2 0.551818 0.002
3 0.698485 0.002
4 0.797766 0.002
```



# Plot .meas data in Waveform Viewer

## Qspice : meas waveform viewer.qsch

Method #1 :

[1] Add ".meas plot [Name]"

Method #2 :

[1] Run Simulation



[2] In Output Window

Right click in Post Process > Plot these Measurements

[3] X-axis default is .step parameter

[4] If you want to display X-axis parameter name



Right click x-axis > add bracket (or curly bracket) to parameter



# .meas – FRA : fourier component between OUTPUT and INPUT

Qspice : meas - fra demo 01.qsch


- Syntax : `.meas NAME fra FREQ INPUT OUTPUT [... range limits ...]`
  - FRA : Fourier component of OUT at FREQ divided by the Fourier component of IN at FREQ
  - Range limits can be set with from/to or trig/targ syntax
  - Normalization is to the time domain RMS




# .meas – FRA : fourier component between OUTPUT and INPUT

Qspice : meas - fra demo 02.qsch


- Frequency response (bode plot) from time domain with use of FRA
  - In this example, .step is used to sweep FRA frequency
  - Time domain simulation is performed at each FRA frequency



fmeas sweep from 100Hz to 10K with 50 points per decade



After .meas is ready in output window  
Right click → Plot these Measurements




.model  
Define Model

# .model – ako Aliases (A Kind Of)


Qspice : model - ako.qsch

- ako (undocumented)
  - Aliases (**A Kind Of**)
  - Syntax : **ako**:
  - Modify parameters of an existing model
  - Example
    - Smdl\_1 aliases model Smdl, but only changed Ron from 40 to 20
- Step model with ako!
  - With ako, it is possible to step a model in simulation
  - .step only accept numerical value
  - .model use numerical value for ako model name
  - Model name of device must be in curly bracket {}




```
.plot V(x)/I(S2)
.plot V(x)/I(S1)

.tran 2
.model Smdl SW Ron=40 Roff=100 Vt=0.5 Vh=0
.model Smdl_1 ako: Smdl Ron=20
```




{ } must be used to step model



```
.dc V1 0 1 0.01
.plot I(D1)

.step param mdl list 4148 4007

.model 4148 ako:1N4148
.model 4007 ako:1N4007
```



.noise  
Stochastic Noise  
Analysis

# .noise Stochastic Noise Analysis

Qspice : noise - basic.qsch

- .noise



- Stochastic Noise Analysis
- .noise calculated results

- Noise spectrum density per unit square root bandwidth ( $V/\sqrt{\text{Hz}}$ )
- Input : Inoise
- Output : Onoise

- Notes

- Noise analysis is performed without the needs of input voltage
- In output window, it calculates total integrated output and input-referenced noise in rms

- $\sqrt{\int (V_{\text{noise}})^2 df}$



Output Window (Simulation)

```
1 of 2 steps: .step r=1000
Total integrated output-referenced noise: 12.8748µV rms
Total integrated input-referenced noise: 12.8748µV rms
2 of 2 steps: .step r=2000
Total integrated output-referenced noise: 18.2077µV rms
Total integrated input-referenced noise: 18.2077µV rms
```

Output Window (Post-Processing)

```
.meas tmp integ v(onoise)*v(onoise):
0 1.65761e-10
1 3.31521e-10
.meas integrated sqrt(tmp):
0 1.28748e-05 1e+07
1 1.82077e-05 1e+07
```



`.option / .options`  
Set Simulator Options

# Set Simulator Options

## Set Simulator Options

Syntax: .option NAME1=VALUE1 [NAME2=VALUE2 [...]]

## Recognized Options

Name	Description	Default
ABSTOL	Absolute error tolerance	1e-12A
ACCT	Print accounting information	(not set)
ASCII	ASCII .raw file	(not set)
BINARY	Override command line switch to use ASCII .raw file	(not set)
BODEAMPFREQ	Frequency with the minimum perturbation amplitude. Set to 0. for constant amplitude.	(not set)
BODEINPUT <sup>1</sup>	Override input node for transfer function computation(AKA BODEIN)	auto
BODEPERIODS	Maximum number of periods to include in deconvolution	20
BODEREF	Reference node to use for Frequency Response Analysis	Node 0 (global ground)
BODEOUTPUT <sup>1</sup>	Override output node for transfer function computation((AKA BODEOUT)	auto
BODETOL	A Frequency Response Analysis relative tolerance	10.
CAPOP	0: Use model value 1: Use Meyer, >1 Use BSIM1	0
CHGTOL	Charge error tolerance	1e-14C
CSHUNT	Capacitance added from every node to ground(aka CMIN)	0F
DEFAD	Default MOSFET area of drain	0m <sup>2</sup>
DEFAS	Default MOSFET area of source	0m <sup>2</sup>
DEFL	Default MOSFET length	10μm
DEFW	Default MOSFET width	10μm
FEATHER	Trap integration damping factor	0
GMIN	Minimum conductance	1e-12S
GMINSTEPS <sup>2</sup>	Number of Gmin steps	10
GSHUNT	Conductance added from every node to ground	0S
ITL1	DC iteration limit	100
ITL2	DC transfer curve iteration limit	50
ITL4	Transient analysis iteration limit	10
KEEPOPINFO	Record operating point for small-signal analysis	(not set)

KEEPOPINFO	Record operating point for small-signal analysis	(not set)
LAUNCHQJUX <sup>3</sup>	Open the .raw file in the waveform viewer after the simulation	(not set)
LIST <sup>4</sup>	Print an expanded netlist	(not set)
LISTPARAM	Print a list of the evaluated parameters	(not set)
MAXORD	Maximum integration order	2
MAXSTEP	Maximum timestep size for .bode and .tran	infinite
METHOD	Integration method(trap or Gear)	trapezoidal
MINBREAK <sup>5</sup>	Minimum time between breakpoints	0s
NOOPITER	Go directly to Gmin stepping	(not set)
NUMDGT	Number of significant digits in an ASCII .raw file	15
PIVREL	Minimum relative matrix pivot	1e-3
PIVTOL	Minimum absolute matrix pivot	1e-13
RELTOL	Relative error tolerance	0.1%
RIC <sup>6</sup>	Impedance of source asserting initial conditions	1mΩ
SAVEPOWERS <sup>7</sup>	Compute and save the dissipation of components	(not set)
SEED <sup>8</sup>	Initialize the random number generator used in .param statements	
SEEDCLOCK	Initialize the random number generator with a 10Mhz clock and the process ID number(aka SEEDCLK).	(not set)
SRCSTEPS <sup>2</sup>	Number of source steps(aka ITL6)	10
TEMP	Operating temperature	27°C
TNOM	Nominal temperature(aka TREF)	27°C
TRTOL	Truncation error overestimation factor	2.5
TRTOL2	Another dimensionless truncation error guidance	1e-8
TRYTOCOMPACT	Try compaction for LTRA lines	(not set)
VNTOL	Voltage error tolerance	1μV

<sup>1</sup> If a resistor is used to indicate where to insert the perturbation, the resistive divider's contribution is excluded.

<sup>2</sup> Since an adaptive step size algorithms are used, the value of GMINSTEPS or SRCSTEPS is irrelevant unless set to zero, which means don't try the stepping algorithm.

<sup>3</sup> Useful when running simulations from the command line. Don't use it if QSPICE64.exe or QSPICE80.exe are launched from the GUI.

<sup>4</sup> Solely for internal diagnostic purposes. Probably not what you're looking for.

<sup>5</sup> MINBREAK is automatically computed if left zero.

<sup>6</sup> Inductor currents are asserted with the compliance of 1e9 \* RIC.

<sup>7</sup> Computes the true power dissipation while ignoring displacement currents. Implemented for BJTs, Capacitors, Diodes, Inductors, JFETs, MOSFET level 1, MOSFET level 2010 and VDMOS.

<sup>8</sup> Used in .param functions Random() and Gauss(double sigma).

# Simulator Options : CSHUNT and GSHUNT



Qspice : option - CSHUNT.qsch ; option - GSHUNT.qsch

## • CSHUNT

- Capacitance added from every node to ground (aka CMIN)
- **Default CSHUNT=0F**

## • Example to explain

- Cshunt is equivalent to add Cshunt1/2/3 in node a/b/c





## • GSHUNT

- Conductance added from every node to ground
- **Default GSHUNT=0Ω**

## • Example to explain

- Gshunt is equivalent to add  $Rshunt1/2/3 = \frac{1}{GSHUNT}$  in node a/b/c



# Simulator Options : Gmin





## Qspice : option - Gmin Diode.qsch

- Gmin

- Minimum conductance
  - LTspice : Conductivity added to every PNjunction to aid convergence
- Default Gmin=1e-12Ω

- Explanation

- Upper simulation use Gmin=1e-3 and measure I(V1) profile of D1a/D2a
- Lower simulation force Gmin=0 (no effect of Gmin) and added  $R_{2a}/R_{2b} = \frac{1}{1e-3}$ , and measure I(V2) profile of D2a/D2b
- This example demonstrate Gmin is equivalent to add shunt conductance for every PNjunction




# Simulator Options : Gmin

Qspice : option - Gmin L (.dc).qsch ; option - Gmin L (.tran).qsch

- Gmin

- Minimum conductance
- In Qspice, Gmin also applied to inductor in .op and .tran initial inductor current calculation
- Unlike PN junctions, gmin is only applied in inductor for its initial current calculation, but not added during transient analysis

.options Gmin=val




.step dec param val 1e-12 1e-4 10

.plot I(L1)

.op ← DC Operation Point Analysis

.options Gmin=val





.step dec param val 1e-12 1e-4 10

.plot I(L1)

.tran 1μ ← Transient Analysis




.meas Iinitial find I(L1) at 0 ← I<sub>L</sub> @ 0s



# Simulator Options : KEEPOPINFO

- KeepOpInfo

- Record operation point into .qraw for .ac and .tran
- A file with extension .op.qraw is forced to create
  - This .op.qraw file contains DC operating point data
  - Open .op.qraw file with waveform viewer, a list of operating point is generated
- .option keepopinfo is equivalent to use
  - Edit > Preferences
  - Click "Enable operating point display"
    - Hover device to display data only work with this enable



# Simulator Options : RIC

## Qspice : option - RIC L.qsch


- RIC

- Impedance of source asserting initial conditions
- Inductor currents are asserted with the compliance of  $1e9 * RIC$
- Default RIC=1m $\Omega$

- Important note


- RIC only affect inductor current if .ic is used to define inductor initial current
- In this simulation example, initial inductor current is plotted with Gmin=1e-12 and Gmin=1e3 with .ic I(L1)=1
  - When RIC=1e-3 (default), initial current is always equal .ic defined value

```
.options Gmin=1e-12  
.options RIC=RIC  
.step dec param RIC 1e-12 1e-3 10
```





```
.ic I(L1)=1  
.plot I(L1)  
.tran 1n  
.meas Iinitial find I(L1) at 0
```

```
.options Gmin=1e3  
.options RIC=RIC  
.step dec param RIC 1e-12 1e-3 10
```



```
.ic I(L1)=1  
.plot I(L1)  
.tran 1n  
.meas Iinitial find I(L1) at 0
```





# Simulator Options : Seed and Seedclock

## Qspice : option - Seed Seedclock.qsch



### • Seed

- Initialize the random number generator used in .param statements
- Same random pattern is generated between Simulation Run



### • Seedclock (aka Seedclk)

- Initialize the random number generator with a 10Mhz clock and the process ID number(aka SEEDCLK)
- Different random pattern is generated between Simulation Run





# Simulator Options : TRTOL

---

- TRTOL
  - Truncation error overestimation factor
    - Qspice : TRTOL = 2.5
    - LTspice : TRTOL = 1
    - Other spice simulators : TRTOL = 7
  - CSHUNT, GSHUNT, GMIN, TRTOL



.step  
Step User-Defined  
Parameter

# .step with table : Batch Simulation

## Qspice : Step with Table.qsch

- .step with table
  - By using table function, user can step integer N from 1, 2, 3, ... and assign value to different parameters according to table
  - This is an example to sweep upper and lower resistor network with different resistance combination

```
.op  
.step param N list 1 2 3  
.param Ra table(N, 1,10K, 2,20K, 3,30K)  
.param Rb table(N, 1,90K, 2,80K, 3,70K)  
.plot V(x)/-I(V1)  
.plot V(y)
```



N=1  
Ra=10K  
Rb=90K

N=2  
Ra=20K  
Rb=80K

N=3  
Ra=30K  
Rb=70K

.tran  
Non-Linear Transient  
Analysis

# Syntax of .tran (Non-Linear Transient Analysis)

- Two syntax of .tran Non-Linear Transient Analysis
  - .tran TSTOP [UIC]
    - If MAXSTEP is required in this syntax, use *.options MAXSTEP* instead
  - .tran **IGNORED** TSTOP [TSTART [MAXSTEP]] [UIC]
    - Recommend to fill 0 at IGNORED. This syntax allows to set start recording time and maxstep
    - If need to limit .graw file size, consider to specify Tstart and limit data to disk .graw file size

## 1. Specify only the stop time

Syntax: .tran TSTOP [UIC]

Name	Description	Units
TSTOP	Total amount of time to simulate	s
UIC	Use initial conditions instead of solving for the initial bias point(SKIPBP)	


## 2. Traditional Berkeley Syntax

Syntax: .tran IGNORED TSTOP [TSTART [MAXSTEP]] [UIC]


Name	Description	Units
IGNORED <sup>2</sup>	An ignored value	s
TSTOP	Total amount of time to simulate	s
TSTART	Time to start recording waveform data to disk	s
MAXSTEP	Maximum time step size to allow	s
UIC	Use initial conditions instead of solving for the initial bias point(SKIPBP)	

# .tran (Non-Linear Transient Analysis) : Syntax Examples


## Only Stop Time Syntax



```
.tran 5 .options MAXSTEP=10μ  
.tran 0 5 2 10μ  
.plot V(sin)
```




## Only Stop Time Syntax with .option MAXSTEP




Use .option to set MaxStep

```
.tran 5 .options MAXSTEP=10μ  
.tran 0 5 2 10μ  
.plot V(sin)
```




MaxStep increases  
simulation points

## Traditional Berkeley Syntax



.plot V(sin)


```
.tran 5 .options MAXSTEP=10μ  
.tran 0 5 2 10μ  
.tran Ignore Tstop Tstart MaxStep
```




# .tran (Non-Linear Transient Analysis) : No UIC

Qspice : .tran - UIC.qsch


## No UIC




```
.ic V(op)=2  
.plot V(op)  
.tran 10m
```




## No UIC + .IC




```
.ic V(op)=2  
.plot V(op)  
.tran 10m
```



## No UIC + Instance IC





```
.ic V(op)=2  
.plot V(op)  
.tran 10m
```





# .tran (Non-Linear Transient Analysis) : With UIC

Qspice : .tran - UIC.qsch



## With UIC



## With UIC + .IC



## With UIC + Instance IC





Batch mode  
Command

# Qspice Execution Files

---


- Qspice execution files
  - Directory (default installation) : C:\Program Files\QSPICE
  - Schematic Capture and Waveform Viewer Program (HELP > Waveform Viewer)
    - Execution file : [QUX.exe](#)
    - Function #1 : Convert .qsch schematic to .cir
    - Function #2 : Export data from data file .qraw
  - QSPICE Simulator (HELP > Simulator)
    - Execution file : [QSPICE64.exe](#) [Enable Fast (less accurate) Math]
    - Execution file : [QSPICE80.exe](#)
    - Function : Run simulation from .cir
  - Post Processor (HELP > Post Processor)
    - Execution file : [QPOST.exe](#)
    - Function : Execute .meas and .four from .qraw

# Batch command basic workflow

## Qspice : Qspice\_Batch\_Command\_LPFexample.bat / LPF Circuit.qsch

### • Batch command workflow

- Run CMD in Windows, in Command Prompt
- Set path for Qspice program
  - `path C:\Program Files\QSPICE\`
- Set variable name for working folder
  - `set Qname=LPF Circuit`
  - `set Qpath=C:\QspiceKSKelvin\Qspice Batch`
- Goto schematic .qsch directory
  - `cd %Qpath%`
- Convert .qsch to .cir (netlist)
  - `QUX -Netlist "%Qname%.qsch"`
- Run Qspice simulation for .graw
  - `QSPICE64 -binary "%Qname%.cir"`
  - `QSPICE64 -ascii "%Qname%.cir" -r "%Qname%-ascii.graw"`
- Export data from .graw to .csv
  - `QUX -Export "%Qname%.graw" V(mid),V(out)`
- Post Process .meas and .four
  - `QPOST "%Qname%.cir" -o "%Qname%.out"`



```
Command Prompt
Microsoft Windows [Version 10.0.19045.3086]
(c) Microsoft Corporation. All rights reserved.

C:\Users\ >path C:\Program Files\QSPICE\

C:\Users\ >set Qname=LPF Circuit

C:\Users\ >set Qpath=C:\QspiceKSKelvin\Qspice Batch

C:\Users\ >cd %Qpath%

C:\QspiceKSKelvin\Qspice Batch>QUX -Netlist "%Qname%.qsch"

C:\QspiceKSKelvin\Qspice Batch>LPF Circuit.cir
C:\QspiceKSKelvin\Qspice Batch>QSPICE64 -binary "%Qname%.cir"
C:\QspiceKSKelvin\Qspice Batch\LPF Circuit.cir

Total elapsed time: 0.0049635 seconds.

C:\QspiceKSKelvin\Qspice Batch>QUX -Export "%Qname%.graw" V(mid),V(out)

C:\QspiceKSKelvin\Qspice Batch>LPF Circuit.csv
C:\QspiceKSKelvin\Qspice Batch>QPOST "C:\QspiceKSKelvin\Qspice Batch\%Qname%.cir"
.meas fc find frequency when db(mag(v(out)))=-3:
( 242610, 0) 242610

C:\QspiceKSKelvin\Qspice Batch>
```

This PC > OS (C:) > QspiceKSKelvin > Qspice Batch

Name
LPF Circuit.cir
LPF Circuit.csv
LPF Circuit.graw
LPF Circuit.qsch
Qspice_Batch_Command_LPFexample.bat

# QUX.exe : Netlist a Schematic (.qsch)

- Syntax for QUX buildtimestamp
  - QUX.exe -buildtimestamp

```
C:\Program Files\QSPICE>QUX.exe -buildtimestamp  
C:\Program Files\QSPICE>Build Nov 3 2023 09:11:08
```

- Syntax for -Netlist
  - QUX.exe -Netlist <schematicfile> [-stdout]
    - <schematicfile> : name (+path) of a .qsch schematic, adds " " quotation for filename
    - If "-stdout" is not specified, the name of the netlist(.cir) file is computed from the name of the input .qsch file
    - [-stdout] : the netlist is printed on the console instead of to a file (not recommended since QSPICE employs a character set that most terminals can't handle)

```
C:\QspiceKSKelvin\Qspice Batch>QUX -Netlist "%Qname%.qsch" -stdout  
C:\QspiceKSKelvin\Qspice Batch>* LPF Circuit.qsch  
L1 in mid 1  
C1 mid 0 1  
R1 out 0 1  
V1 in 0 AC 1  
L2 mid out 1  
.ac dec 100 10K 1Meg  
.plot V(mid) V(out)  
.MEAS fc FIND frequency WHEN db(mag(V(out)))=-3  
.end
```

# QUX.exe : Export Datafile (.qraw)

- Syntax for -Export

- `QUX.exe -Export <datafile> <expr1[,expr2[,...]]> [Npoints] [CSV|SPICE|ASCII] [-stdout]`
  - `<datafile>` : name of a .qraw file
  - `<expr1[,expr2[,...]]>` : expressions of data to extract
    - No space are allowed in the expression
    - Comma-separated expressions
  - `[Npoints]` : number of equally-spaced data points to extract
    - Default Npoints=1000
    - Npoints=1e308 or Npoints=all : all datapoints are extracted, waveform is not interpolated
  - `[CSV|SPICE|ASCII]`
    - CSV : Comma-Separated Value file
    - SPICE : .qraw in binary
    - ASCII : .qraw in ASCII
  - `[-stdout]` : extracted data is printed on the console instead of to a file
  - Example
    - `QUX -Export "<filepath filename>" expr,expr2 all ascii` ← no quotation mark is required for `[Npoints]` and `[CSV|SPICE|ASCII]`

# QSPICE64.exe and QSPICE80.exe : QSPICE Simulator

- Syntax for output data .qraw name same as netlist .cir name
  - QSPICE64.exe -binary <netlistname> : Binary file format for output data .qraw
  - QSPICE64.exe -ascii <netlistname> : Ascii file format for output data .qraw
  - If 80 bit is used, change QSPICE64 to QSPICE80
- Syntax for specify output data .qraw name
  - QSPICE64.exe -[ascii/binary] <netlistname> -r <path> : specify the name of output data file
  - Example
    - set Qname=LPF Circuit
    - QSPICE64 -ascii "%Qname%.cir" -r "%Qname%-ascii.qraw"
- Syntax to directs the .qraw output to null (not saving a .qraw)
  - QSPICE64.exe <netlistname> -r NUL

# .qraw Binary Data format

```
Binary-binary.qraw
1 Title: * Binary.qsch
2 Date: Sun Nov 5 21:41:33 2023
3 Plotname: DC Transfer Characteristic
4 Flags: real
5 Abscissa: 1.0000000000000000e+00 5.0000000000000000e+00 lin
6 No. Variables: 4
7 No. Points: 3
8 Command: QSPICE64, Build Nov 3 2023 09:29:29
9 .param temp=27
10 Variables:
11 0 V1 voltage
12 1 V(a) voltage
13 2 I(V1) current
14 3 P(V1) power
15 Binary:
16 NOPNOPNOPNOPNOPNOP8? NOPNOPNOPNOPNOPNOP3? NOPNOPNOPNOPNOPNOP
```

```
Binary-binary.qraw Binary-ascii.qraw
1 Title: * Binary.qsch
2 Date: Sun Nov 5 21:41:38 2023
3 Plotname: DC Transfer Characteristic
4 Flags: real
5 Abscissa: 1.0000000000000000e+00 5.0000000000000000e+00 lin
6 No. Variables: 4
7 No. Points: 3
8 Command: QSPICE64, Build Nov 3 2023 09:29:29
9 .param temp=27
10 Variables:
11 0 V1 voltage
12 1 V(a) voltage
13 2 I(V1) current
14 3 P(V1) power
15 Values:
16 0 1.0000000000000000e+00
17 1 1.0000000000000000e+00
18 2 0.0000000000000000e+00
19 3 0.0000000000000000e+00
20 1 3.0000000000000000e+00
21 2 3.0000000000000000e+00
22 3 0.0000000000000000e+00
23 0 0.0000000000000000e+00
```

Binary vs Ascii


Newline </n>

```
00000130 76 6f 6c 74 61 67 65 0a 09 32 09 49 28 56 31 29 voltage..2.I(V1)
00000140 09 63 75 72 72 65 6e 74 0a 09 33 09 50 28 56 31 .current..3.P(V1)
00000150 29 09 70 6f 77 65 72 0a 42 69 6e 61 72 79 3a 0a ).power.Binary:.
00000160 00 00 00 00 00 00 00 f0 3f 00 00 00 00 00 00 f0 3f .....8?.....8?
00000170 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
00000180 00 00 00 00 00 00 00 00 00 00 00 00 00 08 40 .....@.....@
00000190 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
000001a0 00 00 00 00 00 00 14 40 00 00 00 00 00 00 14 40 .....@.....@
000001b0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
```

Binary Format : Float 64

# QPOST.exe : Post Processor to execute .meas and .four

- Syntax for Qpost.exe
  - Qpost <netlistname> -o <consoleoutput>
    - This will write .meas and .four results into a file for the console output
    - This result is equivalent in Qspice Post Process Output Window after Simulation is run



path C:\Program Files\QSPICE\

set Qname=resistor\_network

set Qpath=C:\QspiceKSKelvin\O1 User Guide and  
Script\O2 Qspice Reference Guide\Batch  
Command\Qpost

cd %Qpath%

QUX -Netlist "%Qname%.qsch"

QSPICE64 -binary "%Qname%.cir"

QPOST "%Qname%.cir" -o "%Qname%.out"

resistor_network.out				
1	.meas	@amp	param	amp:
2	0	1		
3	1	1.1		
4	2	1.2		
5	3	1.3		
6	4	1.4		
7	5	1.5		
8	6	1.6		
9	7	1.7		
10	8	1.8		
11	9	1.9		
12	10	2		
13	.meas	vrms	xrms	v(in):
14	0	0.707107		
15	1	0.777817		
16	2	0.848528		
17	3	0.919239		
18	4	0.989949		
19	5	1.06066		
20	6	1.13137		
21	7	1.20208		
22	8	1.27279		
23	9	1.3435		