



Customer Process Guidelines

AirPrime HL Series



SIERRA
WIRELESS®

4114330
6.0
December 03, 2015

Important Notice

Due to the nature of wireless communications, transmission and reception of data can never be guaranteed. Data may be delayed, corrupted (i.e., have errors) or be totally lost. Although significant delays or losses of data are rare when wireless devices such as the Sierra Wireless modem are used in a normal manner with a well-constructed network, the Sierra Wireless modem should not be used in situations where failure to transmit or receive data could result in damage of any kind to the user or any other party, including but not limited to personal injury, death, or loss of property. Sierra Wireless accepts no responsibility for damages of any kind resulting from delays or errors in data transmitted or received using the Sierra Wireless modem, or for failure of the Sierra Wireless modem to transmit or receive such data.

Safety and Hazards

Do not operate the Sierra Wireless modem in areas where cellular modems are not advised without proper device certifications. These areas include environments where cellular radio can interfere such as explosive atmospheres, medical equipment, or any other equipment which may be susceptible to any form of radio interference. The Sierra Wireless modem can transmit signals that could interfere with this equipment. Do not operate the Sierra Wireless modem in any aircraft, whether the aircraft is on the ground or in flight. In aircraft, the Sierra Wireless modem **MUST BE POWERED OFF**. When operating, the Sierra Wireless modem can transmit signals that could interfere with various onboard systems.

Note: Some airlines may permit the use of cellular phones while the aircraft is on the ground and the door is open. Sierra Wireless modems may be used at this time.

The driver or operator of any vehicle should not operate the Sierra Wireless modem while in control of a vehicle. Doing so will detract from the driver or operator's control and operation of that vehicle. In some states and provinces, operating such communications devices while in control of a vehicle is an offence.

Limitations of Liability

This manual is provided "as is". Sierra Wireless makes no warranties of any kind, either expressed or implied, including any implied warranties of merchantability, fitness for a particular purpose, or noninfringement. The recipient of the manual shall endorse all risks arising from its use.

The information in this manual is subject to change without notice and does not represent a commitment on the part of Sierra Wireless. SIERRA WIRELESS AND ITS AFFILIATES SPECIFICALLY DISCLAIM LIABILITY FOR ANY AND ALL DIRECT, INDIRECT, SPECIAL, GENERAL, INCIDENTAL, CONSEQUENTIAL, PUNITIVE OR EXEMPLARY DAMAGES INCLUDING, BUT NOT LIMITED TO, LOSS OF PROFITS OR REVENUE OR ANTICIPATED PROFITS OR REVENUE ARISING OUT OF THE USE OR INABILITY TO USE ANY SIERRA WIRELESS PRODUCT, EVEN IF SIERRA WIRELESS AND/OR ITS AFFILIATES HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR THEY ARE FORESEEABLE OR FOR CLAIMS BY ANY THIRD PARTY.

Notwithstanding the foregoing, in no event shall Sierra Wireless and/or its affiliates aggregate liability arising under or in connection with the Sierra Wireless product, regardless of the number of events, occurrences, or claims giving rise to liability, be in excess of the price paid by the purchaser for the Sierra Wireless product.

Customer understands that Sierra Wireless is not providing cellular or GPS (including A-GPS) services. These services are provided by a third party and should be purchased directly by the Customer.

SPECIFIC DISCLAIMERS OF LIABILITY: CUSTOMER RECOGNIZES AND ACKNOWLEDGES SIERRA WIRELESS IS NOT RESPONSIBLE FOR AND SHALL NOT BE HELD LIABLE FOR ANY DEFECT OR DEFICIENCY OF ANY KIND OF CELLULAR OR GPS (INCLUDING A-GPS) SERVICES.

Patents

This product may contain technology developed by or for Sierra Wireless Inc.

This product includes technology licensed from QUALCOMM®.

This product is manufactured or sold by Sierra Wireless Inc. or its affiliates under one or more patents licensed from InterDigital Group and MMP Portfolio Licensing.

Copyright

© 2015 Sierra Wireless. All rights reserved.

Trademarks

Sierra Wireless®, AirPrime®, AirLink®, AirVantage®, WISMO®, ALEOS® and the Sierra Wireless and Open AT logos are registered trademarks of Sierra Wireless, Inc. or one of its subsidiaries.

Watcher® is a registered trademark of NETGEAR, Inc., used under license.

Windows® and Windows Vista® are registered trademarks of Microsoft Corporation.

Macintosh® and Mac OS X® are registered trademarks of Apple Inc., registered in the U.S. and other countries.

QUALCOMM® is a registered trademark of QUALCOMM Incorporated. Used under license.

Other trademarks are the property of their respective owners.

Contact Information

Sales Desk:	Phone:	1-604-232-1488
	Hours:	8:00 AM to 5:00 PM Pacific Time
	Contact:	http://www.sierrawireless.com/sales
Post:	Sierra Wireless 13811 Wireless Way Richmond, BC Canada V6V 3A4	
Technical Support:	support@sierrawireless.com	
RMA Support:	repairs@sierrawireless.com	
Fax:	1-604-231-1109	
Web:	http://www.sierrawireless.com/	

Consult our website for up-to-date product descriptions, documentation, application notes, firmware upgrades, troubleshooting tips, and press releases: www.sierrawireless.com

Document History

Version	Date	Updates
1.0	June 04, 2013	Creation
1.1	June 20, 2013	Updated: <ul style="list-style-type: none"> • 3.2.2 Footprint • 4.1 Stencil Design • Table 1 Solder Reflow Profile
2.0	November 18, 2014	Updated: <ul style="list-style-type: none"> • Product list in 1.2 Reference Documents • Baking conditions in 2.1.3 Moisture Sensitivity • 2.2.1 Package Description • 2.3.1 Packing Description • 3.2.2 Footprint
3.0	June 08, 2015	Updated: <ul style="list-style-type: none"> • 2.1.2 ESD • 2.2.2 Marking Description • 3.2.2 Footprint • 5 Rework Guidelines
4.0	October 20, 2015	Updated: <ul style="list-style-type: none"> • Product list in 1.2 Reference Documents • 2.2.1 Package Description • 2.2.2 Marking Description • Figure 4 AirPrime HL Series Tape and Reel • 4.2 Solder Reflow Profile
5.0	November 05, 2015	Updated: <ul style="list-style-type: none"> • Figure 7 Recommended Solder Resist and Paste Mask Layout • Figure 8 Recommended Reflow Profile
6.0	December 03, 2015	Added support for HL6528RDx
		Updated 2.2.1 Package Description

Contents

1. INTRODUCTION	7
1.1. Overview.....	7
1.2. Reference Documents.....	7
2. HANDLING	8
2.1. Storage and Handling of the AirPrime HL Series Module	8
2.1.1. Storage Condition	8
2.1.2. ESD	8
2.1.3. Moisture Sensitivity	8
2.2. Component Package	9
2.2.1. Package Description	9
2.2.2. Marking Description	10
2.3. Component Packing	11
2.3.1. Packing Description	11
2.3.2. Packing Label.....	11
3. SMT ASSEMBLY PROCESS	12
3.1. Lead-Free Process	12
3.2. PCB Design Requirements	12
3.2.1. PCB Surface Finish.....	12
3.2.2. Footprint	12
3.2.3. Layout Recommendations	13
3.3. Solder Mask.....	14
4. BOARD MOUNTING GUIDELINES	15
4.1. Stencil Design.....	15
4.2. Solder Reflow Profile	16
5. REWORK GUIDELINES.....	17
5.1. Component Removal.....	17
5.2. Pad Redress	17
5.3. Solder Paste Deposit.....	17
5.4. New Component Placement.....	18
5.5. New Component Soldering	18

List of Figures

Figure 1.	Different Assembly Technologies on AirPrime HL Series Modules	9
Figure 2.	AirPrime HL Series Shielded Product Label Example	10
Figure 3.	AirPrime HL Series Molded Product Marking Example.....	10
Figure 4.	AirPrime HL Series Tape and Reel	11
Figure 5.	Packing Label	11
Figure 6.	Recommended Footprint – Copper Layout	13
Figure 7.	Recommended Solder Resist and Paste Mask Layout.....	15
Figure 8.	Recommended Reflow Profile	16

1. Introduction

1.1. Overview

This document presents guidelines for the industrial assembly of an AirPrime HL Series Embedded Module on an application.

1.2. Reference Documents

- [1] AirPrime HL3450 Product Technical Specification
Reference number: 4117500
- [2] AirPrime HL6528x Product Technical Specification
Reference number: 4114016
- [3] AirPrime HL6528RDx Product Technical Specification
Reference number: 4114330
- [4] AirPrime HL7518 Product Technical Specification
Reference number: 4115834
- [5] AirPrime HL7519, HL7548 and HL7588 Product Technical Specification
Reference number: 4116369
- [6] AirPrime HL7528 Product Technical Specification
Reference number: 4116873
- [7] AirPrime HL7549 Product Technical Specification
Reference number: 4117459
- [8] AirPrime HL7618 Product Technical Specification
Reference number: 4117929
- [9] AirPrime HL8518, HL8528 and HL8529 Product Technical Specification
Reference number: 4117047
- [10] AirPrime HL8548 and HL8548-G Product Technical Specification
Reference number: 4114663
- [11] AirPrime HL8549 and HL8549-G Product Technical Specification
Reference number: 4115653
- [12] JEDEC standard JESD625-A, Requirements for Handling Electrostatic Discharge – Sensitive (ESDS) Devices
- [13] ANSI/ESD S20.20: Protection of Electrical and Electronics Parts, Assemblies and Equipment
- [14] IPC/JEDEC J-STD-033 – Handling, Packing, Shipping and Use of Moisture / Reflow Sensitive Surface Mount Devices

2. Handling

2.1. Storage and Handling of the AirPrime HL Series Module

2.1.1. Storage Condition

AirPrime HL modules can be stored in their sealed, original packages, for up to 1 year.

They can withstand a storage temperature range between -40°C to +85°C, nevertheless when packed into T&R the upper storage temperature is decreased to +40°C due to T&R packaging material.

Tip: *For optimal results, the recommended storage temperature is +20°C +/- 10 degrees.*

2.1.2. ESD

The AirPrime HL Series unit is ESD sensitive. For ESD level information, refer to the corresponding Product Technical Specification of each product as listed in section 1.2 Reference Documents.

It is recommended to use standard ESD precautions, as described in the following standards:

- JEDEC standard JESD625-A, Requirements for Handling Electrostatic Discharge-Sensitive (ESDS) Devices
- ANSI/ESD S20.20: Protection of Electrical and Electronics Parts, Assemblies and Equipment

2.1.3. Moisture Sensitivity

The AirPrime HL Series module is sensitive to moisture absorption:

- MSL 3, 245 °C, 2 reflows allowed on customer PCB including one for rework of the component

Caution: *Baking conditions differ according to the HL assembly technology (see section 2.2.1).*

For shielded versions, if tape & reel vacuum pack is open for more than 168h, material should be baked at 40°C for 13 days. If parts are on tray, baking conditions are 24 hours minimum at 85°C.

For molded versions, if the vacuum bag is open for more than 168h, material should be baked for 48 hours at 125°C in tray. Nevertheless, it is recommended to store the modules in dry cabinet (<10% RH) once the vacuum bag is opened.

It is recommended to follow the standard MSL procedure, as described in the following standard:

- IPC/JEDEC J-STD-033 - Handling, Packing, Shipping and Use of Moisture / Reflow Sensitive Surface Mount Devices.

2.2. Component Package

2.2.1. Package Description

The AirPrime HL Series module is a scalable QFN (quad flat no lead) package, 22x23x2.5 mm (except for the HL8549 and HL8549-G being 24x25x2.5 mm), pitch 0.8 mm with 146 terminals.

The terminals include:

- 66 inner signal pads
- 8 mechanical corner pads
- 7 signal pads for JTAG
- 1 polarity mark
- 64 ground pads

The PCB material is FR4. Plating is NiAu ($3\text{ }\mu\text{m} < \text{Nickel} < 8\text{ }\mu\text{m}$ and $0.05 < \text{Gold} < 0.13\text{ }\mu\text{m}$).

Different assembly technologies are used inside the HL Series modules. Some HL modules use Sierra Wireless standard assembly process with a metallic soldered shielding, while others use an overmolding compound plus metal sputtering. Baking conditions and other parameters may vary depending on the technology used. Refer to sections 2.1.3 Moisture Sensitivity and 4.2 Solder Reflow Profile for specific parameters per assembly technology; and the corresponding product technical specification for the assembly technology used per HL Series module.




Figure 1. Different Assembly Technologies on AirPrime HL Series Modules

For additional information, refer to the corresponding Product Technical Specification of each product as listed in section 1.2 Reference Documents.

2.2.2. Marking Description

Marking contents and marking methods on the module may differ between each variant of the product family.

The marking method can be via paper label or laser marking. For variants that use laser marking, there are rare instances where these modules are marked with a paper label instead.

Common label content includes:

- Model Name
- Serial Number and IMEI or MEID Number (both letters and data matrix bar code)
- Fabrication Country
- Relevant regulatory compliance markings and identification codes (this may be a CE logo, FCC ID number, IC ID number, etc.)
- Pin 1 indicator for solder-down modules

The examples below are not contractual and don't show exact contents of the label. Label contents may also be moved around to fit any additional customer-specific need or market segment and can change without notice at the sole discretion of Sierra Wireless.




Figure 2. AirPrime HL Series Shielded Product Label Example




Figure 3. AirPrime HL Series Molded Product Marking Example

2.3. Component Packing

2.3.1. Packing Description

The AirPrime HL Series module is delivered in tape and reel.

Quantity per tape & reel is 500.




Figure 4. AirPrime HL Series Tape and Reel

P1	P0	W
28.0 mm	4.0 mm	44.0 mm

2.3.2. Packing Label







	
Product Model: XXXXXX	
Manufacturer P/N: XXXXXXXX	
XXXXXXXXXXXXXXXXXXXX	
XXXXXXXXXXXXXXXXXXXX	
Box/Reel Number: XXXXXXXXXXXXXXXX	
	
Quantity: 000	Customer P/N: 0000000000
	
Customer PO#: 0000000000	<h1>RoHS</h1> <p>Made in China</p>
	
Packing Date: 00/00/0000 00:00:00	
	

Figure 5. Packing Label



3. SMT Assembly Process

This section presents information and recommendations for the industrial assembly of the AirPrime HL Series module on the application.

Note: *The HL Series products should be assembled by reflow process.*

3.1. Lead-Free Process

In compliance with directive 2011/65/CE, Sierra Wireless products do not contain the following hazardous substances:

- mercury (Hg),
- lead (Pb),
- cadmium (Cd),
- hexavalent chromium (Cr+6),
- polybrominated diphenyl ether (PBDE),
- polybrominated biphenyl (PBB).

The AirPrime HL Series modules are manufactured with RoHS compliant components and processes.

3.2. PCB Design Requirements

3.2.1. PCB Surface Finish

The PCB surface finish recommended is Electroless Nickel, immersion Gold. Organic Solderability Preservative (OSP) may also be used.

Caution: *Hot Air Solder Leveled finish (HASL) is not recommended because the process does not give consistent solder volumes on each pad because of poor pad flatness.*

3.2.2. Footprint

In order to produce high assembly yields and a reliable solder joint, the footprint on the customer application board should match Figure 6 below.

Mechanical drawings of the AirPrime HL Series module's footprint are available in the Product Technical Specification of each product as listed in section 1.2 Reference Documents.




Figure 6. Recommended Footprint – Copper Layout

Note: The 64 inner pads and the 8 corner pads are ground pads.

Sierra Wireless suggests that customers place a copper pad under the Polarity mark to avoid any risk of short circuits between this pin and the customer layout; however, there is no need to solder it. This mark also eases visual confirmation of the module's correct orientation.

For molded versions, the copper pad should not extend out of the module as the PCA edge side is conductive.

3.2.3. Layout Recommendations

Sierra Wireless' layout recommendations include:

- A GROUND area under the HL series module. This ground area should be a whole area of copper with proper ground vias to provide a good grounding system between the application and the embedded module and improved thermal dissipation. It should be covered by solder resist on the non-soldered area.
The ground vias may be micro-vias, filled or unfilled. Through-holes can be used in between each of the 64 ground pads (under the solder resist).
- There should not be any SIGNAL trace or hole / micro-via under the AirPrime HL product.
- The antenna pad and its track should be adapted according to RF constraints, based on customer layout. Refer to each corresponding Product Technical Specification for more details.
- Manufacturing tolerance for copper pad is $\pm 30 \mu\text{m}$.
- Leave a component-free area of 2 mm around the HL Series unit for accessing the surrounding components and for scalability with the HL8549x.

3.3. Solder Mask

The pads on the printed circuit board are either Solder Mask Defined (SMD) or Non Solder Mask Defined (NSMD).

Since the copper etching process has tighter control than solder masking process, NSMD pads are preferred over SMD pads.

Moreover, NSMD pads with solder mask opening larger than the metal pad size also improve the reliability of solder joints, as this limits the stress concentration at the solder-to mask corner interface.

For external pads, the solder mask opening should be 100 μm to 150 μm larger than the pad, resulting in 50 μm to 75 μm clearance between the copper pad and solder mask. This allows for solder mask registration tolerances, depending upon the PCB fabricator's capabilities.

For ground pads, SMD should be used as the ground area under the AirPrime HL Series module. (Refer to Figure 7).

The recommended solder mask thickness on the top copper is 10 to 30 μm .

>> 4. Board Mounting Guidelines

4.1. Stencil Design

The recommended stencil thickness is 125 μm .

The proposed stencil design is presented in the figure below.

It is highly recommended to monitor the solder paste height, registration and proper placement during the squeegee printing.




Figure 7. Recommended Solder Resist and Paste Mask Layout

4.2. Solder Reflow Profile

Lead-free SMT reflow profiles should be used to surface mount the AirPrime HL Series module.

The reflow profile depends on PCB density and type of solder paste being used. The paste manufacturer's recommendation should also be considered to determine the proper reflow profile.

Table 1. Solder Reflow Profile

Peak Temperature	245°C max
Reflow Time (over 220°C), for molded versions	60 sec max

2 reflows are allowed on the customer PCB including one for rework of the component if necessary.

The figure below is an example of reflow profile.




Figure 8. Recommended Reflow Profile

Additional recommendations are presented in the table below for consideration.

Factor	Recommendation
Max slope	1 to 3°C / sec
Soak time (between A and B: 150 and 190°C)	60 to 120 sec
Reflow time (D: over 220°C)	40 to 60 sec
Max temperature (C)	235 – 245°C
Cooling down slope	1 to 3°C / sec

It is recommended to perform reflow in a nitrogen atmosphere.

>> 5. Rework Guidelines

Rework tools and operating parameters are customer/application specific. Rework tools, heating profiles and the rework process should be tailored to these specific needs for optimum results.

Prior to any rework, if the component floor life has been exceeded, it is highly recommended to bake the PCB in order to remove moisture from the assembly. (See JEDEC J-STD-033 paragraph 6 - Board rework. If possible for the PCB and the other components of the board, apply the same baking conditions as per section 2.1.3).

The pre-baking process will prevent damage to any component due to moisture vapor pressures caused during reflow.

Prior to removal, the metal shielding of the AirPrime HL Series shielded module must be glued to the module substrate, by using glue able to withstand reflow profile.

5.1. Component Removal

The step consists of reflowing the solder joints attaching components to the PCB. Ideally, the reflow profile for part removal should be the same as the one used for part attachment. However, the time above liquidus can be reduced as long as the reflow is complete.

In the removal process, it is recommended that the board should be heated from the bottom side using convective heaters and hot gas, or hot air or IR should be used on the top side of the component. Special nozzles or IR lens should be used to direct the heating in the component area and heating of adjacent components should be minimized.

Excessive hot airflow should also be avoided, as this causes the component to overheat.

Once the joints have reflowed, the vacuum lift-off should be automatically engaged for pick-up during the transition from reflow to cool down.

Warning: *If heating conditions are not properly controlled during manual hot removal from PCB assembly, package integrity can be damaged from overheating.*

5.2. Pad Redress

Once the component has been removed, the site and pads need to be cleaned properly. It is better to use the combination of a blade style conductive tool and a fluxed desoldering braid.

Once the residual solder has been removed, the land pads should be cleaned with a solvent. The solvent is usually specific to the type of solder paste used in the original assembly and the paste manufacturer's recommendations should be followed.

5.3. Solder Paste Deposit

Once the PCB is properly cleaned and inspected, solder paste should be applied on the solder land (on the component itself or on the customer PCB) with a mini-stencil which has same thickness and apertures as the stencil used for original attachment.

5.4. New Component Placement

A slip-beam optical system should be used to align the component to the PCB. This method will display an image of the land pad overlaid on the mating footprint and aid in proper alignment. Similar to paste printing, the alignment should be done under magnification of 50x to 100x.

5.5. New Component Soldering

The reflow profile developed during original attachment or removal should be used to attach the new component.



SIERRA
WIRELESS®