

# List of Contents

## GENERAL INFORMATION

<b>1. Safety</b>	<b>1-1</b>
1.1 Introduction	1-1
1.2 Safety Precautions	1-1
1.3 Caution and Warning Statements	1-1
1.4 Impaired Safety Protection	1-1
1.5 Electrostatic Sensitive Devices	1-2
<b>2. Introduction and Applications</b>	<b>2-1</b>
2.1 Introduction	2-1
2.2 Applications	2-1
2.3 Configuration	2-2
<b>3. Product Data</b>	<b>3-1</b>
3.1 Safety Characteristics	3-1
3.2 Performance Characteristics	3-1
3.3 Versions	3-1
3.4 Options	3-1
3.5 Electrical Data	3-1
3.6 Environmental Conditions	3-2
<b>4. Accesories and Options</b>	<b>4-1</b>
4.1 Accessories	4-1
4.2 Options	4-1

## INSTALLATION AND OPERATING INSTRUCTIONS

<b>5. Installation</b>	<b>5-1</b>
5.1 Initial Inspection	5-1
5.2 Safety Instructions	5-1
5.3 Power Supply Cord and Fuses	5-1
5.4 Rack Mounting	5-2
5.5 Cleaning	5-3
5.6 Access to and Replacement of Parts	5-3
<b>6. Configuration</b>	<b>6-1</b>
6.1 General Information	6-1
6.2 Jumpers	6-1
<b>7. Operating Instructions</b>	<b>7-1</b>
7.1 Front Panel Indicators	7-1
7.2 Front Panel Controls	7-1
7.3 Rear Panel Connections	7-2

**SERVICE INSTRUCTIONS**

<b>8. General Service Information</b>	<b>8-1</b>
8.1 Use of the Service Instructions	8-1
8.2 Safety	8-1
8.3 Block Diagram Symbols Description	8-1
<b>9. Instrument Block Diagram</b>	<b>9-1</b>
9.1 General Information	9-1
9.2 Basic Instrument	9-1
9.3 Options	9-2
<b>10. Circuitry Description</b>	<b>10-1</b>
10.1 Main Board - Unit 1	10-1
10.2 Front Panel - Unit 2	10-2
10.3 Remote Interfaces	10-2
10.4 Options	10-2
<b>11. Performance Check</b>	<b>11-1</b>
11.1 General Information	11-1
11.2 Basic Instrument	11-1
11.3 PT 8617 - BNC Option	11-2
11.4 PT 8618 - XLR Option	11-2
<b>12. Service Hints</b>	<b>12-1</b>
12.1 Maintenance	12-1
12.2 Repairs	12-1
<b>13. List of Mechanical Parts</b>	<b>13-1</b>
<b>14. List of Electrical Parts</b>	<b>14-1</b>
<b>15. List of Recommended Spare Parts</b>	<b>15-1</b>