

Operation of PT5212 remote

The PT5212 functions as a master controller for the changeover, and behaves virtually as the changeover itself. There are however certain differences, that the user should be aware of:

- When turned on, the remote is per default disabled for remote control. This is so no unwanted changes are made in the changeover settings. The external remote-LED will flash x times, to indicate software version. Hereafter the remote is ready for operation.
- On power on, the remote settings are set, as they were before it was shut down.
- If auto/manual mode is changed in the changeover when the remote is disabled, these changes are not known by the remote. When the remote is again enabled, the remote settings will be applied to the changeover. The remote control will always override the changeover settings, when enabled.
- If remote control is disabled, the primary sync generator selection on the remote will follow the 'on air' generator on the changeover.
- When in 'manual mode' and with 'remote control' *enabled*, the buzzer will not sound when a generator fails. The error LEDs will however still indicate failures. (the buzzer will sound, when in 'manual mode' and with 'remote control' *disabled* if enabled in the changeover)
- When in 'auto mode', both LEDs and the buzzer will indicate failures. To reset the error state, set the remote into 'manual mode' or change primary sync generator.
- When switching from 'auto mode' to 'manual mode' on the remote, the primary sync generator will be set to the 'on air' generator.
- If the error state is not reset, the changeover can not automatically switch sync generator, when an new error occurs.

Below is an schematic for operation of the remote:

Remote enable	Auto/Manual mode	Event	Action
Off	X	Switch to 'remote enabled'	While disabled, the remote responds only to the 'remote enable' button. The primary generator selection follows the 'on air' generator. When enabled, the remote settings will be applied to the changeover
On	Manual	Switch to 'remote disabled'	The remote will go into 'disabled mode', behaving like described above.
On	Manual	Switch to 'auto mode'	The remote will go into 'auto mode'.
On	Manual	Switch prim. sync generator	The primary sync selection will change.
On	Auto	Switch to 'remote disabled'	The remote will go into 'disabled mode', behaving like described above.
On	Auto	Switch to 'manual mode'	The remote will go into 'manual mode'. The primary generator will be set to the 'on air' generator. This resets error states, if a generator has failed.
On	Auto	Switch prim. sync generator	The primary sync selection will change. This resets error states, if a generator has failed.