



## Setting up the IOT2000

SIMATIC IOT2020, SIMATIC IOT2040

<https://support.industry.siemens.com/tf/ww/en/posts/155642/>

Siemens  
Industry  
Online  
Support



## Legal information

### Use of application examples

Application examples illustrate the solution of automation tasks through an interaction of several components in the form of text, graphics and/or software modules. The application examples are a free service by Siemens AG and/or a subsidiary of Siemens AG ("Siemens"). They are non-binding and make no claim to completeness or functionality regarding configuration and equipment. The application examples merely offer help with typical tasks; they do not constitute customer-specific solutions. You yourself are responsible for the proper and safe operation of the products in accordance with applicable regulations and must also check the function of the respective application example and customize it for your system.

Siemens grants you the non-exclusive, non-sublicensable and non-transferable right to have the application examples used by technically trained personnel. Any change to the application examples is your responsibility. Sharing the application examples with third parties or copying the application examples or excerpts thereof is permitted only in combination with your own products. The application examples are not required to undergo the customary tests and quality inspections of a chargeable product; they may have functional and performance defects as well as errors. It is your responsibility to use them in such a manner that any malfunctions that may occur do not result in property damage or injury to persons.

### Disclaimer of liability

Siemens shall not assume any liability, for any legal reason whatsoever, including, without limitation, liability for the usability, availability, completeness and freedom from defects of the application examples as well as for related information, configuration and performance data and any damage caused thereby. This shall not apply in cases of mandatory liability, for example under the German Product Liability Act, or in cases of intent, gross negligence, or culpable loss of life, bodily injury or damage to health, non-compliance with a guarantee, fraudulent non-disclosure of a defect, or culpable breach of material contractual obligations. Claims for damages arising from a breach of material contractual obligations shall however be limited to the foreseeable damage typical of the type of agreement, unless liability arises from intent or gross negligence or is based on loss of life, bodily injury or damage to health. The foregoing provisions do not imply any change in the burden of proof to your detriment. You shall indemnify Siemens against existing or future claims of third parties in this connection except where Siemens is mandatorily liable.

By using the application examples you acknowledge that Siemens cannot be held liable for any damage beyond the liability provisions described.

### Other information

Siemens reserves the right to make changes to the application examples at any time without notice. In case of discrepancies between the suggestions in the application examples and other Siemens publications such as catalogs, the content of the other documentation shall have precedence.

The Siemens terms of use (<https://support.industry.siemens.com>) shall also apply.

### Security information

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, systems, machines and networks.

In order to protect plants, systems, machines and networks against cyber threats, it is necessary to implement – and continuously maintain – a holistic, state-of-the-art industrial security concept. Siemens' products and solutions constitute one element of such a concept.

Customers are responsible for preventing unauthorized access to their plants, systems, machines and networks. Such systems, machines and components should only be connected to an enterprise network or the Internet if and to the extent such a connection is necessary and only when appropriate security measures (e.g. firewalls and/or network segmentation) are in place. For additional information on industrial security measures that may be implemented, please visit <https://www.siemens.com/industrialsecurity>.

Siemens' products and solutions undergo continuous development to make them more secure. Siemens strongly recommends that product updates are applied as soon as they are available and that the latest product versions are used. Use of product versions that are no longer supported, and failure to apply the latest updates may increase customer's exposure to cyber threats.

To stay informed about product updates, subscribe to the Siemens Industrial Security RSS Feed at: <https://www.siemens.com/industrialsecurity>.

# Table of contents

<b>Legal information .....</b>	<b>2</b>
<b>1 Task.....</b>	<b>4</b>
1.1 Overview.....	4
<b>2 Requirements .....</b>	<b>5</b>
2.1 Required Hardware .....	5
2.2 Required Software.....	9
<b>3 Operating .....</b>	<b>10</b>
3.1 Installing the SD-Card Example Image .....	10
3.2 First Commissioning of the SIMATIC IOT2000 .....	15
3.2.1 Remote access with Putty SSH Connection .....	15
3.2.2 Change IP Address .....	21
3.2.3 Create new directory on the SIMATIC IOT2000 .....	24
<b>4 Checklist .....</b>	<b>26</b>
<b>5 Related links.....</b>	<b>27</b>
<b>6 History.....</b>	<b>27</b>

# 1 Task

## 1.1 Overview

### Introduction

This Setting Up shows how to set up the SIMATIC IOT2000 with a SD-Card image provided through the Siemens Industry Online Support.

### Goals

After working through this document you know how to

- Get remote access to the SIMATIC IOT2000
- Change the IP-Address of the SIMATIC IOT2000
- Create a new directory on the SIMATIC IOT2000

## 2 Requirements

### 2.1 Required Hardware

This chapter contains the hardware required for this Setting up.

#### **SIMATIC IOT2000**

Two different versions of the SIMATIC IOT2000 are available. The hardware of both versions is described in this document. However, this Setting Up will only use the SIMATIC IOT2020 as basis for all examples. In order to setup the SIMATIC IOT2040, proceed in the same way as described for the SIMATIC IOT2020.

#### **SIMATIC IOT2020**

Hardware Overview:

- Intel Quark® x1000
- 512 MB RAM
- 1 Ethernet Interface
- 1 USB Host Type A
- 1 USB Client microUSB



Figure 2-1




Table 2-1

No.	Description
1	Aperture for wall-mounting
2	Designation for integration of antennas
3	Connection for Power Supply
4	5 LED's, 1 programmable USER LED
5	Left cap
6	Right cap
7	Aperture to lock the right cap
8	RESET button for the CPU
9	USER button
10	Ethernet Interface 10/100 Mbps
11	USB Typ Mini-B
12	USB Typ A

### SIMATIC IOT2040

#### Hardware Overview:

- Intel Quark® x1020
- 1 GB RAM
- 2 Ethernet Interfaces
- 2 RS232/485 interfaces
- Battery buffered RTC

#### Interface Overview:

Figure 2-2




Table 2-1

No.	Description
1	Aperture for wall-mounting
2	Designation for integration of antennas
3	Connection for Power Supply
4	COM-Interfaces (RS232/485)
5	5 LED's, 1 programmable USER LED
6	Left cap
7	Right cap
8	Aperture to lock the right cap
9	RESET button for the CPU
10	USER button
11	Ethernet Interface 10/100 Mbps
12	Ethernet Interface 10/100 Mbps
13	USB Typ Mini-B
14	USB Typ A

### Micro-SD Card

SIMATIC IOT2000 can be operated with a Yocto Linux Operating System, which requires the use of a Micro-SD Card.

The requirement for using SIMATIC IOT2000 with Yocto Linux Operating System is a Micro-SD Card with storage capacity from 8GB up to 32GB.

### Engineering Station

To work with the SIMATIC IOT2000 an Engineering Station is required. In this Setting Up a PC with Windows 7 Enterprise is used.

The Engineering Station has to include the following Interfaces:

- SD Card Slot
- Ethernet Port

### Ethernet cable

For an Ethernet Connection between the Engineering Station and the SIMATIC IOT2000 in order to establish a SSH connection and to download the Eclipse projects an Ethernet cable is required.

### Power supply

In order to run the SIMATIC IOT2000 a power supply is required.

This power supply has to provide between 9 and 36V DC.



### 2.2 Required Software

This chapter contains the software required for this Setting up.

#### Micro-SD Card Example Image

To use the full functionality of the SIMATIC IOT2000 a SD-Card Example Image with a Yocto Linux Operating System is necessary to be installed. This Image is provided through the Siemens Industry Online Support.

It can be downloaded [here](#).

#### PuTTY

To get remote access to the SIMATIC IOT2000 software is required.

In this Getting Started “PuTTY” is used. With this software it is possible to establish a connection to different devices for example via Serial, SSH or Telnet.

The “PuTTY” software can be downloaded [here](#).

#### Win32 Disk Imager

In order to put the SD Card image to the µSD Card software is needed.

In this Setting Up the Win32 Disk Imager is used.

The “Win32 Disk Imager” can be downloaded [here](#).

#### NOTE

All existing data on the SD Card will be removed!

## 3 Operating

This chapter describes the steps necessary to install and start up the SIMATIC IOT2000 using the hard- and software listed before.


For the necessary software components please refer to the download links in [Chapter 2.2](#)




### 3.1 Installing the SD-Card Example Image




The first step to work with the SIMATIC IOT2000 is to set up a Micro-SD Card with the Image provided through the [Siemens Industry Online Support](#).




The following table shows the required steps to transfer the SD-Card Image to a Micro-SD Card.


Table 3-1

No.	Action
1.	Insert the $\mu$ SD-Card via SD-Card Adapter in the SD-Card Slot of your Engineering Station
2.	Retrieve the downloaded SD Card image .zip-file
3.	Install the downloaded "Win32DiskImager-x.x.x-install.exe"
4.	Start the Win32 Disk Imager
5.	Click on the folder 

No.	Action
6.	<p>Select “*.*” in the right bottom corner Then select the “iot2000-example-image-iot2000.wic” file in the retrieved SD Card Image folder</p> 
7.	<p>Select the drive letter of your SD Card</p> 
8.	<p>Click the “Write” button</p> 

No.	Action
9.	<p>Confirm the warning message  <b>NOTE: All data will be deleted</b></p>  <p>The dialog box shows a warning icon and text: "Writing to a physical device can corrupt the device. (Target Device: [E:] '') Are you sure you want to continue?". The "Yes" button is highlighted with a red rectangle.</p>
10.	<p>You will receive a success message if the transfer is done</p>  <p>The dialog box shows an information icon and text: "Write Successful.". The "OK" button is highlighted with a red rectangle.</p>
11.	<p>Right click on "Safely Remove Hardware and Eject Media"</p>  <p>The context menu shows options: "Open Devices and Printers", "Eject HP Skylab USB Smartcard Keyboard", "Eject WinUSB", "Eject Unknown USB Device (Port Reset Failed)", and a "Device" section with sub-items: "Eject (F:) Removable Disk", "Eject (G:) Removable Disk", and "Eject (E:) BOOT0". The "Eject (E:) BOOT0" option is highlighted with a red rectangle.</p> <p>Choose the SD Card</p>

No.	Action
12.	<p data-bbox="499 304 1359 338">Insert the <math>\mu</math>SD-Card into the <math>\mu</math>SD-Card Slot of the SIMATIC IOT2000 as follows:</p> <ol style="list-style-type: none"> <li data-bbox="499 371 788 405">1. Slide the locking down</li> <li data-bbox="499 931 727 965">2. Open the locking</li> <li data-bbox="499 1491 762 1525">3. Insert the <math>\mu</math>SD-Card</li> </ol> <div data-bbox="496 405 1375 893">  </div> <div data-bbox="496 965 1375 1453">  </div> <div data-bbox="496 1525 1331 1998">  </div>

No.	Action
	<p>4. Close the locking and slide it up</p> 



## 3.2 First Commissioning of the SIMATIC IOT2000

### Ethernet cable

The following table shows how to connect the SIMATIC IOT2000 and the engineering station with an Ethernet cable.

Table 3-2

No.	Action
1.	Connect one end of the Ethernet cable to an Ethernet-Port of the Engineering Station
2.	Connect the other end of the Ethernet cable to the Ethernet-Port X1P1 of the SIMATIC IOT2000. Note: If you use the SIMATIC IOT2040 X1P1 is the left port.

### Power supply

The following table shows how to connect the SIMATIC IOT2000 to a power supply.

Table 3-3

No.	Action
1.	Power off the power supply
2.	Connect the cable to the connecting terminal
3.	Connect the connecting terminal to the SIMATIC IOT2000
4.	Power on the power supply

The diagram illustrates the physical connection of the power supply to the SIMATIC IOT2000. It shows a terminal block with two terminals labeled 'M' and 'L+'. A blue wire is connected to 'M' and a red wire to 'L+'. An arrow labeled '2' points from the wires to the terminal block. Another arrow labeled '3' points from the terminal block to the SIMATIC IOT2000 module. A label '1 POWER OFF' is shown next to the wires.

**CAUTION** Only use a DC 9...36V power supply!

### 3.2.1 Remote access with Putty SSH Connection



The Software “Putty” can be used to get remote access from the Engineering Station to the SIMATIC IOT2000 via Serial, SSH or Telnet.



In this Example the SSH connection is used.

- NOTE** The SIMATIC IOT2000 has a static IP address by default.  
This address is **192.168.200.1**.  
The Engineering Station has to be in the same subnet as the SIMATIC IOT2000 to establish a SSH connection!
- NOTE** The first boot may last a few minutes –up to 5 – because the filesystem is resized automatically. The time is depending on the SD card you are using.



The following table shows how to use Putty.

Table 3-4

No.	Action
1.	Open downloaded Putty.exe with double-click 
2.	Configure the connection as follows: <ol style="list-style-type: none"> <li>1. Choose the Connection Type "SSH"</li> <li>2. Enter the IP address 192.168.200.1</li> <li>3. The port is 22 by default</li> <li>4. This configuration can be saved as Default Settings (Mark Default Settings and press the "Save" Button)</li> </ol> <p><b>Hint</b> Under Window &gt; Translation Tab, set ISO-8859-15:1999 (Latin-9, "euro") for proper character set.</p> 

No.	Action
3.	<p>Click on "Open" button for opening the communication to the SIMATIC IOT2000 via SSH.</p> 
4.	<p>Connecting the first time via SSH a Warning dialog will appear. It is necessary to update the SSH key. Press the "Yes" button.</p> 

No.	Action
5.	<p data-bbox="507 306 938 336">If once confirmed a login dialog appears</p>  <p>The screenshot shows a PuTTY terminal window titled '192.168.200.1 - PuTTY'. The terminal displays the prompt 'login as:' followed by a green cursor. The background is black, and the text is white.</p>
6.	<p data-bbox="507 963 890 992">Type "root" and press the Enter key</p>  <p>The screenshot shows the same PuTTY terminal window. The prompt 'login as:' has been replaced by 'root', and the user has entered 'root'. The prompt is now 'root@iot2000:~#'. The background is black, and the text is white.</p> <p data-bbox="507 1520 783 1550">The login was successful.</p> <p data-bbox="507 1585 970 1615">Note: There is no password set per default.</p>

No.	Action
7.	<p>Set a password for the login “root” because of security issues:</p> <ol style="list-style-type: none"> <li>1. Type in “passwd”</li> <li>2. Set a new password (input is hidden)</li> <li>3. Confirm the password (input is hidden)</li> </ol> 
8.	<p>Now a few Linux commands can be tested.</p> <p>For example, “cd /” to get in the file system and “ls” to list the folders in the current directory</p> 






### 3.2.2 Change IP Address



In the default settings of the SIMATIC IOT2000's Image, the IP address is set to **192.168.200.1**. Thus, if another static IP address or a DHCP address is required, this can be set with the `iot2000setup` tool

The following table displays the procedure for configuring the IP address settings.

Table 3-5

No.	Action
1.	Open a valid serial Putty connection and login as root (i.e. See <a href="#">topic 3.3</a> )
2.	<p>Type in "<code>iot2000setup</code>" to open the setup tool, navigate to "Networking" and press "Enter"</p>  <p>&lt;Tab&gt;/&lt;Alt-Tab&gt; between elements   &lt;Space&gt; selects   &lt;F12&gt; next screen</p>
3.	<p>Select active interfaces by putting cross and press "OK"</p> <p>eth0 = X1P1, eth1 = X2P1</p>  <p>&lt;Tab&gt;/&lt;Alt-Tab&gt; between elements   &lt;Space&gt; selects   &lt;F12&gt; next screen</p>

No.	Action
4.	<p>Change the static IP address of your interfaces here, if required. If a DHCP address is required, write "dhcp" to your interface</p>  <p>The first screenshot shows a terminal window titled '192.168.200.1 - PuTTY'. Inside, a dialog box titled 'Configure eth0' is displayed. The dialog box contains the text: 'Specify IP addresses for network interfaces, enter 'dhcp' to obtain address by DHCP.' Below this text, the text 'eth0 192.168.200.1' is shown with a green cursor at the end of the IP address. There are two red buttons at the bottom: 'OK' and 'Cancel'.</p> <p>The second screenshot shows a terminal window titled '192.168.200.1 - PuTTY'. Inside, a dialog box titled 'Configure eth1' is displayed. The dialog box contains the text: 'Specify IP addresses for network interfaces, enter 'dhcp' to obtain address by DHCP.' Below this text, the text 'eth1 dhcp' is shown with a green cursor at the end of 'dhcp'. There are two red buttons at the bottom: 'OK' and 'Cancel'.</p> <p>&lt;Tab&gt;/&lt;Alt-Tab&gt; between elements   &lt;Space&gt; selects   &lt;F12&gt; next screen</p>

No.	Action
5.	<p>Default netmask 255.255.255.0 will be added to /etc/network/interfaces configuration file.</p>  <p>If you want to change the netmask you have to edit the file “interfaces” in the directory “/etc/network”</p> <p>Therefore, type in “nano /etc/network/interfaces” and change the netmask for your interface</p> <p>After changing do the following:</p> <ol style="list-style-type: none"> <li>Press Ctrl+X to Exit</li> <li>Press Y to save</li> <li>Press Enter</li> </ol> 

**NOTE**

You can use the `iot2000setup` tool for many other settings. Just have a look at it.

### 3.2.3 Create new directory on the SIMATIC IOT2000


The default storage path for scripts, created with the Eclipse IDE, on the SIMATIC IOT2000 is the directory “tmp”. The files present in this directory, will be automatically deleted after a reset or power failure of the SIMATIC IOT2000.


In order to avoid the loss of scripts, a new directory can be created where the files will be stored.

This is only an example; the projects can be stored in other locations too.

The following table shows how to create a new directory in the SIMATIC IOT2000's filesystem.

Table 3-6

No.	Action
1.	Open a valid serial Putty connection and login as root (i.e. See <a href="#">topic 3.3</a> )
2.	Type in “cd /home” command to change the current directory to the home directory of filesystem, and then press the Enter key.
3.	Type in “mkdir <Foldername>” to create a new directory and then press the Enter key (i.e mkdir ProjectFolder) 
4.	Type in “ls” to show all directories

No.	Action
	 <p>The created folder is now present in the directory “/home”.</p>

## 4 Checklist

This chapter contains a Checklist which summarizes all important steps in this Setting up.

Table 4-1

No.	Action
1.	<a href="#">Download the software listed</a>
2.	<a href="#">Write the image to the µSD Card</a>
3.	<a href="#">Insert the µSD-Card to the SIMATIC IOT2000</a>
4.	<a href="#">Connect the Ethernet cable</a>
5.	<a href="#">Connect the Power Supply</a>
6.	<a href="#">Establish a SSH with PuTTY</a>
7.	<a href="#">Change IP-Address</a>
8.	<a href="#">Create a new storage directory for the Eclipse projects</a>



## 5 Related links

Table 5-1

	Topic
\1\	SIMATIC IOT2000 forum <a href="http://www.siemens.com/iot2000-forum">www.siemens.com/iot2000-forum</a>
\2\	Download SD-Card Example Image <a href="https://support.industry.siemens.com/cs/ww/en/view/109741799">https://support.industry.siemens.com/cs/ww/en/view/109741799</a>
\3\	SIMATIC IOT2000 Getting Started <a href="https://support.industry.siemens.com/tf/ww/en/posts/155643/">https://support.industry.siemens.com/tf/ww/en/posts/155643/</a>
\4\	Operating Instructions <a href="https://support.industry.siemens.com/cs/document/109741658/simatic-iot2020-simatic-iot2040?dti=0&amp;lc=en-WW">https://support.industry.siemens.com/cs/document/109741658/simatic-iot2020-simatic-iot2040?dti=0&amp;lc=en-WW</a>

## 6 History

Table 6-1

Version	Date	Modifications
V1.0	09/2016	First version
V2.0	01/2017	Added chapter "Resize the SD card partition"
V2.1	08/2017	Added iot2000setup tool for changing IP Removed manually resizing of filesystem
V2.6	12/2019	Updated network configuration via iot2000setup tool