

How to install the Firmware

There are two programs that need to be installed before you can upload software on the Seeeduino's

Download and install Arduino: <http://arduino.cc/en/Main/Software>

Download and install tortoissvn: <http://tortoissvn.net/downloads>

- 1) Get the your log in data from Jerry
- 2) Open file manager
- 3) Go to the directory were you want to save all of the repository data
- 4) Right click in the file manager and select SVN Checkout
- 5) Enter in the URL: <https://129.82.106.205/svn/BuildingEnergy>
- 6) Remember you need to be connected to the CSU Engr. network

To load software on to the boards. For additional example go to:

http://seedstudio.com/wiki/Seeeduino_Stalker_v2.0#Key_Technical_Specifications
and go to Usage section.

- 1) Plug in the Seeeduino to the UartSBee and the UartSBee to your computer.
- 2) Open Arduino IDE.
- 3) Go to File → Preferences and change your Sketchbook location :
(~/BuildingEnergy/trunk/Arduino).
Note: ~ is the location of your repository
Alternately: copy file to your sketchbook. This is not suggested.
- 4) Go to Tools → Board → Arduino Pro or Pro Mini (3.3v,8MHz) w/Atmega328
- 5) Go to File → Open; scroll to ~/BuildingEnergy/trunk/NodeFirmware-Installed/NodeFirmware – 2011_12_07/NodeFirmware/, click on NodeFirmware.pde
- 6) A new window will open, (you can close the first window) go to Tools → Serial Port → (The code port your seeeduino is attached to)
Note: go control panel → device manger; to find were the Seeduino is attached too.
- 7) There are 7 icons, The first icon (or play icon) is the compile button, the sixth button is the upload button, press this button to upload the software.
Note: upload can also be found: file → Upload to I/O Board.
- 8) To test the code make sure the debug variables are set high, and click the seventh button to put up the Serial Monitor.
Note: Serial Monitor can also be found: Tools → Serial Monitor.

If you have any question you can e-mail me at: kspremo@rams.colostate.edu