



Contents

INTRODUCTION.....	3
HOW TO USE THE LIBRARY?	3
REFERENCE	4
COM.ANDROID.AUDIODEC.AUDIO32DECODER.INIT().....	4
COM.ANDROID.AUDIODEC.AUDIO32DECODER. DECODE()	5
COM.ANDROID.AUDIODEC.AUDIO32ENCODER.INIT ().....	6
COM.ANDROID.AUDIODEC.AUDIO32ENCODER.ENCODE ()	7

The information contained herein is the exclusive property of SONiX and shall not be distributed, reproduced or disclosed in whole or no in part without prior written permission of SONiX. 本資料為松翰科技股份有限公司專有之財產，未經書面同意不准透露、使用，亦不准複印或轉變成任何其他形式使用。



VERSION HISTORY

Version	Date	Description
V1.0.0	2015/04/23	First Version

The information contained herein is the exclusive property of SONiX and shall not be distributed, reproduced or disclosed in whole or no in part without prior written permission of SONiX. 本資料為松翰科技股份有限公司專有之財產，未經書面同意不准透露、使用，亦不准複印或轉變成任何其他形式使用。

Introduction

This document describes how to use the static library, libAudio32Decoder.so and libAudio32Encoder.so, to build a Audio32 16K encode/decode app based on android developer sample code.

How to use the library?

Below is just a rough call flow to show how components work, please refer to the sample code for detail usage.

- Import Library

Add library into your project (/lib/armeabi)

- Import library API

Add Audio32Decoder.java and Audio32Encoder.java to package com.android.AudioCodec

Reference

com.android.AudioCodec.Audio32Decoder.init()

Prototype: void init(short sample_rate, short bit_rate, short in_size, short out_size)

Parameters:

short sample_rate	: Audio sample rate
short bit_rate	: Audio bit rate
short in_size	: Retention, The default input 0
short out_size	: Retention, The default input 0

Returned Value:

none

Description:

To initial audio32 decoder lib.

Notes:

Example:

```
short sample_rate = 16000;  
short bit_rate = 16000;  
short in_size = 0;  
short out_size = 0;  
com.android.AudioCodec.Audio32Decoder.init(sample_rate, bit_rate, in_size, out_size);  
...
```

com.android.AudioCodec.Audio32Decoder.decode()

Prototype: short[] decode(short[] input);

Parameters:

short[] input : input data

Returned Value:

Return audio32 decode data

Description:

Audio32 decode.

Notes:

input buffer size is 20 (short).

output buffer size is 320 (short).

Example:

```
// Audio32 16K Decode
```

```
short[] output = new short[320];
```

```
output = com.android.AudioCodec.Audio32Decoder.decode(input);
```

```
// input buffer size is 20 (short).
```

com.android.AudioCodec.Audio32Encoder.init ()

Prototype: void int(short sample_rate, short bit_rate, short in_size, short out_size)

Parameters:

short sample_rate	: Audio sample rate
short bit_rate	: Audio bit rate
short in_size	: Retention, The default input 0
short out_size	: Retention, The default input 0

Returned Value:

none

Description:

To initial audio32 encoder lib.

Notes:

Example:

```
short sample_rate = 16000;  
short bit_rate = 16000;  
short in_size = 0;  
short out_size = 0;  
com.android.AudioCodec.Audio32Encoder.init(sample_rate, bit_rate, in_size, out_size);
```

com.android.AudioCodec.Audio32Encoder.encode()

Prototype: short[] encode(short[] input);

Parameters:

short[] input : input data

Returned Value:

Return audio32 encode data

Description:

Audio32 encode.

Notes:

input buffer size is 320 (short).

output buffer size is 20 (short).

Example:

```
// Audio32 16K Encode
```

```
short[] output = new short[20];
```

```
output = com.android.AudioCodec.Audio32Encoder.encode(input);
```

```
// input buffer size is 320 (short).
```