

# Installation Tool Kit

## Overview

Installation Tool Kit







## Tool Kit Content

Number	Description
1	<b>Flexy Sensor</b> Fitting Tool with handle
2	<b>Standard Sensor</b> O-Ring Fitting Tool
3	Hinged Ratchet Combination Spanner (10mm for rim clamps)
4	<b>Standard Sensor</b> Fitting Tool
5	Adapter (Fitting tool to Torque Driver)

Number	Description
6	Torque Driver (fixed to 4Nm)
7	O-Ring (Standard Sensor)
8	O-Ring (Flexy Sensor)
9	300mm Extension Bar for Torque Driver

Tool Kit How To

Description	Items used	Picture
<b>Standard Sensor</b> Installation on single tires	4+5+6	
<b>Standard Sensor</b> Installation on dual tires	4+5+6+9	
<b>Flexy Sensor</b> Installation	1	
Rim Clamp Installation	3	

Description	Items used	Picture
O-Ring Replacement	2	