

***Operator manual***

***KSW-7B***

***VNC / FieldBus***

---

### \*\*\* SAFETY REGULATIONS \*\*\*

**Being under voltage the device must not be opened. Danger of electric shock exists. Service works at the weighing equipment are permitted only for qualified personnel. In case of works at conveying lines, all relevant drives have to be switched-off and secured against re-engaging.**



The related device/system may only be set-up and operated in connection with this documentation. Start-up and operation of a devices/system may only be carried out by **qualified personnel**. Qualified personnel in terms of safety notes of this documentation are persons being authorized to take into operation, to ground and to label the devices, systems and circuits in accordance with the standards of safety engineering.

## Index

1 General description .....	6
1.1 Symbols .....	6
1.2 Hardware- Aufbau Basisgerät KSW-7B .....	6
1.3 Optional TP-7B Operator Panel .....	8
2 Operating Mode / Single Scale - Variants .....	10
2.1 Simple actual weight measurement (static balance) .....	11
2.2 Charging in weight containers (batch positive) .....	12
2.3 Charging from weighed storage container (batch negative) .....	13
2.4 Multiple single scales in one KSW-7B .....	14
3 Mode – Board scale .....	15
4 VNC Connection .....	17
4.1 Network setting on the PC .....	17
4.2 Start VNC .....	18
5 General operation of the KSW-7B .....	19
5.1 Navigation for KSW-7B .....	19
5.2 Overview .....	20
6 Parameterization .....	21
6.1 Px1000 Scale Data - Parameters .....	21
6.2 Px1500 Auxiliary drives XD0 – XD3 .....	22
6.3 Px2000 Limits .....	23
6.4 Px4000 Special functions .....	24
6.5 Px5000 Analog I/O .....	25
7 Fieldbus Communication .....	26
7.1 FB Status .....	27
7.2 ProfibusDP - General .....	28
7.3 ProfibusDP data transfer rate / plug assignment .....	28
7.4 ProfibusDP – Node Address .....	28
7.5 ProfiNet – IP-Adresse .....	29
7.6 ProfibusDP - LED Statusmeldungen .....	29
7.7 Data structure / consistence .....	29
7.8 ProfibusDP - GSD-Datei .....	30
7.9 ProfiNet - GSDML-Datei .....	30
7.10 DeviceNet - EDS-Datei .....	30
7.11 EthernetIP - EDS-Datei .....	30
8 General data structure .....	31
8.1 Setpoint and process data fields .....	31
8.2 Recommended data structure (for standard applications only) .....	32
8.3 Control and status bits (byte order / endianness) .....	33

---

9 PARAMETER DESCRIPTION .....	34
9.1 General parameter up to 9xxxx .....	34
9.2 Change the IP address .....	35
9.3 Set time and date .....	36
9.4 Create parameter list / USB or FTP .....	37
9.5 General Fieldbus parameters 97xxx .....	38
9.6 Setpoints and Commands via Fieldbus (P972x) .....	38
9.7 Actual values and control/status bits via fieldbus (P974xx) .....	40
10 Communication with S7 controllers (Profibus / ProfiNetIO) .....	44

## Revisionsliste

Revision	Datum	Autor	Kapitel	Beschreibung
FB_KSW7_V01_11en	29.07.2021	AutoTranslate	all	Automatic translation

## Software indication

These instructions are based on following Software versions:

**V 1.11**

In course of the technical progress changes can be carried out at the software. At subsequent software versions therefore, deviations are possible compared to these instructions.

Only operating instruction in German is considered as

ORIGINAL INSTRUCTION

All other languages are defined as Translations.

KUKLA WAAGENFABRIK GmbH & Co KG  
Stefan-Fadingerstrasse 1-11  
A-4840 VOECKLABRUCK

Tel. +43 (0)7672-26666-0

Homepage: [www.kukla.co.at](http://www.kukla.co.at)  
email: [office@kukla.co.at](mailto:office@kukla.co.at)

## 1 General description

This manual describes the KSW-7B system in general and in particular the communication possibilities via fieldbus systems of the KSW-7B scale system.

### 1.1 Symbols

This manual uses the following symbolism as special icons:



**IMPORTANT NOTE !**  
Marks an important note.



**WARNING!**  
Indicates a general warning.



**DANGER!**  
means that death or serious bodily injury may occur if the corresponding  
Precautions are not taken

SPS      Is a central controller (PLC) superior to the scale system  
PLC

### 1.2 Hardware- Aufbau Basisgerät KSW-7B

Basically, the KSW-7 allows the following application, which is defined in the parameter P93000:

00: Mono-Scale	In this operating mode, one or more individual wagons can be realized with a single KSW-7B.
01: Board Scale	This operating mode allows the weight of individual plasterboards to be measured.

Each balance basically has its own input or inputs for the force transducer (weight signal) as well as a digital input and output card.



Here is a usual minimal structure with additional cards shown:

KSW-7B is the actual CPU module  
PM2 is the power supply module (24VDC)

The 1st scale includes:

WC00 is the mV weight signal input from the force transducer.

DI00 is a digital input card for control commands

DI01 is an optional input card, here one or more analog and digital cards can optionally be inserted as required (DIxx, DOxx, AIxx, AOxx)

A KSW-7B can currently contain up to 5 scales depending on the expansion stage. A further expansion to 8 scales is planned in the medium term. Simply use the WC10,DI10,DI11,... and so on. expanded to the right. The KSW-7B can be up to about 70cm wide.



For the details regarding ATEX in particular as well as all other technical details, the specifications of the original operating manual of the manufacturer must be strictly followed!

Download at: <https://download.br-automation.com/> ( Product X20 – CP0482 + Components)

## 1.3 Optional TP-7B Operator Panel



Each KSW-7B can control an optional operator panel.

Communication takes place via the VNC protocol. This means that the terminal is actually just a VNC\_Client.


For this reason, the display display can also be displayed on any other available device that supports VNC client communication.

This also applies to PCs and notebooks with a VNC client


If the VNC client uses a mobile phone or tablet without an Ethernet RJ45 connector, a WLAN wireless connection must be set up.

Rated voltage:	24VDC 8 to 32 VDC allowed / reverse polarity proof
Max Power	Consumption:9.34W
Protection class:	EN60529 IP65 frontside only, IP20 back side UL50 Front Type 4X indoor use only
Temperature:	-20 to 60°C
Dimensions:	W: 197mm / H: 140mm / D: 47.8mm 0.6kg
Approvals:	CE, Zone 22 II 3D Ex tc IIIC T70°C Dc, UL cULus E115267

### Attention:

	<p>If necessary, the TP-7B must be configured via integrated service page. This service page can be accessed in different ways.</p> <p>The service page can be accessed by pressing the hand button at the front of the front if it is configured as usual and not locked.</p> <p>The service page can also be used by pressing the right and left mouse buttons simultaneously for at least 2 seconds if a USB mouse is connected</p> <p>At least the "Network" and "VNC" input elements must be parameterized, The parameterization must be completed via "Save &amp; Exit".</p>
---	--





Dimensions of the cut-out for this Power Panel variant:  $186.8 \pm 1 \text{ mm} \times 129.8 \pm 1 \text{ mm}$



For the details regarding ATEX in particular as well as all other technical details, the specifications of the original operating manual of the manufacturer must be strictly followed!

Download unter: <https://download.br-automation.com/> (HMI – PowerPanels T30-Series)

## 2 Operating Mode / Single Scale - Variants

Each scale can currently work in 3 different operating modes.

These are:

1. Simple weight measurement (static balance)
2. Charging in weight containers (batch positive)
3. Charging from weighed storage container (batch negative)
4. General cargo scale (This option is planned for the near future)

The first scale always works with the group number 00, the next scales then have the group numbers 10,20,30... and so on.

This group number is very important in the visual representation as well as for the parameterization of the different scales.

The necessary measuring channels and I/O's can be plugged in centrally directly next to the CPU as well as distributed over several hundred meters.

In this case, additional bus transmitter / receiver modules must be purchased.

The length of the individual cable segments between the different wagons must not exceed 100 metres.

A KSW-7B CPU can simultaneously evaluate up to 5 (later 8) individual scales, provided that the necessary hardware is installed.

## 2.1 Simple actual weight measurement (static balance)

In this operating mode, the current weight in a container or silo is simply displayed.

The weight display is scalable in wide ranges of (g,kg,t,%, etc.)




A tare option via button or external IO's is included.

Limit values can be switched individually

The actual weight can be passed on to higher-level systems via analog IO's or fieldbus.

## 2.2 Charging in weight containers (batch positive)

This operating mode is used for dosing batches if the weighing container is always empty at the beginning of the batch. This is the classic type of batch filling.




The screenshot shows the HUKLA control interface for batch charging. The main display is divided into several sections:

- PAN**: The top left section, containing the title "PAN".
- Batch pos**: The main control area, divided into two sub-sections:
  - 01: Batch pos.**: Contains weight measurements for A (0g), B (0g), SBT (0g), Kor. (0g), BT (0g), LBT (0g), E (0.00% -0.09%), and BSV (0.00%). There is a "del" button next to the B weight measurement.
  - 00: Preparing batch**: Contains a "Start" button and a "Stop" button.
- Overview**: A vertical list on the right side of the interface, showing the status of various weight containers (WC 00, WC 10, WC 20, WC 30, WC 40, WC 50, WC 60, WC 70) and the "FB Status". The "PA" button at the bottom is highlighted in yellow.

1. The complete batch process is controlled by the KSW-7B.
2. A batch setpoint must be specified either analogously or by fieldbus.
3. A local (PANel) and a remote controlled (REMOte) operating mode are possible.
4. The process can be started or stopped via control signals (screen button, buttons, digital inputs or fieldbus command bits).
5. Various control signals (coarse current, fine current, many limit values, etc. are generated, which are also output again via physical outputs or fieldbus.
6. The coarse and fine current control can be realized via 2 digital signals or alternatively via an analog signal for speed control of a FU.
7. Two summing counters (A= non-resettable, B= resettable) are provided
8. The complete process is displayed in the overview screen and can also be controlled via it if permitted in the parameterization.

## 2.3 Charging from weighed storage container (batch negative)

This operating mode is used for dosing batches when the storage container is weighed, and the batch is delivered via a discharge organ (screw, rotary valve).



**PAN**

**Batch neg.**

**02: Batch neg.**

A: 0g

B: 0g

**SBT:** 0g

Kor.: 0g

**BT:** 0g

LBT: 0g

t: 0.00% -0.03%

**BSV:** 0.00%

Filling: ☐

☐ Max Max

☐ Max

☐ Min

☐ Min Min

☐ Empty

**Overview**

WC 00

WC 10

WC 20

WC 30

WC 40

WC 50

WC 60

WC 70

**FB Status**

**PA**

1. The complete batch process is controlled by the KSW-7B.
2. A batch setpoint must be specified either analogously or by fieldbus.
3. A local (PANel) and a remote controlled (REMOte) operating mode are possible.
4. The process can be started or stopped via control signals (on-screen buttons, digital inputs or fieldbus command bits).
5. Various control signals (coarse current, fine current, many limit values, etc. are generated, which are also output again via physical outputs or fieldbus.
6. 2 summing counters (A= non-resettable, B= resettable) are provided
7. The complete process is displayed in the overview screen and can also be controlled via it if permitted in the parameterization.

## 2.4 Multiple single scales in one KSW-7B

These designs may also be mixed within a KSW-7B. It is possible that the scale 00 works in the operating mode "Static" and at the same time the scale 01 works as a summing batch scale "Batch positive" and the third scale 02 as a subtracting batch scale.


hukla				Overview	
Static scale	Batch pos.	Batch neg.			
PAN	PAN	PAN		WC 00	
WC00: 0.40 %	SBT: 0 g	SBT: 0 g		WC 10	
WC00: 0.00 %	BT:	BT: 0 g		WC 20	
	BSV: 0.00 %	t: 0.00 %		WC 30	
		BSV: 0.00 %		WC 40	
	00: Preparing batch	05: Filling on		WC 50	
				WC 60	
				WC 70	
				FB Status	
				PA	

## 3 Mode – Board scale

In the application Board scale determined in the parameter P93000 we can connect several force transducers to a total balance.

This application is primarily intended for measuring the board weight in the gypsum industry.

However, applications in the field of wood fiber boards or insulation materials are also conceivable.



**Configuration Parameters:**


- P9300 Type of scale: 01: Boardscale
- P93100 Measuring points: 3
- P93101 WC per measuring point: 2
- P93105 Measuring distance: 2000 mm
- P93106 Board width: 01: Bus 1 ABS
- P93110 Start weighing: 00: Always active
- P93115 Settling time: 0.5 s
- P93116 Block filter: 00: All filter active
- P93120 Weighing time: 0.0 s

**Navigation Buttons (Right Side):** Overview, WC 00, WC 10, WC 20, WC 30, WC 40, WC 50, WC 60, WC 70, FB Status, PA

**System Component Buttons (Bottom):** P91xxx Scale data, P93xxx Type, P95xxx Analog I/O, P96xxx Digital I/O, P97xxx Field Bus

P93000 Type of scale	Uses the setting shown to determine the basic application as a Board scale
P93100 Measuring points	Here the number of measuring points in direction of feeding is entered.
P93101 WC per measuring point	This parameter determines the number of measuring points perpendicular to the conveying direction
P93105 Measuring distance	Determines the length of the measuring range in the direction of conveying in millimeters.
P93106 Board width:	Source of information on the working range of the systems
P93110 Start Weighing:	it can be selected whether the measurement is always active, only when a limit value is reached or when a Startbit is activated.
P93115 Settling time:	The actual measurement begins only after the expiry of the time of calming set here
P93116 Block filter	Of course, all weight signals are filtered by the electronics hardware and by software, with the help of this parameter individual filters can be deactivated.
P93120 Weighing time	This parameter determines the duration of the actual measurement. It must be chosen in such a way that the next Board does not reach the beginning of the measuring section before completion of the entire measurement.

Example of a representation of the process values



(internal / exchange image with real display values)




## 4 VNC Connection

If the KSW-7B base unit is not connected to its own operator panel, the virtual screen must be displayed via VNC client (e.g. a PC with a suitable VNC client). This device then serves as a virtual screen. A retrofit with a real terminal can be carried out at any time later because the actual data communication between terminal panel and PC is completely identical.

### 4.1 Network setting on the PC


The IP address under Internet Protocol version 4 (TCP/IPv4) must be set as follows:

IP Address:                   xxx.xxx.xxx.xxx                   (IP Adresse darf nicht wie KSW-7B sein!!)  
 Subnet mask:               xxx.xxx.xxx.xxx  
 Standardgateway:       not necessary  
 DNS-Server:               not necessary



## 4.2 Start VNC

After installing VNC Viewer, a new connection must be created.



Under VNC Server, the IP address 10.0.1.40 must be entered.  
The name is freely selectable.



Plug in the network cable here (IF2)

Only the lower interface may be used. The upper Ethernet interface is reserved for future use

The visualization of the KSW-7B is opened with a double click on the created connection.

## 5 General operation of the KSW-7B

### 5.1 Navigation for KSW-7B

On top of the real page of the overview image is the navigation bar. This remains unchanged on all sides. Above the navigation bar, the name of the current page is displayed in plain text. The button of the current page is always locked in the navigation bar, this can be recognized by the color change of the texts.

Static scale	Batch pos	Batch neg.	Overview	
PAN	PAN	PAN	<div>1</div>	WC 00
WC00: 0.40 %	SBT: 0 g	SBT: 0 g		WC 10
WC00: 0.00 %	BT:	BT: 0 g		WC 20
	BSV: 0.00 %	t: 0.00 %		WC 30
	00: Preparing batch	05: Filling on		WC 40
				WC 50
				WC 60
				WC 70
				FB Status <div>2</div>
				PA <div>3</div>

- 1 Button of the current page. Unconnected datapoints are white colored
- 2 Navigation button for fieldbus overview
- 3 Navigation keys to parameter mode

## 5.2 Overview

The overview screen can look very different depending on the parameterization of the system. Basically, the system distinguishes whether several independent scales are realized in a KSW-7B or whether a single scale with several measuring points has been parameterized.

Static scale			Batch pos		Batch neg.		Overview	
PAN			PAN		PAN		WC 00	
WC00:	0.40 %		SBT:	0 g	SBT:	0 g	WC 10	
WC00:	0.00 %		BT:		BT:	0 g	WC 20	
			BSV:	0.00 %	t:	0.00 %	WC 30	
					BSV:	0.00 %	WC 40	
			00: Preparing batch		05: Filling on		WC 50	
							WC 60	
							WC 70	
							FB Status	
							PA	

Example 1:

KSW-7B with 3 scales, each with different functionality

Example 2:

KSW-7B single scale configuration consisting of 3-6 measuring points.

Current total weight: 0g/m²				Last total weight: 0g/m²		Overview	
WC00: 0.00 t				WC20: 0.00 %		WC 00	
				WC40: NaN %		WC 10	
						WC 20	
						WC 30	
						WC 40	
						WC 50	
						WC 60	
						WC 70	
						FB Status	
						PA	

## 6 Parameterization

The parameterization is done via the "PA" button at the bottom right

Parameters are assigned to the following scales

P01xxx-09xxx	WC00	(first scale)
P11000-19999	WC10	(second scale)
P21000-29999	WC20	(third scale)
P31000-39999	WC30	(fourth scale)
P41000-49999	WC40	(fifth scale)


and so on.

The parameter group P9xxxx is intended for general cross-balance parameters.

### 6.1 Px1000 Scale Data - Parameters

This is where the general settings for a scale are made.

Example of programming a static weight measurement:



The screenshot shows the HUKLA parameterization interface. The main area contains the following parameters:

- P01010 Scale name: Static scale
- P01020 Type of Scale: 00: Static scale
- P01300 Display unit: 5: 0,01t
- P01305 Nominal weight: 0.10 t
- P01310 Counter unit: 05: 0,1t
- P01500 XD0: 2: STD drive
- P01501 XD1: 0: Not active
- P01502 XD2: 0: Not active
- P01503 XD3: 0: Not active

The bottom bar contains the following buttons:

- P01000 | Scale data
- P01600 | XD 1/2
- P01620 | XD 2/2
- P01xxx Scale data
- P02xxx Limits
- P04xxx Special functions
- P05xxx Analog I/O
- P06xxx Digital I/O
- PA

The sidebar on the right contains the following buttons:


- Overview
- WC 00
- WC 10
- WC 20
- WC 30
- WC 40
- WC 50
- WC 60
- WC 70
- FB Status

Px1010 Scale name:	Here the name of the scale must be entered as free text
Px1020 Type of Scale:	This parameter determines the function of the scale
Px1300 Display unit:	Here the unit of the display (g,kg,t,%) can be defined.
Px1305 Nominal weight	Defines the nominal range of the scale (100%).
Px1310 Counter unit:	Specifies in which counting unit the controller sums internally

## 6.2 Px1500 Auxiliary drives XD0 – XD3

The controller allows the control of the drives assigned to this to 4 in different operating modes. Depending on the selection in the x1500 group and the assigned x16xx parameters, the controller knows how to control the corresponding drive and when it must be switched on or off.

Px1500 XD0 Px1503 XD3	It is defined whether a main drive XD0: is connected and its functionality is determined. (e.B. slider)
--------------------------	---



The screenshot displays the HUKLA control interface with a yellow header. The main area is divided into four quadrants for configuring auxiliary drives XD0 and XD1 in REM (Remote) and PAN (Panel) modes. Each quadrant contains parameters for source, control option, and working/standby times. A right-hand sidebar provides navigation options like Overview, WC 00-70, FB Status, and PA. A bottom navigation bar includes tabs for Scale data, Limits, Special functions, Analog I/O, Digital I/O, and PA.

XD0 STD drive REM		XD0 STD drive PAN	
P01600 XD0 REM source:	01: Batch enable	P01605 XD0 PAN source:	00: ---
P01602 XD0 REM controlopt:	00: ---	P01607 XD0 PAN controlopt:	00: ---
P01603 XD0 REM Arbeitszeit:	0.0 s	P01608 XD0 PAN Arbeitszeit:	0.0 s
P01604 XD0 REM Pausenzeit:	0.0 s	P01609 XD0 PAN Pausenzeit:	0.0 s

XD1 REM		XD1 PAN	
P01610 XD1 REM source:	00: ---	P01615 XD1 PAN source:	00: ---
P01612 XD1 REM controlopt:	00: ---	P01617 XD1 PAN controlopt:	00: ---
P01613 XD1 REM Arbeitszeit:	0.0 s	P01618 XD1 PAN Arbeitszeit:	0.0 s
P01614 XD1 REM Pausenzeit:	0.0 s	P01619 XD1 PAN Pausenzeit:	0.0 s

Navigation bar: P01000 | Scale data | P01600 | XD 1/2 | P01620 | XD 2/2


Bottom tabs: P01xxx Scale data | P02xxx Limits | P04xxx Special functions | P05xxx Analog I/O | P06xxx Digital I/O | PA

Px16y0 XDy REM Source	Determines which signal primarily activates the drive in REMote mode
Px16y2 XDy REM Controloption	Determines whether and which signal is additionally necessary to activate the drive in the corresponding operating mode ( log. AND – Link )
Px16y3 XDy REM Acticetime	Sometimes it is necessary to start the actual drive a little delayed. This parameter delays the start-up according to the settime.
Px16y4 XDy REM delaytime	This parameter offers the possibility to artificially extend a signal. The signal remains active for longer for the set time even if the actual trigger is already inactive.

In Parameter group Px16y5 to Px16y9 the entire block is shown again for the operating type PANEL . Thus, the controller offers the possibility to optimally adapt the drive in each type of drive.

## 6.3 Px2000 Limits

Times and limits are set here.




Px2000 Max Max:	Threshold for MaxMax status of a batch in %
Px2001 Max:	Threshold for Max Status of a Batch in %
Px2002 Min:	Threshold for min status of a batch in %
Px2003 Min Min:	Threshold for MinMin status of a batch in %
Px2004 Empty	Threshold for empty status of the container in %
Px2005 Fill on:	Threshold for refilling for subtracting scales
Px2006 Fill off:	Threshold for end of refill for subtracting scales
Px2007 Settling time:	Waiting time before a new batch can be started after refilling with subtracting scales
Px2010 Tare time:	Determines the time of the tare of the scale
Px2011 Tare error limit:	Specifies how far the current tare may deviate from the originally defined zero point.
Px2015 Max batch deviation:	Defines when a batch is detected as faulty.



## 6.4 Px4000 Special functions

Here, special possibilities for special applications are parameterized.




Px4510 Batch setpoint:	Determines the source of the setpoint for a batch
Px4511 Batch scaling:	Defines the resolution of the scale.
Px4515 Fine switch over	Defines the residual quantity at which the material flow is reduced to ensure an accurate achievement of the batch weight.
Px4521 Pre-switch off min	Determines by how much the fine flow is stopped before reaching the target weight. Thus, a "dripping" can be compensated as far as it is basically the same for each batch.
Px4525 Ramp Min	Determines the percentage value to which the dosage towards the end of the batch is reduced for analog fine-flow dosing devices.
Px4535 Batch correction factor	Allows a dynamic automatic adjustment of the pre-switch quantity by a certain percentage value. This value should be set to a maximum of 30%.
Px4540 Settling time	Determines the time between reaching the batch weight and its actual final settlement.



## 6.5 Px5000 Analog I/O

In this group, the actual measuring channel is set.

To improve the setting option, the signal is permanently displayed dynamically.



Px5002 WC Nominal characteristic value	Here the constant of the force transducer is entered (e.B. 2mV/V)
Px5004 WC Offset	Defines the mV value at which the scale basically recognizes 0
Px5006 WC Span	Defines how many mV correspond to the nominal range (0 and 100%)
Px5007 Hardware Filter	Specifies how the signal on the force transducer measurement card itself is attenuated
Px5008 WC AI Filter	Specifies how the signal is attenuated by software

Using the "Set offset" and "Set span" buttons, the zero point and the area can be measured automatically.

The mV values shown may differ in the microvolt range from post-measurements with multimeters.

## 7 Fieldbus Communication

Optionally, a KSW-7B can be equipped with various fieldbus modules.



Device with ProfibusDP - Modul (left side)



Device with ProfiNet module or EthernetIP

EthernetIP is already available, DeviceNet would be possible on request.

## 7.1FB Status


It is possible to control the data transfer of the fieldbus interface under "FB status".

FB OUT			FB IN			Overview
DW 00:	49	01: WC00 Pr	DW 00	0x00000000	01: WC00 CMD	WC 00
DW 04	0	10: WC00 Abs	DW 04	0x00000000	02: WC10 CMD	WC 10
DW 08	0x00000000	19: WC00 StatusBits 1	DW 08	0x00000000	03: WC20 CMD	WC 20
DW 12	-8	02: WC10 Pr	DW 12	0	00: ---	WC 30
DW 16	0	11: WC10 Abs	DW 16	0	00: ---	WC 40
DW 20	0x00000000	20: WC10 StatusBits 1	DW 20	0	00: ---	WC 50
DW 24	-2	03: WC20 Pr	DW 24	0	00: ---	WC 60
DW 28	0	11: WC10 Abs	DW 28	0	00: ---	WC 70
DW 32	0x00000000	21: WC20 StatusBits 1				FB Status
DW 36	0	00: ---				
DW 40	0	00: ---				
DW 44	0	00: ---				
DW 48	0	00: ---				
DW 52	0	00: ---				
DW 56	0	00: ---				
DW 60	0	00: ---				PA

- 1 Data sent by the KSW-7B. The parameterization of the data fields is described in point 7.4
- 2 Data sent to KSW-7B. The parameterization of the data fields is described in point 7.3


## 7.2 ProfibusDP - General

The scale computers of the KSW-7B series can be equipped with a Profibus DP interface. This interface must be specified when ordering. Subsequent installation is also possible in consultation with the manufacturer. The interface is licensed by the manufacturer KUKLA and complies with the Profibus standard 50170. In addition to many other communication solutions, a DP V1 or a ProfiNet interface can also be implemented as an option.



## 7.3 ProfibusDP data transfer rate / plug assignment

The interface supports the common standardized data transfer rates up to 12 MBit. At higher transmission speeds, it is essential to use approved plugs.


Schnittstelle	Anschlussbelegung	
 <p>9-polige DSUB-Buchse</p>	Pin	RS485
	1	Reserviert
	2	Reserviert
	3	RxD/TxD-P
	4	CNTR-P
	5	DGND
	6	VP
	7	Reserviert
	8	RxD/TxD-N
		CNTR-N
		Transmit Enable\

CNTR ... Richtungsumschaltung für externe Repeater

The use of standardized Profibus DP connectors is recommended. The cable ends must be terminated with terminating resistors.

## 7.4 ProfibusDP – Node Address

The station address is set directly in the parameter group P97xxx.



The parameter P97010 is relevant. Addresses between 3 and 125 may be set.

The parameter P97020 swap allows a change of the address where the lowest byte is stored. (see Endianess)



If the number 126 is set, all associated fieldbus parameters of the group P97xxx become inactive and cannot be used.



**AFTER CHANGING THE FIELDBUS-ADDRESS, THE SCALE COMPUTER MUST BE REMOVED FROM THE VOLTAGE FOR ABOUT 5 SECONDS SO THAT THE NEW ADDRESS IS ALSO TAKEN OVER!**

## 7.5 ProfiNet – IP-Adresse

Die Stationsadresse muss über ein geeignetes Setup-Tool vom Master eingestellt werden.

## 7.6 ProfibusDP - LED Statusmeldungen

Figure	LED	Color	Status	Description
	STATUS	Green	On	Interface module active
		Red	On	CPU starting up
	RxD	Yellow	On	The module receives data via the PROFIBUS DP slave interface
	TxD	Yellow	On	The module sends data via the PROFIBUS DP slave interface

## 7.7 Data structure / consistence

Please, find details concerning Data structure in the general part of section "General data structure "

## 7.8 ProfibusDP - GSD-Datei

The necessary device master data is stored on the homepage [www.kukla.co.at](http://www.kukla.co.at) in the download area or can be obtained directly from the manufacturer. Data formats other than those described in this documentation are not possible.

## 7.9 ProfiNet - GSDML-Datei

The necessary device master data is stored on the homepage [www.kukla.co.at](http://www.kukla.co.at) in the download area or can be obtained directly from the manufacturer. Data formats other than those described in this documentation are not possible.

## 7.10 DeviceNet - EDS-Datei

The necessary device master data is in preparation.

## 7.11 EthernetIP - EDS-Datei

The necessary device master data must be assembled manually.  
A ready-made EDS is currently not planned.  
However, the same data structure applies as in the other bus systems.

## 8 General data structure

In general, 8 double words must always be transmitted by the higher-level controller as target data.

Since the scale computer can usually collect a lot of different data, 16 duplicate words are always reported back to the higher-level system. Each process data double word can be individually assigned to which value is sent exactly on this field via the corresponding parameter number.

### 8.1 Setpoint and process data fields

	PLC > KSW - 7	KSW - 7 > PLC
00 Double word	BusIn DW00 (P97200)	BusOut DW00 (P97400)
01 Double word	BusIn DW04 (P97201)	BusOut DW04 (P97401)
02 Double word	BusIn DW08 (P97202)	BusOut DW08 (P97402)
03 Double word	BusIn DW12 (P97203)	BusOut DW12 (P97403)
04 Double word	BusIn DW16 (P97204)	BusOut DW16 (P97404)
05 Double word	BusIn DW20 (P97205)	BusOut DW20 (P97405)
06 Double word	BusIn DW24 (P97206)	BusOut DW24 (P97406)
07 Double word	BusIn DW28 (P97207)	BusOut DW28 (P97407)
08 Double word		BusOut DW32 (P97408)
09 Double word		BusOut DW36 (P97409)
10 double word		BusOut DW40 (P97500)
11 Double word		BusOut DW44 (P97501)
12 Double word		BusOut DW48 (P97502)
13 Double word		BusOut DW52 (P97503)
14 Double word		BusOut DW56 (P97504)
15 double word		BusOut DW60 (P97505)

Percentages are usually transmitted as values with 1/100 percent resolution (e.B. 74.83 % corresponds to the numerical value 7483).

P97500 DW00 format:

Alternatively, output in floating-point format is also possible for all numerical values. The settings for this are made in the parameter group P973xx and P975xx.


P97500 DW00 format:



## 8.2 Recommended data structure (for standard applications only)

(For details see the following chapters)

00 Double word	01: WC00 CMD	28: WC00 Control Bits 1
01 Double word	10: Bus 1 ABS	10: WC00 ABS
02 Double word	02: WC10 CMD	55: WC00 Istcharge
03 Double word	11: Bus 2 ABS	37: WC00 Dosing setpoint
04 Double word	03: WC20 CMD	46: WC00 Batch Step
05 Double word	12: Bus 3 ABS	29: WC10 Control Bits 1
06 Double word	00: ---	11: WC10 ABS
07 Double word	00: ---	56: WC10 Istcharge
08 Double word		38: WC10 dosing setpoint
09 Double word		47: WC10 batch step
10 double word		30: WC20 Control Bits 1
11 Double word		12: WC20 ABS
12 Double word		57: WC20 Istcharge
13 Double word		39: WC20 dosing setpoint
14 Double word		48: WC20 batch step
15 Double word		00: ---




Parameter	Value	Format
P97200 BusIn DW00:	10: Bus 1 ABS	0: INTEGER
P97201 BusIn DW04:	02: WC10 CMD	0: INTEGER
P97202 BusIn DW08:	03: WC20 CMD	0: INTEGER
P97203 BusIn DW12:	04: WC30 CMD	0: INTEGER
P97204 BusIn DW16:	505: Mailbox- number 1	0: INTEGER
P97205 BusIn DW20:	510: Mailbox- value 0	0: INTEGER
P97206 BusIn DW24:	500: Scaleindex 0	0: INTEGER
P97207 BusIn DW28:	1010: Glob CMD	0: INTEGER
P97300 DW00 format:	0: INTEGER	
P97301 DW04 format:	0: INTEGER	
P97302 DW08 format:	0: INTEGER	
P97303 DW12 format:	0: INTEGER	
P97304 DW16 format:	0: INTEGER	
P97305 DW20 format:	0: INTEGER	
P97306 DW24 format:	0: INTEGER	
P97307 DW28 format:	0: INTEGER	

Navigation: Overview, WC 00, WC 10, WC 20, WC 30, WC 40, WC 50, WC 60, WC 70, FB Status, PA

Buttons: P97000 | FB, P97200 | FB IN, P97400 | FB Out, P97408 | FB Out, P91xxx Scale data, P93xxx Type, P95xxx Analog I/O, P96xxx Digital I/O, P97xxx Field Bus

Here is the example of an alternative parameterization of the input range via the parameter group P9720x.





Parameter	Value	Format
P97400 BusOut DW00:	01: WC00 Pr	1: REAL
P97401 BusOut DW04:	02: WC10 Pr	1: REAL
P97402 BusOut DW08:	03: WC20 Pr	0: INTEGER
P97403 BusOut DW12:	04: WC30 Pr	0: INTEGER
P97404 BusOut DW16:	05: WC40 Pr	0: INTEGER
P97405 BusOut DW20:	500: ScaleIndex 0	0: INTEGER
P97406 BusOut DW24:	505: Mailbox- number	0: INTEGER
P97407 BusOut DW28:	510: Mailbox- value 0	0: INTEGER

Navigation buttons: P97000 | FB, P97200 | FB IN, P97400 | FB Out, P97408 | FB Out

Category buttons: P91xxx Scale data, P93xxx Type, P95xxx Analog I/O, P96xxx Digital I/O, P97xxx Field Bus

Right sidebar: Overview, WC 00, WC 10, WC 20, WC 30, WC 40, WC 50, WC 60, WC 70, FB Status, PA

The output data fields in the direction of the higher-level controller are also freely adjustable under the parameter group P940xx.

## 8.3 Control and status bits (byte order / endianness)




Byte order (*byte order* or *endianness*) denotes the storage organization for INT and DINT value. This is especially important when evaluating control bits!

Bit fields (status and control keywords) are usually transmitted as double words by the KSW-7B base device. The first bit (00 xxxxx) is usually located on the lowest byte address (0.0-0.7, 1.0-1.7, 2.0-2.7, 3.0-3.7) for AB controllers. For Siemens-S7 controllers, the first bit starts at the highest quality address (3.0-3.7, 2.0-2.7, 1.0-1.7, 0.0-0.7)

## 9 PARAMETER DESCRIPTION

### 9.1 General parameter up to 9xxxx



Parameter numbers of the group P9xxxx are used for general parameterization of the balance.

P91070	Language	INT
Selection:	00: English 01: German	Range: 0-1
Description:	this parameter determines the language of the visualization	

P91000	Serial number	DINT
Selection:		Range: 0-2147483647
Description:	This parameter determines the manufacturing number of the balance	

P91100	IP address	
Selection:	0.0.0.0	Range: 0.0.0.0 – 255.255.255.255
Description:	this parameter determines the ip address of the if2 interface	
Hint:	<b>The IP address in the default is 10.0.1.40</b> <b>The default IP address is set as soon as the KSW7 is restarted without a plugged card!!</b>	
Dependence:		

P91101	Subnet Mask	
Selection:	0.0.0.0	Range: 0.0.0.0 – 255.255.255.255
Description:	this parameter determines the subnet mask of the if2 interface	
Hint:	<b>The IP address in the default is 255.255.0.0</b> <b>The default subnet mask is set as soon as the KSW-7B is restarted without a plugged card!!</b>	

## 9.2 Change the IP address

1. Enter the desired IP parameters in the respective fields
2. Press the "Set IP Parameters" button
3. Confirm the specified parameters in the confirmation window
4. If the IP parameters are successfully converted, the VLC viewer will lose the connection

The screenshot shows the HUKLA configuration interface. At the top, there are fields for 'P91000 Fabricationnumber' (1500) and 'P91070 Language' (00: English). Below these is 'P91060 Parameterpassword' (0). The main section contains IP settings for 'P91100 IP address' (0.0.0.0) and 'P91101 Subnet Mask' (0.0.0.0), both highlighted with a red circle 1. To the right, 'IF2 IP' (10.0.1.40) and 'IF2 Subnet' (255.255.0.0) are shown, with the 'IF2 IP' field highlighted by a red circle 2. A 'Set IP parameter' button is highlighted with a red circle 3. Below the button, the status 'Status: FUB rdy' is highlighted with a red circle 4. The interface also includes a 'Date Time Parameterlist' section with HH:MM:SS (09:10:45) and yy/mm/dd (2022:07:30) fields, a 'Save parameter' button, and a 'Load parameter' button. At the bottom, there are tabs for 'P91xxx Scale data', 'P93xxx Type', 'P95xxx Analog I/O', 'P96xxx Digital I/O', and 'P97xxx Field Bus'. A sidebar on the right contains buttons for 'Overview', 'WC 00', 'WC 10', 'WC 20', 'WC 30', 'WC 40', 'WC 50', 'WC 60', 'WC 70', 'FB Status', and 'PA'.

- 1 IP parameters to be set for the IF2 interface of the KSW-7B
- 2 Current ip parameters of the IF2 interface
- 3 Button to set the IP parameters
- 4 Status of the function module for the IF2 configuration
- 5 Confirmation window of the IP parameters

The screenshot shows the HUKLA configuration interface with a confirmation window titled 'Set network:'. The window displays 'IP: 10.0.1.40' and 'SubNetz: 255.255.0.0'. Below the fields are 'OK' and 'Cancel' buttons. A red circle 5 points to the 'Set network' dialog box. The background interface is the same as the previous screenshot, showing the configuration fields and sidebar.

### Reset ip parameters to default

1. Taking the weighing electronics off the current
2. Pull all modules, except the supply module,
3. Start up the weighing electronics until all LEDs are green
4. Remove from the Net again
5. Plug all modules back into the electronics
6. After this ramp-up of the electronics, the IF2 interface will be accessible with the default values  
IP: 10.0.1.40  
SubNet: 255.255.0.0

## 9.3 Set time and date

The current time is important for the creation of the parameter expression because the file name is formed from the manufacturing number and the current time information.


Date Time Parameterlist			
HH:MM:SS	09	12	43
yy/mm/dd	2022	07	30

## 9.4 Create parameter list / USB or FTP

All currently set parameters are stored in the parameter list. This parameter list can either be created on a USB stick that is plugged DIRECTLY INTO THE CPU. Alternatively, it can also be stored in the internal file system and downloaded from there via FTP protocol.

The parameter list is a CSV.

The name of this file is composed of the manufacturing number of the language and the current date and time.



### To create the parameter list:


1. Check time and date
2. Press key 1 "Create parameter list" to create the parameter expression in the main directory of the plugged in USB memory
3. Alternatively, press key 2 to create the parameter expression in the main directory of the internal file system
4. During the creation of the parameter list, this button is locked
5. When RDY is displayed again in the progress bar, the process is finished

## 9.5 General Fieldbus parameters 97xxx

The parameter group **"Fieldbus"** allows the setting and Change of communication possibilities to a central control.

P9710	Fieldbus address:	INT
	Selection: Profibus 1..124	Tomboy: 1-125
Description:	This parameter determines the Profibus address.	
Hint:	126 / Neutral address	
Branch:		

## 9.6 Setpoints and Commands via Fieldbus (P972x)



This example shows the command words for 3 cars. Data communication takes place via integers in the format double integer (4byte).

P9720x P9727x	– Bus IN DW0 – DW28:	INT
	Selection: 00: ----- 01: WC0 CMD 02: WC1 CMD 03: WC2 CMD 04: WC3 CMD 05: WC4 CMD 06: WC5 CMD 07: WC6 CMD 08: WC7 CMD 09: --- 10: Bus 1 ABS 11: Bus 2 ABS	Range: 0-8

12: Bus 3 ABS  
 13: Bus 4 ABS  
 14: Bus 5 ABS  
 15: Bus 6 ABS  
 16: Bus 7 ABS  
 17: Bus 8 ABS  
 18: ---  
 19: BUS 1 [%]  
 20: BUS 2 [%]  
 21: BUS 3 [%]  
 22: BUS 4 [%]  
 23: BUS 5 [%]  
 24: BUS 6 [%]  
 25: BUS 7 [%]  
 26: BUS 8 [%]  
 27: ---  
 18: Scale index 0  
 29: Scale index 1  
 30: Scale index 2  
 31: Scale index 3  
 32: ---  
 33: Mailbox number 0  
 34: Mailbox number 1  
 35: Mailbox number 2  
 36: Mailbox number 3  
 37: ---  
 38: Mailbox value 0  
 39: Mailbox value 1  
 40: Mailbox value 2  
 41: Mailbox value 3

Description:	This parameter determines how the first input setpoint double word DW0- DW28 of the fieldbus setpoint range is used.
Hint:	Details about the function can be found in the previous chapters.

## 9.7 Actual values and control/status bits via fieldbus (P974xx)

WC0-7 CMD	<i>Digital control commands to the scale computer</i>	
	Hex	Description
	0x00000001	00: ---
	0x00000002	01: Set zero point <0> START
	0x00000004	02: Start buoyancation
	0x00000008	03: Reset counter B
	0x00000010	04: Max Max
	0x00000020	05: Max
	0x00000040	06: Min
	0x00000080	07: Min Min
	0x00000100	08: Empty
	0x00000200	09: Start batch
	0x00000400	10: Interrupt batch
	0x00000800	11: Batch Cancellation
	0x00001000	12: Fine flow
	0x00002000	13: Empty the system
	0x00004000	14: ---
	0x00008000	15: REM
	0x00010000	16: Drive lock
	0x00020000	17: Emergency stop active
	0x00040000	18: Message running
	0x00080000	19: Jog
	0x00100000	20: Opto 0
	0x00200000	21: Opto 1
	0x00400000	22: Opto 2
	0x00800000	23: Opto 3
	0x01000000	24: Opto 4
	0x02000000	25: Engine malfunction
	0x04000000	26: ---
	0x08000000	27: ---
	0x10000000	28: ---
	0x20000000	29: ---
	0x40000000	30: ---
	0x80000000	31: ---





Again, the communication with 3 scales is provided. As a data format, the Floating-point format Real selected. (z.B. P097500, P97501..)

Pure bit fields, on the other hand, must be displayed in the double-integer data format. (z.B. P97402)

P740 - P755 BusIs DW0:		INT or REAL
Selection:	00: -----	Range:
	01: WC00 Pr	
	02: WC10 Pr	
	03: WC20 Pr	
	04: WC30 Pr	
	05: WC40 Pr	
	06: WC50 Pr	
	07: WC60 Pr	
	08: WC70 Pr	
	09: ---	
	10: WC00 Abs	
	11: WC10 Abs	
	12: WC20 Abs	
	13: WC30 Abs	
	14: WC40 Abs	
	15: WC50 Abs	
	16: WC60 Abs	
	17: WC70 Abs	
	18: ---	
	19: WC00 Status	
	20: WC10 Status	
	21: WC20 Status	
	22: WC30 Status	
	23: WC40 Status	
	24: WC50 Status	
	25: WC60 Status	
	26: WC70 Status	
	27: ---	
	28: WC00 Control Bits1	
	29: WC10 ControlBits1	

30: WC20 ControlBits1  
 31: WC30 ControlBits1  
 32: WC40 ControlBits1  
 33: WC50 Control Bits1  
 34: WC60 Control Bits1  
 35: WC70 ControlBits1  
 36: ---  
 37: WC00 batch setpoint  
 38: WC10 batch setpoint  
 39: WC20 batch setpoint  
 40: WC30 batch setpoint  
 41: WC40 batch setpoint  
 42: WC50 batch setpoint  
 43: WC60 batch setpoint  
 44: WC70 batch setpoint  
 45: ---  
 46: WC00 batch step  
 47: WC10 batch step  
 48: WC20 batch step  
 49: WC30 batch step  
 50: WC40 batch step  
 51: WC50 batch step  
 52: WC60 batch step  
 53: WC70 batch step  
 54: ---  
 55: WC 00 Istcharge  
 56: WC 10 Istcharge  
 57: WC 20 Istcharge  
 58: WC 30 Istcharge  
 59: WC 40 Istcharge  
 60: WC 50 Istcharge  
 61: WC 60 Istcharge  
 62: WC 70 Istcharge  
 63: ---  
 64: Scale index 0  
 65: Scale index 1  
 66: Scale index 2  
 67: Balance index 3  
 68: ---  
 69: Mailbox – Number 0  
 70: Mailbox – Number 1  
 71: Mailbox – Number 2  
 72: Mailbox – Number 3  
 73: ---  
 74: Mailbox – Value 0  
 75: Mailbox – Value 1  
 76: Mailbox – Value 2  
 77: Mailbox – Value 3  
 1000: AI00  
 1001: AI01  
 1010: Global Control Bits


Description:	This parameter determines which value is transmitted to a central controller via the first actual value double word DW00 – DW36 of the fieldbus output area.
Hint:	The type of output is defined under P840 – 855 (0 Integer   1 REAL)

<b>WC0-7 SteuerBits1</b>	<i>Digitale Steuerkommandos an den Waagencomputer</i>																																																																
	<table> <tr><td>0x00000001</td><td>00: ---</td></tr> <tr><td>0x00000002</td><td>01: Charge Start</td></tr> <tr><td>0x00000004</td><td>02: Batch of coarse current</td></tr> <tr><td>0x00000008</td><td>03: Batch fine flow</td></tr> <tr><td>0x00000010</td><td>04: Fill in</td></tr> <tr><td>0x00000020</td><td>05: Empty</td></tr> <tr><td>0x00000040</td><td>06: Min Min</td></tr> <tr><td>0x00000080</td><td>07: Min</td></tr> <tr><td>0x00000100</td><td>08: Max</td></tr> <tr><td>0x00000200</td><td>09: Max Max</td></tr> <tr><td>0x00000400</td><td>10: Quantity error</td></tr> <tr><td>0x00000800</td><td>11: ---</td></tr> <tr><td>0x00001000</td><td>12: ---</td></tr> <tr><td>0x00002000</td><td>13: ---</td></tr> <tr><td>0x00004000</td><td>14: Material release</td></tr> <tr><td>0x00008000</td><td>15: Rem active</td></tr> <tr><td>0x00010000</td><td>16: Drive lock active</td></tr> <tr><td>0x00020000</td><td>17: Emergency stop active</td></tr> <tr><td>0x00040000</td><td>18: System running</td></tr> <tr><td>0x00080000</td><td>19: Jog Maindrive active</td></tr> <tr><td>0x00100000</td><td>20: Relay 0</td></tr> <tr><td>0x00200000</td><td>21: Relay 1</td></tr> <tr><td>0x00400000</td><td>22: Relay 2</td></tr> <tr><td>0x00800000</td><td>23: Relay 3</td></tr> <tr><td>0x01000000</td><td>24: Warning</td></tr> <tr><td>0x02000000</td><td>25: Ready for operation</td></tr> <tr><td>0x04000000</td><td>26: XD0</td></tr> <tr><td>0x08000000</td><td>27: XD1</td></tr> <tr><td>0x10000000</td><td>28: XD2</td></tr> <tr><td>0x20000000</td><td>29: XD3</td></tr> <tr><td>0x40000000</td><td>30: ---</td></tr> <tr><td>0x80000000</td><td>31: Relay 4</td></tr> </table>	0x00000001	00: ---	0x00000002	01: Charge Start	0x00000004	02: Batch of coarse current	0x00000008	03: Batch fine flow	0x00000010	04: Fill in	0x00000020	05: Empty	0x00000040	06: Min Min	0x00000080	07: Min	0x00000100	08: Max	0x00000200	09: Max Max	0x00000400	10: Quantity error	0x00000800	11: ---	0x00001000	12: ---	0x00002000	13: ---	0x00004000	14: Material release	0x00008000	15: Rem active	0x00010000	16: Drive lock active	0x00020000	17: Emergency stop active	0x00040000	18: System running	0x00080000	19: Jog Maindrive active	0x00100000	20: Relay 0	0x00200000	21: Relay 1	0x00400000	22: Relay 2	0x00800000	23: Relay 3	0x01000000	24: Warning	0x02000000	25: Ready for operation	0x04000000	26: XD0	0x08000000	27: XD1	0x10000000	28: XD2	0x20000000	29: XD3	0x40000000	30: ---	0x80000000	31: Relay 4
0x00000001	00: ---																																																																
0x00000002	01: Charge Start																																																																
0x00000004	02: Batch of coarse current																																																																
0x00000008	03: Batch fine flow																																																																
0x00000010	04: Fill in																																																																
0x00000020	05: Empty																																																																
0x00000040	06: Min Min																																																																
0x00000080	07: Min																																																																
0x00000100	08: Max																																																																
0x00000200	09: Max Max																																																																
0x00000400	10: Quantity error																																																																
0x00000800	11: ---																																																																
0x00001000	12: ---																																																																
0x00002000	13: ---																																																																
0x00004000	14: Material release																																																																
0x00008000	15: Rem active																																																																
0x00010000	16: Drive lock active																																																																
0x00020000	17: Emergency stop active																																																																
0x00040000	18: System running																																																																
0x00080000	19: Jog Maindrive active																																																																
0x00100000	20: Relay 0																																																																
0x00200000	21: Relay 1																																																																
0x00400000	22: Relay 2																																																																
0x00800000	23: Relay 3																																																																
0x01000000	24: Warning																																																																
0x02000000	25: Ready for operation																																																																
0x04000000	26: XD0																																																																
0x08000000	27: XD1																																																																
0x10000000	28: XD2																																																																
0x20000000	29: XD3																																																																
0x40000000	30: ---																																																																
0x80000000	31: Relay 4																																																																

## 10 Communication with S7 controllers (Profibus / ProfiNetIO)

In the hardware configuration, care must be taken to ensure the correct assignment of the individual double words.

This example also applies functionally to all other bus systems. The byte order, i.e. whether the lowest byte of a double word is stored on the lowest or highest address, is particularly important to consider. (see Endianness / P97020\_Swap)



Steckplatz	DP-Kennung	Bestellnummer / Bezeichnung	E-Adresse	A-Adresse	Kommentar
1	225	2 Words Out	256..259		
2	225	2 Words Out	260..263		
3	225	2 Words Out	264..267		
4	225	2 Words Out	268..271		
5	225	2 Words Out	272..275		
6	225	2 Words Out	276..279		
7	225	2 Words Out	280..283		
8	225	2 Words Out	284..287		
9	209	2 Words In	256..259		
10	209	2 Words In	260..263		
11	209	2 Words In	264..267		
12	209	2 Words In	268..271		
13	209	2 Words In	272..275		
14	209	2 Words In	276..279		
15	209	2 Words In	280..283		
16	209	2 Words In	284..287		
17	209	2 Words In	288..291		
18	209	2 Words In	292..295		
19	209	2 Words In	296..299		
20	209	2 Words In	300..303		
21	209	2 Words In	304..307		
22	209	2 Words In	308..311		
23	209	2 Words In	312..315		
24	209	2 Words In	316..319		

Example HW Config S7 Classic

---

Notes: