

Freescale MQX RTOS Example Guide

HVAC_ERROR demo example

HVAC_ERROR demo is similar to web_hvac demo example excluding the following points.

- hvac_error demo uses switch_task and logging_task while web_hvac does not enable these two tasks.
- hvac_error demo uses ftp_server whereas web_hvac uses web_server.
- web_hvac demo uses usb host functionalities but the hvac_error demo does not.

Other than those differences the logic flow of hvac_error demo example is exactly similar to the logic flow of web_hvac demo example.

The _README.doc document for web_hvac demo already covers every aspect related to hvac_error demo example. It is therefore redundant to write a new guide document for hvac_error demo example. The user should consult _README.doc file of web_hvac demo example excluding sections about USB and WEB server functions.