

## **Freescale MQX RTOS Example Guide**

### **HVAC demo example**

HVAC demo is similar to web\_hvac demo example except that the web\_hvac demo example has the additional demonstration of USB and WEB server functionality. The fact is that all source files of hvac demo example are included in the web\_hvac example. Though the macros DEMOCFG\_ENABLE\_USB\_FILESYSTEM, DEMOCFG\_ENABLE\_RTCS are set to zero in file HVAC.h of hvac demo example which disables the functionalities related to USB and WEB server.

For the description of hvac demo example, user should refer to the README document of the web\_hvac demo example excluding sections related to USB and WEB server.