

DTC	C1223 / 43	ABS Control System Malfunction
------------	-------------------	---------------------------------------

CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
C1223 / 43	ABS control system is abnormal.	ABS control system

INSPECTION PROCEDURE

1	Check the DTC for the ABS (See page DI-185).
----------	---

¹*Repair ABS control system according to the code output.*****²****Check for ECU connected to malfunction indicator light.*****¹**: Output NG code***²**: Malfunction indicator light remains ON