


REASSEMBLY

NOTICE:

When using a vise, do not over tighten it.

1. **COAT WITH MOLYBDENUM DISULFIDE LITHIUM BASE GREASE**
(See page SR-27)



2. **INSTALL MAIN SHAFT ASSEMBLY**

- (a) Install the bearing thrust collar and compression spring to the main shaft assembly.
- (b) Install the main shaft assembly to the column upper tube sub-assembly.
- (c) Using SST, compress the compression spring.
SST 09950 -40011 (09958-04010)

NOTICE:

Do not bend the universal joint of the shaft more than 20°.

- (d) Using a snap ring expander, install a new snap ring to the shaft.

3. **INSTALL COLUMN UPPERTUBE SUB –ASSEMBLY WITH MAIN SHAFT ASSEMBLY**

- (a) Install the 3 bushings to the break away bracket.
- (b) Install 2 new support stopper bolt bushings to the column upper tube assembly.
- (c) Install the column upper tube assembly to the break away bracket.
- (d) Install the column upper tube sub –assembly with the main shaft assembly to the break away bracket.
- (e) Using a hexagon wrench, install the 2 tilt steering bolts.
Torque: 20 N·m (2 10 kgf·cm, 15 ft·lbf)
- (f) Install a new snap ring.

4. **INSTALL TELESCOPIC STEERING SCREW**

- (a) Install the 4 energy absorber cushions, 2 bearings and telescopic steering screw.
- (b) Install the nut.
Torque: 0.8 N·m (8.2 kgf·cm, 7. 1 in.·lbf)
- (c) Using a punch, stake the nut.

5. **INSTALL STEERING COLUMN BRACKET SPACER**


6. **INSTALL TELESCOPIC STEERING SLIDER**

7. **INSTALL TELESCOPIC STEERING BUSHING**

8. **INSTALL TELESCOPIC STEERING SLIDER SUPPORT**

Install the telescopic steering slider support with the 2 bolts.

Torque: 11 N·m (110 kgf·cm, 8 ft·lbf)




9. INSTALL 2 ENERGY ABSORBING GUIDES, PLATES AND CLIPS

- Install 2 new energy absorbing guides and new absorbing plates.
- Install 2 new energy absorbing clips.

10. INSTALL COLUMN TUBE SUPPORT

- Install the tube attachment to the tube support.
- Install the column tube support with the bolt.

Torque: 15 N·m (150 kgf·cm, 11 ft·lbf)



11. INSTALL COLUMN UPPER BRACKET AND COLUMN UPPER CLAMP

- Install the 2 telescopic steering wedge lock springs and 2 steering lock wedges.
- Using a hexagon wrench, install the 2 telescopic lever lock bolts.

Torque: 10 N·m (100 kgf·cm, 7 ft·lbf)

- Install and tighten the 2 new tapered –head bolts until the bolt heads break off.
- Install the column tube stopper.

Torque: 19 N·m (190 kgf·cm, 14 ft·lbf)

12. INSTALL POWER TELESCOPIC MOTOR

- Install the telescopic steering column cable.
- Install the power telescopic motor with the 2 bolts.

13. INSTALL ADJUSTING NUT NO. 1

- Install 2 new support stopper bolt bushings.
- Install the adjusting nut No. 1 to the power tilt motor.
- Install the 2 tilt steering shafts.

14. INSTALL POWER TILT MOTOR

- Install 2 new support stopper bolt bushings to the power tilt motor.
 - Install 2 new E –rings.
 - Using a hexagon wrench, install the 2 tilt steering bolts.
- Torque: 20 N·m (200 kgf·cm, 15 ft·lbf)**
- Install the stopper No. 1 and stopper spring.
 - Using a hexagon wrench, install the support stopper bolt.

15. INSTALL TURN SIGNAL BRACKET

Install the turn signal bracket with the 3 bolts.

16. INSTALL STEERING COLUMN PROTECTOR NO. 1

Install the steering column protector No. 1 with the bolt.

Torque: 15 N·m (153 kgf·cm, 11 ft·lbf)

17. INSTALL CONNECTOR BRACKET

Install the connector bracket with the bolt.

18. INSTALL KEY CYLINDER LAMP ASSEMBLY AND TRANSPONDER KEY COIL

- Install the transponder key coil with the key cylinder lamp assembly to the column upper bracket.
- Install the screw.

19. INSTALL NO. 2 LOWER COVER

20. INSTALL INTERMEDIATE SHAFT ASSEMBLY

- (a) Install the thrust stopper.
- (b) Align the matchmarks on the intermediate shaft assembly and main shaft assembly.
- (c) Install the bolt.

Torque: 34 N·m (350 kgf·cm, 25 ft·lbf)

21. INSTALL NO. 2 LOWER COVER

Install the No. 2 lower cover with the 2 nuts.

Torque: 24.5 N·m (240 kgf·cm, 17 ft·lbf)