


## REMOVAL

### 1. REMOVE REAR WHEEL

Torque:

Steel wheel: 209 N·m (2, 131 kgf·cm, 154 ft·lbf)

Aluminum wheel: 131 N·m ( 1,340 kgf·cm, 97 ft·lbf)




### 2. DISCONNECT BRAKE LINE

#### (a) DRUM BRAKE:

Using SST, disconnect the brake line.

SST 09023 -00100

Torque: 15 N·m ( 155 kgf·cm, 11 ft·lbf)



#### (b) DISC BRAKE:


Using SST, disconnect the brake line and remove the clip.

SST 09023 -00100

Torque: 15 N·m ( 155 kgf·cm, 11 ft·lbf)

### 3. DRUM BRAKE:

REMOVE DRUM




### 4. DISC BRAKE:

REMOVE BRAKE CALIPER AND DISC

Remove the 2 bolts, brake caliper and disc.

Torque: 103 N·m ( 1,050 kgf·cm, 76 ft·lbf)



### 5. CHECK BEARING BACKLASH AND AXLE SHAFT DEVIATION

#### (a) Using a dial indicator, check the backlash in the bearing shaft direction.

**Maximum: 0.6 mm (0.024 in.)**


If the backlash exceeds the maximum, replace the bearing.

#### (b) Using a dial indicator, check the deviation at the surface of the axle shaft outside the hub bolt.

**Maximum: 0.05 mm (0.0020 in.)**

If the deviation exceeds the maximum, replace the axle shaft.

6. **DRUM BRAKE:**  
**REMOVE REAR BRAKE ASSEMBLY**  
(See page BR-44)
7. **DISC BRAKE:**  
**REMOVE PARKING BRAKE ASSEMBLY**  
(See page BR-57)



8. **REMOVE AXLE SHAFT ASSEMBLY**
  - (a) Remove the 4 nuts.  
**Torque: 123 N·m ( 1,250 kgf·cm, 90 ft·lbf)**
  - (b) Pull out the axle shaft assembly.**NOTICE:**  
**Be careful not to damage the oil seal.**
  - (c) Remove the O –ring from the bearing case.