


# Diagnosis Circuit

## CIRCUIT DESCRIPTION


This circuit sends an signal to the ECU that outputs DTC.

## WIRING DIAGRAM



**INSPECTION PROCEDURE**

- 1** Check voltage between terminals SIL and CG of DLC3.

**PREPARATION:**

Turn ignition switch ON.

**CHECK:**

Measure voltage between terminals SIL and CG of DLC3.

**OK:**

**Voltage: 10 – 14 V**

**OK**

**Proceed to next circuit inspection shown in problem symptom table ([See page DI-893](#)).**

**NG**

- 2** Check harness and connector between transponder key ECU and DLC3, SIL and body ground ([See page IN-38](#)).

**NG**

**Repair or replace harness or connector.**

**OK**

**Check and replace transponder key ECU.**