

16. Touch switch does not function. (A/C control screen only)

INSPECTION PROCEDURE

1 Display check mode (Touch switch check screen)

NG

Replace the multi-display.

OK

2 Check "AVC-LAN communication circuit". ([See page DI-275](#))

NG

Replace or repair AVC-LAN circuit.

OK

3 Check wire harness between gateway ECU and A/C amplifier (Center ECU) ([See page IN-38](#))

NG

Repair or replace wire harness and connector.

OK

Check and replace A/C amplifier (Center ECU).