

DTC	C 1242 / 42	IG2 Power Source Circuit
------------	--------------------	---------------------------------


CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
C1242/42	With the vehicle running, open circuit in IG2 is detected for more than 7 sec.	<ul style="list-style-type: none"> • Battery • IC regulator • Power source circuit

Fail safe function:


If trouble occurs in the power source circuit, the ECU cuts off current to the ABS solenoid relay and prohibits ABS & BA & TRC & VSC controls and the brake system becomes normal.

WIRING DIAGRAM



F09984

RHD:



F10013

INSPECTION PROCEDURE

1 Check battery voltage.

OK:

Voltage: 10 – 14 V

NG

Check and repair the charging system.

OK

2 Check voltage of the ECU IG power source.

In case of using the hand –held tester:

PREPARATION:

- (a) Connect the hand –held tester to the DLC3.
- (b) Turn the ignition switch ON and push the hand –held tester main switch ON.
- (c) Select the DATALIST mode on the hand –held tester.


CHECK:

Check the voltage condition output from the ECU displayed on the hand –held tester.

OK:

"Normal" is displayed.

In case of not using the hand –held tester:



PREPARATION:

Remove ABS & BA & TRC & VSC ECU with connectors still connected.

CHECK:

- (a) Turn the ignition switch ON.
- (b) Measure voltage between terminals IG2 and GND of ABS & BA & TRC & VSC ECU connector.

OK:


Voltage: 10 – 14 V

OK

Turn ignition switch OFF, check and replace ABS & BA & TRC & VSC ECU.

NG

- 3 Check continuity between terminal GND of ABS & BA & TRC & VSC ECU connector and body ground.**

**CHECK:**

Measure resistance between terminal GND of ABS & BA & TRC & VSC ECU connector and body ground.

OK:

Resistance: 1 Ω or less

NG

Repair or replace harness or connector.

OK

Check for open circuit in harness and connector between ABS & BA & TRC & VSC ECU and battery ([See page IN-35](#)).