


DTC	47	Rear Air Mix Damper Control Servomotor Circuit
------------	-----------	---

CIRCUIT DESCRIPTION

The rear air mix damper control servomotor is controlled by the A/C amplifier and moves the air mix damper to the desired position.

DTC No.	Detection Item	Trouble Area
47	Air mix damper position sensor value does not change even if A/C control assembly operates air mix damper control servomotor	<ul style="list-style-type: none"> • Rear air mix damper control servomotor • Harness or connector between rear air mix damper control servomotor and rear A/C amplifier • Rear A/C amplifier

WIRING DIAGRAM



INSPECTION PROCEDURE

1 Actuator check.

PREPARATION:

- (a) Warm up the engine.
- (b) Set to actuator check mode ([See page DI-1226](#)).
- (c) Press the DEF switch and change it to step operation.

CHECK:

Press the DEF switch and check the operation of the air mix damper and the condition of the blower.

OK:


Display Code	Air Mix Damper	Condition
0 – 2	0 % (Fully closed)	Cool air comes out
3 – 4	50 %	
5 – 7	100 % (Full opened)	Warm air comes out

OK

Proceed to next circuit inspection shown on problem symptoms table ([See page DI-1238](#)).

NG

2 Check rear air mix damper control servomotor.



PREPARATION:

Remove the rear air mix servomotor.

CHECK:

Connect positive (+) lead to terminal 1 and negative (–) lead to terminal 2.

OK:

The lever turns smoothly to WARM side.

CHECK:

Connect positive (+) lead to terminal 2 and negative (–) lead to terminal 1.

OK:

The lever turns smoothly to COOL side.

NG

Replace rear air mix servomotor.

OK

3

Check harness and connector between rear air mix damper control servomotor and rear A/C amplifier ([See page IN-38](#)).

NG

Repair or replace harness or connector.

OK

Check and replace rear A/C amplifier.