

3. No navigation screen displayed when "MAP", "Menu", or "DEST" switch pressed. (Screen cannot be switched.)

INSPECTION PROCEDURE

1 Service check mode (Check the navigation ECU).

NG

Troubleshoot for each diagnosis.

OK

Replace multi –display.

Ncon

2 Check the navigation ECU.

PREPARATION:

Disconnect the navigation ECU connector.

CHECK:

Check voltage terminals +B.

OK:

+B: 10 – 14 V

CHECK:

Check voltage terminal ACC when turn ignition switch ACC or ON position.

OK:

ACC: 10 – 14 V

CHECK:

Check continuity terminal GND.

OK:

GND: Continuity

NG

Replace or repair wire harness or connector.

OK

3

Check wire harness and connector between multi display and navigation ECU
([See page IN-38](#)).

NG

Repair or replace wire harness or connector.

OK

Check and replace multi display.