



## INSTALLATION

### 1. INSTALL CAMSHAFT POSITION SENSOR

Install the camshaft position sensor with the bolt and stud bolt

**Torque: 7.5 N·m (80 kgf·cm, 66 in·lbf)**

### 2. INSTALL LH NO.3 TIMING BELT COVER

(See page EM-23)

### 3. CONNECT RADIATOR HOSE

### 4. INSTALL V –BANK COVER

### 5. FILL ENGINE COOLANT (See page CO-2)

### 6. CHECK ENGINE COOLANT FOR LEAKS

### 7. CHECK IGNITION TIMING (See page EM-11)