

## CIRCUIT INSPECTION

<b>DTC</b>	<b>P0705</b>	<b>Transmission Range Sensor Circuit Malfunction (PRNDL Input)</b>
------------	--------------	--


<b>DTC</b>	<b>P0850</b>	<b>Park/Neutral Switch Input Circuit</b>
------------	--------------	--

## CIRCUIT DESCRIPTION

The neutral start switch detects the shift lever range and sends signals to the Engine and ECT ECU.

DTC No.	DTC Detection Condition	Trouble Area
P0705	(2-trip detection logic) <ul style="list-style-type: none"> <li>• All switches are OFF simultaneously for P, R, N, D, 3 and 2 ranges.</li> <li>• 2 or more switches are ON simultaneously for P, R, N, (D 4), 3 and (2 L) ranges.</li> </ul>	<ul style="list-style-type: none"> <li>• Short in neutral start switch circuit</li> <li>• Neutral start switch.</li> <li>• Engine and ECT ECU</li> </ul>
P0850	Neutral start switch remains ON (P, N range) during driving under conditions (a) and (b) for 30 sec. (2 –trip detection logic) (a) Vehicle speed: 70 km/h (44 mph) or more (b) Engine speed: 1,500 – 2,500 rpm	


## WIRING DIAGRAM



D12768

## INSPECTION PROCEDURE

## 1 Check neutral start switch.



N

D06561

**PREPARATION:**

- (a) Jack up the vehicle.
- (b) Disconnect the neutral start switch connector.

**CHECK:**

Check continuity between each terminal shown below when the shift lever is moved to each range.

**OK:**


Shift range	Terminal No. to continuity	Terminal No. to continuity
P	1 – 3	6 – 9
R	2 – 3	–
N	3 – 5	6 – 9
D, 4	3 – 7	–
3	3 – 4	–
2, L	3 – 8	–

**NG**

**Replace neutral start switch**  
(See page AT-7).

**OK**

**2 Check transmission control switch.**



**PREPARATION:**

- (a) Connect the neutral start switch connector.
- (b) Disconnect the shift lock control computer connector (transmission control switch).

**CHECK:**

Check continuity between each terminal of shift lock control computer (transmission control switch).

**OK:**


Shift range	Tester connection	Specified valve
D	1 – 8 (NSSD – AT4)	No continuity
4		Continuity
2	6 – 12 (NSSL – ATL)	No continuity
L		Continuity

**NG**

**Replace the transmission control switch**  
(See page AT-21).

**OK**

- 3 Measure voltage between each terminals of NSW, P, R, N, D, 4, 3, 2, L and E1 of Engine and ECT ECU.**

**PREPARATION:**

- Connect the shift lock control computer connector (transmission control switch).
- Turn the ignition switch ON.

**CHECK:**

Measure voltage between each terminals NSW, P, R, N, D, 4, 3, 2, L and E1 of Engine and ECT ECU when the shift lever is shifted to the following ranges.

**OK:**

Tester connection	Condition	Specified condition
NSW – Body ground	Shift lever range: P and N	Below 1 V
	Shift lever range: Except P and N	Battery voltage
P – Body ground	Shift lever range: P	Battery voltage
R – Body ground	Shift lever range: R	Battery voltage*
N – Body ground	Shift lever range: N	Battery voltage
D – Body ground	Shift lever range: D and 4	Battery voltage
4 – Body ground	Shift lever range: 4	Battery voltage
3 – Body ground	Shift lever range: 3	Battery voltage
2 – Body ground	Shift lever range: 2 and L	Battery voltage
L – Body ground	Shift lever range: L	Battery voltage

**HINT:**

\*: The voltage will drop slightly due to lighting up of the back up light.

**OK**

**Check and replace the Engine and ECT ECU (See page IN-38).**

**NG**

**Repair or replace the harness or connector (See page IN-38).**