

# TORQUE SPECIFICATION

Part tightened	N·m	kgf·cm	ft·lbf
Shift lever boot retainer x Body (Separate seat, M/T)	6.5	66	58 in.·lbf
Transfer shift lever assembly x Transfer (Separate seat, M/T)	19	190	14
Transfer x Front propeller shaft	80	820	59
Front propeller shaft x Front differential	80	820	59
Transfer x Rear propeller shaft	106	1,080	78
Rear propeller shaft x Rear differential	106	1,080	78
Transfer case protector x Crossmember	28	290	21
Drain and filler plug	37	380	27
Transfer shift lever rod assembly x Shift outer lever Except separate seat, M/T A/T	12	120	9
	14	140	10
Transfer shift lever rod assembly x Transfer shift lever shaft [w/o One touch 2-4 selector system, bench seat (M/T)]	12	120	9
Transfer shift lever rod assembly stopper nut [w/o One touch 2-4 selector system, bench seat (M/T)]	13	130	9
Crossmember x Frame	50	510	37
Crossmember x Engine rear mounting	74	750	54
Transfer x Transmission	69	700	51
Lever lock pin	12	120	9
Oil receiver x Front case	12	120	9
Case cover x Rear case	37	380	27
Rear extension housing x Rear case	37	380	27
Front extension housing x Front case	37	380	27
Transfer 4WD position switch	37	380	27
L4 position switch	37	380	27
Neutral position switch	37	380	27
Screw plug	19	190	14
Output shaft lock nut	127	1,300	94
Motor actuator x Front case (w/ One touch 2-4 selector system, M/T & A/T)	18	185	13
Speed sensor driven gear set bolt	11	115	8
Oil receiver pipe x Rear case (See page TR-13)	Bolt A	12	120
	Bolt B	18	185
Front case x Rear case	37	380	27
Oil receiver x Idler gear	7.8	80	69 in.·lbf
Oil receiver pipe x Front extension housing	4.9	50	43 in.·lbf
Shift lever cap x Transfer control shift lever retainer (M/T)	29	300	22
Transfer control shift lever retainer x Transmission or transfer (M/T)	19	190	14
Transfer shift lever x Lever lock pin (M/T)	12	120	9
Transfer control shift lever retainer x Transmission (A/T)	29	300	22