


## BRAKE Warning Buzzer Circuit

### CIRCUIT DESCRIPTION

The BRAKE warning buzzer sounds when the accumulator pressure is abnormally low or an abnormality causing low fluid pressure occurs.

### WIRING DIAGRAM



### INSPECTION PROCEDURE

Start the inspection from step 1 in case of using the hand –held tester and start from step 2 in case of not using the hand –held tester.

1	Check operation of the BRAKE warning buzzer.
---	--

#### PREPARATION:

- (a) Connect the hand –held tester to the DLC3.
- (b) Turn the ignition switch ON and push the hand –held tester main switch ON.
- (c) Select the ACTIVE TEST mode on the hand –held tester.

#### CHECK:

Check that BRAKE warning buzzer sounds "ON" using the hand –held tester.

#### HINT:

BRAKE warning buzzer sounds "OFF" automatically 2 seconds after it sounds "ON".

OK

Check and replace ABS ECU.

NG

**2 Check BRAKE warning buzzer.**

See combination meter troubleshooting on [page BE-2](#).

**NG****Replace BRAKE warning buzzer.****OK****3 Check for open and short circuit in harness and connector between BRAKE warning buzzer and ABS ECU (See [page IN-24](#)).****NG****Repair or replace harness or connector.****OK****Check and replace ABS ECU.**