



## Door key lock and unlock switch circuit

### CIRCUIT DESCRIPTION

The door key lock and unlock switch is built in the door key cylinder. When the key is turned to the lock side, terminal 3 of the switch is grounded and when the key is turned to the unlock side, terminal 2 of the switch is grounded.

### WIRING DIAGRAM





**INSPECTION PROCEDURE**

- |   |  |
|---|--|
| 1 | Check the door key lock and unlock switch. ( <a href="#">See page BE-111</a> ) |
|---|--|

NG
----

Replace the door key lock and unlock switch.
--

OK
----

- |   |   |
|---|---|
| 2 | Check wireharness and connector between door key lock and unlock switch and body ECU. |
|---|---|

NG
----

Repair or replace wireharness or connector.
---

OK
----

Proceed to next circuit inspection shown on problem symptoms table. ( <a href="#">See page DI-773</a> )
--