


BRAKE Warning Light Circuit

CIRCUIT DESCRIPTION


The BRAKE warning light lights up while the brake fluid is insufficient or an abnormality occurs in the hydraulic brake booster and EBD is abnormally.

WIRING DIAGRAM



F09207

RHD:



P

F10019

INSPECTION PROCEDURE

1 Check parking brake switch circuit ([See page BE-4](#)).

NG

Repair or replace parking brake switch circuit.

OK

2 Check brake fluid level warning switch circuit ([See page BE-4](#)).

NG

Repair or replace brake fluid level warning switch circuit.

OK

3 Is DTC output for ABS?

YES

Repair circuit indicated by the output code.

NO

4 Does the warning lights other than BRAKE warning lights up?

YES

Go to step 6.

NO

- | | |
|----------|---|
| 7 | Check for short circuit in harness and connector between brake warning light and ABS & BA & TRC & VSC ECU (See page IN-35). |
|----------|---|

NG

Repair or replace harness or connector.

OK

- | | |
|----------|---|
| 8 | Check voltage of the ECU-IG power source. |
|----------|---|

In case of using the hand-held tester:

PREPARATION:

- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the ignition switch ON and push the hand-held tester main switch ON.
- (c) Select the DATALIST mode on the hand-held tester.


CHECK:

Check the voltage condition output from the ECU displayed on the hand-held tester.

OK:

"Normal" is displayed.

In case of not using the hand-held tester:

**PREPARATION:**

Remove ABS & BA & TRC & VSC ECU with connectors still connected.

CHECK:

- (a) Turn the ignition switch ON.
- (b) Measure voltage between terminals IG1 and GND of ABS & BA & TRC & VSC ECU connector.

OK:

Voltage: 10 – 14 V

NG

Check and replace harnedd or connector.

OK

Check and repair ABS & BA & TRC & VSC ECU.