

## 5. No navigation displayed, "Audio OFF" on audio screen and no audio sound.

### INSPECTION PROCEDURE

**1 Service check mode.**

**NG**

**Troubleshoot for each diagnosis.**

**OK**

**2 Check the radio receiver assembly.**

#### **PREPARATION:**

Disconnect the radio receiver assembly connector.

#### **CHECK:**

Check voltage terminals +B.

#### **OK:**

**+B: 10 – 14 V**

#### **CHECK:**

Check voltage terminal ACC when turn ignition switch ACC or ON position.

#### **OK:**

**ACC: 10 – 14 V**

#### **CHECK:**

Check continuity terminal GND.

#### **OK:**

**GND: Continuity**

**NG**

**Replace or repair wire harness.**

**OK**

**3 Check "AVC-LAN communication circuit". ([See page DI-104](#))**

**NG**

**Replace the AVC –LAN circuit or radio receiver assembly.**

**OK**

**Replace the multi display.**