

DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during the DTC check, check the circuit listed for that code in the table below (Proceed to the page given for that circuit.).

DTC No. (See Page)	Detection Item	Trouble Area	SRS Warning Light
B0100/13 (DI-452)	• Short in D squib circuit	<ul style="list-style-type: none"> • Steering wheel pad (squib) • Spiral cable • Airbag sensor assembly • Dash wire • Column wire 	ON
B0101/14 (DI-458)	• Open in D squib circuit	<ul style="list-style-type: none"> • Steering wheel pad (squib) • Spiral cable • Airbag sensor assembly • Dash wire • Column wire 	ON
B0102/11 (DI-463)	• Short in D squib circuit (to ground)	<ul style="list-style-type: none"> • Steering wheel pad (squib) • Spiral cable • Airbag sensor assembly • Dash wire • Column wire 	ON
B0103/12 (DI-468)	• Short in D squib circuit (to B+)	<ul style="list-style-type: none"> • Steering wheel pad (squib) • Spiral cable • Airbag sensor assembly • Dash wire • Column wire 	ON
B0105/53 (DI-473)	• Short in P squib circuit	<ul style="list-style-type: none"> • Front passenger airbag assembly (squib) • Airbag sensor assembly • Dash wire 	ON
B0106/54 (DI-477)	• Open in P squib circuit	<ul style="list-style-type: none"> • Front passenger airbag assembly (squib) • Airbag sensor assembly • Dash wire 	ON
B0107/51 (DI-480)	• Short in P squib circuit (to ground)	<ul style="list-style-type: none"> • Front passenger airbag assembly (squib) • Airbag sensor assembly • Dash wire 	ON
B0108/52 (DI-483)	• Short in P squib circuit (to B+)	<ul style="list-style-type: none"> • Front passenger airbag assembly (squib) • Airbag sensor assembly • Dash wire 	ON
B0110/43 (*1) (DI-486)	• Short in side squib RH circuit	<ul style="list-style-type: none"> • Side airbag assembly RH (squib) • Airbag sensor assembly • Floor No. 2 wire 	Blink
B0111/44 (*1) (DI-490)	• Open in side squib RH circuit	<ul style="list-style-type: none"> • Side airbag assembly RH (squib) • Airbag sensor assembly • Floor No. 2 wire 	Blink
B0112/41 (*1) (DI-493)	• Short in side squib RH circuit (to ground)	<ul style="list-style-type: none"> • Side airbag assembly RH (squib) • Airbag sensor assembly • Floor No. 2 wire 	Blink
B0113/42 (*1) (DI-496)	• Short in side squib RH circuit (to B+)	<ul style="list-style-type: none"> • Side airbag assembly RH (squib) • Airbag sensor assembly • Floor No. 2 wire 	Blink
B0115/47 (*1) (DI-499)	• Short in side squib LH circuit	<ul style="list-style-type: none"> • Side airbag assembly LH (squib) • Airbag sensor assembly • Floor No. 1 wire 	Blink

B0116/48 (*1) (DI-503)	• Open in side squib LH circuit	• Side airbag assembly LH (squib) • Airbag sensor assembly • Floor No. 1 wire	Blink
B0117/45 (*1) (DI-506)	• Short in side squib LH circuit (to ground)	• Side airbag assembly LH (squib) • Airbag sensor assembly • Floor No. 1 wire	Blink
B0118/46 (*1) (DI-509)	• Short in side squib LH circuit (to B+)	• Side airbag assembly LH (squib) • Airbag sensor assembly • Floor No. 1 wire	Blink
B0121/B0122/ 26 (*2) (DI-522)	• Seat belt buckle switch RH malfunction	• Front seat inner belt RH • Airbag sensor assembly • Floor No. 2 wire • Front seat wire RH	ON
B0126/B0127/ 27 (*3) (DI-522)	• Seat belt buckle switch LH malfunction	• Front seat inner belt LH • Airbag sensor assembly • Floor No. 1 wire • Front seat wire LH • Dash wire (Bench seat)	ON
B0130/63 (DI-539)	• Short in P/T squib RH circuit	• Seat belt pretensioner RH (squib) • Airbag sensor assembly • Floor No. 2 wire • Dash wire (Bench seat)	Blink
B0131/64 (DI-547)	• Open in P/T squib RH circuit	• Seat belt pretensioner RH (squib) • Airbag sensor assembly • Floor No. 2 wire • Dash wire (Bench seat)	Blink
B0132/61 (DI-555)	• Short in P/T squib RH circuit (to ground)	• Seat belt pretensioner RH (squib) • Airbag sensor assembly • Floor No. 2 wire • Dash wire (Bench seat)	Blink
B0133/62 (DI-563)	• Short in P/T squib RH circuit (to B+)	• Seat belt pretensioner RH (squib) • Airbag sensor assembly • Floor No. 2 wire • Dash wire (Bench seat)	Blink
B0135/73 (DI-571)	• Short in P/T squib LH circuit	• Seat belt pretensioner LH (squib) • Airbag sensor assembly • Floor No. 1 wire • Dash wire (Bench seat)	Blink
B0136/74 (DI-579)	• Open in P/T squib LH circuit	• Seat belt pretensioner LH (squib) • Airbag sensor assembly • Floor No. 1 wire • Dash wire (Bench seat)	Blink
B0137/71 (DI-587)	• Short in P/T squib LH circuit (to ground)	• Seat belt pretensioner LH (squib) • Airbag sensor assembly • Floor No. 1 wire • Dash wire (Bench seat)	Blink
B0138/72 (DI-595)	• Short in P/T squib LH circuit (to B+)	• Seat belt pretensioner LH (squib) • Airbag sensor assembly • Floor No. 1 wire • Dash wire (Bench seat)	Blink
B1100/31 (DI-603)	• Airbag sensor assembly malfunction	• Airbag sensor assembly	ON

DIAGNOSTICS – SUPPLEMENTAL RESTRAINT SYSTEM

B1135/24 (DI-605)	<ul style="list-style-type: none"> • Half connection in airbag sensor assembly connector 	<ul style="list-style-type: none"> • Airbag sensor assembly • Dash wire • Floor No. 1 wire • Floor No. 2 wire 	ON
B1140/32 (*1) (DI-607)	<ul style="list-style-type: none"> • Side and curtain shield airbag sensor assembly RH malfunction 	<ul style="list-style-type: none"> • Side and curtain shield airbag sensor assembly RH • Airbag sensor assembly • Floor No. 2 wire 	Blink
B1141/33 (*1) (DI-613)	<ul style="list-style-type: none"> • Side and curtain shield airbag sensor assembly LH malfunction 	<ul style="list-style-type: none"> • Side and curtain shield airbag sensor assembly LH • Airbag sensor assembly • Floor No. 1 wire 	Blink
B1148/36 (*1) (DI-619)	<ul style="list-style-type: none"> • Front airbag sensor RH malfunction 	<ul style="list-style-type: none"> • Front airbag sensor RH • Airbag sensor assembly • Dash wire • Engine room No. 2 wire • Engine room main wire 	ON
B1149/37 (*1) (DI-628)	<ul style="list-style-type: none"> • Front airbag sensor LH malfunction 	<ul style="list-style-type: none"> • Front airbag sensor LH • Airbag sensor assembly • Dash wire • Engine room No. 2 wire • Engine room main wire 	ON
B1153/25 (DI-636)	<ul style="list-style-type: none"> • Seat position sensor malfunction 	<ul style="list-style-type: none"> • Seat position sensor assembly • Airbag sensor assembly • Floor No. 1 wire (LHD) • Floor No. 2 wire (RHD) • Front seat wire LH (LHD) • Front seat wire RH (RHD) • Dash wire (Bench seat) 	ON
B1154/38 (*1) (DI-667)	<ul style="list-style-type: none"> • Curtain shield airbag sensor assembly RH malfunction 	<ul style="list-style-type: none"> • Curtain shield airbag sensor assembly RH • Airbag sensor assembly • Floor No. 2 wire 	Blink
B1155/39 (*1) (DI-673)	<ul style="list-style-type: none"> • Curtain shield airbag sensor assembly LH malfunction 	<ul style="list-style-type: none"> • Curtain shield airbag sensor assembly LH • Airbag sensor assembly • Floor No. 1 wire 	Blink
B1156/B1157/ 15 (*4) (DI-679)	<ul style="list-style-type: none"> • Front airbag sensor RH malfunction 	<ul style="list-style-type: none"> • Front airbag sensor RH • Airbag sensor assembly • Dash wire • Engine room No. 2 wire • Engine room main wire 	ON
B1158/B1159/ 16 (*4) (DI-686)	<ul style="list-style-type: none"> • Front airbag sensor LH malfunction 	<ul style="list-style-type: none"> • Front airbag sensor LH • Airbag sensor assembly • Dash wire • Engine room No. 2 wire • Engine room main wire 	ON
B1160/83 (*1) (DI-693)	<ul style="list-style-type: none"> • Short in curtain shield squib RH circuit 	<ul style="list-style-type: none"> • Curtain shield airbag assembly RH (squib) • Airbag sensor assembly • Floor No. 2 wire 	Blink
B1161/84 (*1) (DI-697)	<ul style="list-style-type: none"> • Open in curtain shield squib RH circuit 	<ul style="list-style-type: none"> • Curtain shield airbag assembly RH (squib) • Airbag sensor assembly • Floor No. 2 wire 	Blink
B1162/81 (*1) (DI-700)	<ul style="list-style-type: none"> • Short in curtain shield squib RH circuit (to ground) 	<ul style="list-style-type: none"> • Curtain shield airbag assembly RH (squib) • Airbag sensor assembly • Floor No. 2 wire 	Blink
B1163/82 (*1) (DI-703)	<ul style="list-style-type: none"> • Short in curtain shield squib RH circuit (to B+) 	<ul style="list-style-type: none"> • Curtain shield airbag assembly RH (squib) • Airbag sensor assembly • Floor No. 2 wire 	Blink

B1165/87 (*1) (DI-706)	• Short in curtain shield squib LH circuit	<ul style="list-style-type: none"> • Curtain shield airbag assembly LH (squib) • Airbag sensor assembly • Floor No. 1 wire 	Blink
B1166/88 (*1) (DI-710)	• Open in curtain shield squib LH circuit	<ul style="list-style-type: none"> • Curtain shield airbag assembly LH (squib) • Airbag sensor assembly • Floor No. 1 wire 	Blink
B1167/85 (*1) (DI-713)	• Short in curtain shield squib LH circuit (to ground)	<ul style="list-style-type: none"> • Curtain shield airbag assembly LH (squib) • Airbag sensor assembly • Floor No. 1 wire 	Blink
B1168/86 (*1) (DI-716)	• Short in curtain shield squib LH circuit (to B+)	<ul style="list-style-type: none"> • Curtain shield airbag assembly LH (squib) • Airbag sensor assembly • Floor No. 1 wire 	Blink
B1180/17 (*5) (DI-719)	• Short in D squib (2nd step) circuit	<ul style="list-style-type: none"> • Steering wheel pad (D squib, 2nd step) • Spiral cable • Airbag sensor assembly • Dash wire • Column wire 	ON
B1181/18 (*5) (DI-725)	• Open in D squib (2nd step) circuit	<ul style="list-style-type: none"> • Steering wheel pad (D squib, 2nd step) • Spiral cable • Airbag sensor assembly • Dash wire • Column wire 	ON
B1182/19 (*5) (DI-730)	• Short in D squib (2nd step) circuit (to ground)	<ul style="list-style-type: none"> • Steering wheel pad (D squib, 2nd step) • Spiral cable • Airbag sensor assembly • Dash wire • Column wire 	ON
B1183/22 (*5) (DI-736)	• Short in D squib (2nd step) circuit (to B+)	<ul style="list-style-type: none"> • Steering wheel pad (D squib, 2nd step) • Spiral cable • Airbag sensor assembly • Dash wire • Column wire 	ON
B1185/57 (*5) (DI-742)	• Short in P squib (2nd step) circuit	<ul style="list-style-type: none"> • Front passenger airbag assembly (squib) • Airbag sensor assembly • Wire harness 	ON
B1186/58 (*5) (DI-746)	• Open in P squib (2nd step) circuit	<ul style="list-style-type: none"> • Front passenger airbag assembly (squib) • Airbag sensor assembly • Wire harness 	ON
B1187/55 (*5) (DI-749)	• Short in P squib (2nd step) circuit (to ground)	<ul style="list-style-type: none"> • Front passenger airbag assembly (squib) • Airbag sensor assembly • Wire harness 	ON
B1188/56 (*5) (DI-753)	• Short in P squib (2nd step) circuit (to B+)	<ul style="list-style-type: none"> • Front passenger airbag assembly (squib) • Airbag sensor assembly • Wire harness 	ON
B1628/29 (*1) (DI-753)	• RSCA cutoff switch indicator	<ul style="list-style-type: none"> • RSCA cutoff switch • Airbag sensor assembly • Dash wire • Instrument panel wire 	Blink
Normal (DI-764)	System normal	–	OFF
	Voltage source drop	<ul style="list-style-type: none"> • Battery • Airbag sensor assembly 	ON

*1: w/ Side Airbag

*2: RHD

*3: LHD

*4: w/o Side Airbag (Single Stage Airbag)

*5: w/ Side Airbag and w/o Side Airbag (Dual Stage Airbag)

HINT:

- S When the SRS warning light remains lit up and the DTC is the normal code, a voltage source drop is possible.
This malfunction is not stored in memory by the airbag sensor assembly and if the power source voltage returns to normal, the SRS warning light will automatically go out.
- S When 2 or more codes are indicated, smaller numbered code will be shown first.
- S If a code not listed on the chart is displayed, the airbag sensor assembly is at fault.
- S In the case of any malfunction concerning any open circuit, ground short, or B+ short due to any squib, another malfunction code may not be detected. In this case, correct the malfunction currently indicated and then perform malfunction diagnosis again. Another malfunction code may then be detected.