





P

BODY ELECTRICAL – COMBINATION METER

| No. | | Wiring connector side | No. | | Wiring connector side |
|-----|----|--------------------------------------|-----|----|------------------------------------|
| A | 1 | Key unlock warning switch | C | 1 | Front diff. lock detection switch |
| | 2 | Fuel main sender gauge | | 2 | Rear diff. lock detection switch |
| | 3 | Fuel main sender gauge | | 3 | ECU-B fuse |
| | 4 | Fuel main sender gauge | | 4 | Center airbag sensor assembly |
| | 5 | Fuel sub sender gauge | | 5 | Neutral start switch (N range) |
| | 6 | Fuel sub sender gauge | | 6 | Neutral start switch (D range) |
| | 7 | Fuel sub sender gauge | | 7 | Neutral start switch (2 range) |
| | 8 | Sub fuel switch | | 8 | Neutral start switch (L range) |
| | 9 | ABS ECU | | 9 | Air filter warning switch |
| | 10 | Light control rheostat | | 10 | O/D main switch |
| | 11 | TAIL fuse | | 11 | Engine and ECT ECU |
| | 12 | Driver door courtesy switch | | 12 | Low oil pressure warning switch |
| | 13 | Engine and ECT ECU | | 14 | Engine and ECT ECU |
| | 14 | Fuel sedimenter warning switch | | 15 | Transfer 4WD position switch |
| | 15 | Seat belt buckle switch | | | Center diff. lock indicator switch |
| | 16 | GAUGE fuse | | 16 | Rear fog light switch |
| | 17 | DOVE fuse | | 17 | ABS, TRC, VSCECU |
| | 18 | ABS ECU | | 18 | ABS, TRC, VSCECU |
| | 19 | Front fog light switch | | 19 | ABS, TRC, VSCECU |
| | | | | 20 | ABS, TRC, VSCECU |
| B | 1 | Tire half lock indicator switch | D | 2 | Glow plug timer |
| | 2 | Engine and ECT ECU | | 3 | Suspension control ECU |
| | 3 | Turbo pressure gauge | | 4 | Suspension control ECU |
| | 4 | CIGAR fuse | | 5 | Suspension control ECU |
| | 5 | Neutral start switch (P range) | | 6 | Suspension control ECU |
| | 6 | Neutral start switch (P range) | | 7 | Brake fluid level warning switch |
| | 7 | Neutral start switch (R range) | | 8 | Parking brake switch |
| | 8 | A/T oil temperature indicator switch | | 9 | Body control ECU (M/T) |
| | 9 | Speed control unit | | 10 | ECT pattern select switch |
| | 10 | Speed sensor | | 11 | Body control ECU |
| | 11 | Ground | | 12 | Ground |
| | 13 | Alternator | | 13 | Turn signal switch (Left) |
| | 14 | IGN fuse | | 14 | Headlight dimmer switch |
| | 15 | Water temperature sender gauge | | 15 | Turn signal switch (Right) |
| | 16 | Ground | | 18 | ABS, TRC, VSCECU |
| | 17 | Engine and ECT ECU | | | |
| | 18 | Engine oil level sensor | | | |