


# Diagnosis Circuit

## CIRCUIT DESCRIPTION


This circuit sends a signal to the ECU that DTC output is required.

## WIRING DIAGRAM



## INSPECTION PROCEDURE

- 1 Check voltage between terminals Tc and E<sub>1</sub> of DLC3.

**PREPARATION:**

Turn ignition switch ON.

**CHECK:**

Measure voltage between terminals Tc and E<sub>1</sub> of DLC3.

**OK:**

Voltage: 10 – 14 V

OK

Proceed to next circuit inspection shown in problem symptom table ([See page DI-773](#)).

NG

- 2 Check harness and connector between instrument panel ECU (body ECU) and DLC3, DLC3 and body ground ([See page IN-35](#)).

NG

Repair or replace harness or connector.

OK

Check and replace instrument panel ECU ([See page IN-35](#)).