

15. Touch switch does not function. (Navigation screen only)**INSPECTION PROCEDURE**

1 Display check mode (Touch switch, Touch point screen).

NG

Replace the multi-display.

OK

2 Check "AVC-LAN communication circuit" ([See page DI-1215](#)).

NG

Replace or repair AVC –LAN circuit.

OK

Replace the navigation ECU.