

| | | |
|------------|-----------------|-----------------------------------|
| DTC | P0607/54 | Control Module Performance |
|------------|-----------------|-----------------------------------|

CIRCUIT INSPECTION

This DTC expresses the internal abnormalities of ECM.

| DTC No. | Detection Item | Trouble Area |
|----------|--|---|
| P0607/54 | <ul style="list-style-type: none">• Cruise control input signal abnormal.• Stop light switch input signal abnormal. | <ul style="list-style-type: none">• ECM |

INSPECTION PROCEDURE

Check and replace ECM ([See page IN-38](#)).