

## 9. Black screen appears when "MAP", "Menu" or "DESTINATION" switch pressed.

### INSPECTION PROCEDURE

1	Check the navigation ECU.
---	---------------------------

#### CHECK:

Check terminals +B.

#### OK:

**+B: 10 – 14 V**

#### CHECK:

Check terminal ACC when turn ignition switch ACC or ON position.

#### OK:

**ACC: 10 – 14 V**

#### CHECK:

Check terminal R, G, B, VR or VG.

#### OK:

**R, G, B, VR or VG: See "Navigation ECU" of "TERMINAL OF ECU"**

**NG**

**Replace the wire harness when all terminals are faulty. Replace the wire harness when R,G,B terminal is faulty.**

**OK**

**Replace the multi –display.**