


DTC	C 1340 / 47	Center Differential Lock Circuit
------------	--------------------	---


CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
C1240/47	Open or short circuit in center differential lock circuit.	<ul style="list-style-type: none"> Center differential lock system Center differential lock circuit

WIRING DIAGRAM



RHD:



INSPECTION PROCEDURE

1

Check the center differential is free and center diff. lock switch is OFF.

NG

Repair the center differential lock system.

OK

2 Is DTC output?

Check DTC on [page DI-185](#).

NO

END

YES

3 Check that bulb for center diff. lock indicator light is not burnt out.

NG

Replace indicator light.

OK


4 Check for open circuit in harness and connector between battery and center diff. lock indicator light, center diff. lock indicator light and skid control ECU ([See page IN-38](#)).

NG

Repair or replace harness or connector.

OK

5 Check voltage between terminal EXI of skid control ECU and body ground.



PREPARATION:

Remove skid control ECU with connectors still connected.

CHECK:

- (a) Turn the ignition switch ON.
- (b) Measure voltage between terminal EXI of skid control ECU and body ground when transfer in L4 position.

OK:

Voltage: 10 – 14 V

NG

Repair or replace harness or connector.

OK

6	Check center diff. lock indicator switch (Full time 4WD type: See Pub. No. RM616E on page TR -53).
---	--

NG

Replace center diff. lock indicator switch.

OK

Check and replace skid control ECU.