

**15. Touch switch does not function. (Navigation screen only)****INSPECTION PROCEDURE**

**1** Display check mode (Touch switch check screen)

NG

Replace the multi-display.

OK

**2** Check "AVC-LAN communication circuit". ([See page DI-275](#))

NG

Replace or repair AVC –LAN circuit.

OK

Replace the navigation ECU.