



# POWER DOOR LOCK CONTROL SYSTEM INSPECTION

BE12V-01

**Master Switch:**  
**INSPECT DRIVER'S DOOR LOCK CONTROL SWITCH CONTINUITY**

Switch position	Tester connection	Specified condition
LOCK	9 - 15	Continuity
OFF	-	No continuity
UNLOCK	9 - 16	Continuity

If continuity is not as specified, replace the switch.