


Security Indicator Light Circuit

CIRCUIT DESCRIPTION


WIRING DIAGRAM



I26278

INSPECTION PROCEDURE

- 1 Check voltage between terminals IND of transponder key ECU connector and body ground.**

**PREPARATION:**

Turn ignition switch ON and do diagnosis mode.

CHECK:

Measure voltage between terminals IND of transponder key ECU connector and body ground when security indicator light light up and does not light up.

OK:


Indicator light	Voltage
Light up	3 – 6 V
Does not light up	Below 1 V

NG

Proceed to next circuit inspection shown in problem symptom table ([See page DI-893](#)).

OK

- 2 Check multi –information display.**

**PREPARATION:**

Turn ignition switch ON and do diagnosis mode.

CHECK:

Measure voltage between terminals IND of transponder key ECU connector and body ground when security indicator light light up and does not light up.

OK:

Indicator light	Voltage
Light up	8 – 10 V
Does not light up	Below 1 V

NG

Repair or Replace wire harness or connector.

OK

Check and replace multi –information display.