



DISASSEMBLY

1. REMOVE DRIVEN ROTOR

2. REMOVE RELIEF VALVE

Remove the plug, gasket, spring and relief valve.