

18. Panel Switch Does Not Function (A/C control only)

INSPECTION PROCEDURE

1 Display check mode (Panel Switch Check screen).

NG

Replace the multi display.

OK

2 Check "AVC-LAN communication circuit" ([See page DI-104](#)).

NG

Replace or repair AVC-LAN circuit.

OK

3 Check wire harness and connector between gateway ECU and A/C amplifier (Center ECU) ([See page IN-34](#)).

NG

Repair or replace wire harness and connector.

OK

Check and replace A/C amplifier (Center ECU).