

17. Panel switch does not function. (Navigation screen only)

INSPECTION PROCEDURE

| | |
|---|--|
| 1 | Display check mode (Panel switch check screen) |
|---|--|

| | |
|----|----------------------------|
| NG | Replace the multi display. |
|----|----------------------------|

OK

| | |
|---|--|
| 2 | Check "AVC-LAN communication circuit". (See page DI-275) |
|---|--|

| | |
|----|-------------------------------------|
| NG | Replace or repair AVC –LAN circuit. |
|----|-------------------------------------|

OK

| |
|-----------------------------|
| Replace the navigation ECU. |
|-----------------------------|