

CIRCUIT INSPECTION

1. Black screen (Nothing displayed)

INSPECTION PROCEDURE

1 Check the ECU –IG fuse.

NG

Replace the fuse.

OK

2 Check multi–display power source circuit ([see page DI-259](#)).

NG

Replace or repair wire harness or connector.

OK

Replace the mult –display.