


ADJUSTMENT

1. ADJUST DOOR IN FORWARD/REARWARD AND VERTICAL DIRECTION

Loosen the body side hinge bolts to adjust.


Torque: 42 N·m (430 kgf·cm, 3 1 ft·lbf)



2. ADJUST DOOR IN LEFT/RIGHT AND VERTICAL DIRECTION

Loosen the door side hinge bolts to adjust.

Torque: 42 N·m (430 kgf·cm, 3 1 ft·lbf)



3. ADJUST DOOR UPPER LOCK STRIKER


(a) Check that the door fit and door lock linkages are adjusted correctly.

(b) Using a torx wrench, loosen the door lock striker mounting screws.

Torx wrench: T40 (Part No.09042 –00020 or locally manufactured tool)

Torque: 12 N·m (122 kgf·cm, 19 ft·lbf)

(c) Using a plastic hammer, tap the striker to adjust.



4. ADJUST DOOR LOWER LOCK STRIKER


(a) Check that the door fit and door lock linkages are adjusted correctly.

(b) Using a torx wrench, loosen the door lock striker mounting screws.

Torx wrench: T40 (Part No.09042 –00020 or locally manufactured tool)

Torque: 12 N·m (122 kgf·cm, 19 ft·lbf)

(c) Using a plastic hammer, tap the striker to adjust.



5. ADJUST BACK DOOR STOPPER BRACKET

(a) Check that the door fit and door stopper are adjusted correctly.

(b) Loosen the door stopper bracket mounting bolts.

Torque: 18 N·m (185 kgf·cm, 13 ft·lbf)

(c) Using a plastic hammer, tap the striker to adjust.