

GlowCore v2.0

Quick Start Guide

Learn how to get started
with your GlowCore dev board.




Download PDF:
bit.ly/3gZ5Wep




Step 1:

Connect your LED strip to GlowCore. Check out the pinout overview (PDF available via bit.ly/3P3ZSO1) for more details.



Step 2:

Power GlowCore via **USB-C** or connect an external 5V source to the **5V IN** pin.



Step 2:

Connect to Wi-Fi:



 GlowCore

Control GlowCore via your web browser or the WLED app, using the IP **4.3.2.1**