


PRIME LESSONS

By the Makers of EV3Lessons



INSTALLING SOFTWARE & FIRMWARE ON SPIKE PRIME AND ROBOT INVENTOR


BY SANJAY AND ARVIND SESHAN

LESSON OBJECTIVES


- Learn how to update SPIKE Prime and Robot Inventor



FIRST USE





- Connect your SPIKE Prime or Robot Inventor to your computer using the USB Cable for OS Updates
- The software will auto-connect to the brick if you are using USB
- Note: If you are using the iOS, Android, or Chromebook version of the software, you may need to connect to your Hub using a computer the very first time to update the firmware on the Hub. Subsequent updates may be possible via Bluetooth. [This process may get updated.]




INSTALL LATEST SOFTWARE

- SPIKE Prime: <https://education.lego.com/en-us/downloads/spike-prime/software>
- Robot Inventor: <https://www.lego.com/en-us/service/device-guide/mindstorms-robot-inventor/>
- You can check for SPIKE Prime Software Updates from inside the App
 - Click on the Help Menu inside a Project and Check for Update
- There is no equivalent choice in Robot Inventor (you will be prompted for any updates or you can visit the app store)




CHECKING WHAT SOFTWARE VERSION YOU ARE RUNNING

- In SPIKE Prime, the version is at the top of all screens. You can also click on the gear icon on the top right of the home screen to access the Settings page.
- In Robot Inventor, click on Settings at the bottom of the home screen




SPIKE Prime




Robot Inventor

UPDATING THE HUB OPERATING SYSTEM

- If there is an Update for SPIKE Prime or Robot Inventor available, you will get a popup telling you to do so





SPIKE Prime



Robot Inventor


INSTALL LATEST HUB OS

- When a new Hub OS is available a button labeled Update will appear next to the current Hub OS in the Hub Dashboard
- You may also see a pop-up show up on the right side of the screen indicating a Hub OS update is available
- Never disconnect the Hub while the update is in progress




CHECKING WHAT HUB OS VERSION YOU ARE RUNNING

- To check what version of firmware you are running, you can click on the small Hub icon in either SPIKE Prime or Robot Inventor from inside a Project file
- This will take you to the Dashboard where you can see the firmware version on the top left.




SPIKE Prime




Robot Inventor

RENAMING THE HUB

- The first time you update your Hub OS, you will be prompted to rename your Hub
- After that you can rename your Hub by clicking on small the Hub icon in a Project and entering the Hub Dashboard
- In the SPIKE Prime or Robot Inventor Dashboard, click on the three dots on the top right and rename your Hub



SPIKE Prime



Robot Inventor

CREDITS

- This lesson was created by Sanjay Seshan and Arvind Seshan for Prime Lessons
- More lessons are available at www.primelessons.org



This work is licensed under a [Creative Commons Attribution-NonCommercial-ShareAlike 4.0 International License](https://creativecommons.org/licenses/by-nc-sa/4.0/).