

/direct

Parameter:

motor_l	integer -10 ... 10	required
motor_r	integer -10 ... 10	required
user	email	required

Info: For direct motor control, enable remote control has to be called first

/toggle-remote-control

Parameter:

status	enabled / disabled	required
user	email	required

Info: Enable / Disable remote control

/add-order

Parameter:

location	ex. Morty	required
user	email	required
priority	True / False	not required

Info: Add Order to que

/cancel-order

Parameter:

user	email	required
------	-------	----------

Info: Cancel open order

/confirm-delivery

Parameter:

user	email	required
------	-------	----------

Info: Mark your order as delivered

/get-orders

Parameter: None

Info: Get all open orders as JSON