
A Getting Started to

AURIXTM TC3xx - Free Entry Tool Chain

AURIX family and AUDO Future, AUDO MAX

Integrated Development Environment for 32-bit AURIX and TriCore derivatives



© **PLS / HighTec** 1991-2019 V 5.00.03.06

This manual contains 42 pages.

Contact us at:

E-Mail: tctcsupport@pls-mc.com

HighTec EDV Systeme GmbH

Europaallee 19

D - 66113 Saarbrücken

Germany

Phone: +49 681 92613 - 0

Fax: +49 681 92613 - 26

PLS Programmierbare Logik & Systeme GmbH

Technologiepark Lauta

D - 02991 Lauta

Germany

Phone: + 49 35722 384 - 0

Fax: + 49 35722 384 - 69

PLS Development Tools

19925 Stevens Creek Blvd

Cupertino, CA 95014

USA

+ 1 408 451 - 8408

+ 1 408 501 - 8808

Toll Free: + 1 877 - 77DEBUG

All rights reserved. No part of this manual may be reproduced or may be transmitted in any form or by any means without prior written permission of PLS Programmierbare Logik & Systeme GmbH (PLS). The information in this manual is subject to change without notice, no responsibility is assumed for its use.

Universal Debug Engine is a trademark of PLS Programmierbare Logik & Systeme GmbH. Adobe® is a registered trademark of Adobe Systems Incorporated. AURIX™, TriCore™ are trademarks of Infineon AG. Windows®7, Windows®8, Windows®10 are trademarks of Microsoft Corporation. Pentium® and Core™ are trademarks of Intel Corporation. XScale®, Celeron® are registered trademarks of Intel Corporation. Athlon™ is a trademark of Advanced Micro Devices, Inc. SuperH™ is a trademark of Renesas Technology Corporation.

All other names and trademarks are the property of their respective owners.

Contents

Contents	3
Introduction	5
Installing the AURIX TC3xx - Free Entry Tool Chain	6
Before you start	6
System Requirements	6
Installation	7
First Starting of HighTec IDE	11
Starting HighTec IDE	11
Content Manager	12
HighTec IDE Documentation	12
Create an AURIX/TriCore Project	13
C/C++ Project wizard	13
Set the HighTec C/C++ perspective	13
Import a sample Project	13
Start with an empty Project	15
Build the Project	15
Connecting the Target	17
TriBoard with mounted TC38xA, TC39xA, TC39xB processor	17
Application Kit AURIX TC387, TC397 TFT with TC38xA, TC397A, TC397A (ADAS), TC397B	18
TriBoard with mounted TC2D5T, TC21xA, TC22xA, TC23xA, TC26xA, TC26xB, TC27xA, TC27xB, TC27xC, TC27xD, TC29xA, TC29xB processor	19
Application Kit AURIX TC2X4 TFT with TC224, TC234 (TLF35584A, TLF35584B, TLF35584C)	20
Application Kit AURIX TC2X5 TFT with TC265B, TC275A, TC275B, TC275C	21
Application Kit AURIX TC2X7 TFT with TC237, TC267B, TC277C, TC277D, TC297B	22
ShieldBuddy TC275C, TC275D	23
phyCORE-TC29xB with baseboard	24
phyCORE-TC39xB with baseboard	25
TriBoard with mounted TC1767 processor	26
TriBoard with mounted TC1797 processor	27
TriBoard with mounted TC1782 processor	28
TriBoard with mounted TC1724 processor	29
TriBoard with mounted TC1791 processor	30
TriBoard with mounted TC1793 processor	31
TriBoard with mounted TC1798 processor	32
phyCORE-TC1793 with baseboard	33

Debugging your Application	34
Start a Debug Session	34
Stepping through the Application	38
Using the UDE debugger	39
End the Debug Session	39
Summary	40
Index	41

Introduction

This **Getting Started** document will help you to install and configure the Hardware and Software tools necessary to operate the Free TriCore Entry Tool Chain. At the end of the instructions described in this document, you will have a running environment that could be used as a starting point for further development or evaluation work.

This tutorial goes step-by-step through the necessary procedures in order to:

- Install the **Free TriCore™ Entry Tool Chain**
- Set up a project
- Configure the Evaluation Board and connect it to the PC
- Debug your application



If you need more information, please contact your nearest Infineon sales office. Contact information is available on Infineon web site: **www.infineon.com**.

We wish you a lot of success with the Free TriCore Entry Tool Chain!

Note: "Starter Kit Evaluation Board", "Evaluation Board", "TriBoard" and "Target" terminology are used to denote Evaluation Boards as shown in Figure 17 to Figure 31.

Installing the AURIX TC3xx - Free Entry Tool Chain

Before you start

To execute this **Getting Started**, it is necessary to have a

- Microsoft Windows® compatible PC equipped with USB port
- Operating System Windows® 7, Windows® 8.1, Windows® 10 (32-bit/64-bit)
- **Power user's** or **administrator rights** are mandatory to install the required programs
- **During installation a connection to the internet is required for license activation**

All the items below are included in the Starter Kit.

- Power Supply (AC/DC converter) (5.5V – 60V) for the Starter Kit Board (optional)
- TriCore Family Starter Kit Evaluation Board
- Free TriCore Entry Tool Chain installation package
- USB cable.

System Requirements

Before installing, make sure the following minimum system requirements are met:

- 2,5 GHz or faster 32-bit (x86) or 64-bit (x64) processor
- 4 GByte RAM (32-bit) or 8 GByte RAM (64-bit)
- 3 GByte available hard disk space
- Microsoft .NET™ Framework 4
- Microsoft Windows® Scripting Host V5.6
- Microsoft Internet Explorer® 10 or higher
- Java Runtime Environment v8 (32-bit version)
- Adobe® Acrobat Reader 10.0 or higher.

Installation

1. From the installation package run the installer setup.exe. **Free TriCore Entry Tool Chain** dialog appears (Figure 8).



Figure 1 Free TriCore Entry Tool Chain Setup dialog

2. Select **Next** button. The License Agreement dialog appears. Please read carefully and agree or cancel the installation with Cancel button (Figure 8).




Figure 2 License Agreement dialog

3. Click **Next** button. It is recommended to choose the full installation with all components (Figure 3).




Figure 3 Setup Type selection

4. Click **Next** button. The dialog for selecting the installation directory appears (Figure 4). Use the default or select another installation directory.




Figure 4 Free TriCore Entry Tool Chain Setup folder dialog

5. Click **Next** button. Select the name of the Program Group and




Figure 5 Set Program Group

6. Click **Next** button. (Figure 6)




Figure 6 Ready to Install dialog

7. Click **Next**. Further dialogs inform you about the progress of installation.

Please note: For commercial development you need the **full version of TriCore Development Platform**.



The **Free TriCore Entry Tool Chain** cannot be used together with professional versions of the containing products because they are incompatible. That's why, it is not possible to use a parallel installation of the **Free TriCore Entry Tool Chain** together with a **professional version UDE 5.0**.




Figure 7 Installation Complete

Note: The Free TriCore Entry Tool Chain license is valid for at least one year. There are following restrictions in comparison to the professional version:



Useable for TriCore evaluation boards with on-board wiggler only, PCP assembler only, Debugger: No visualization functions at runtime, no MCDS support, no Script support, no GTM support.

Please contact **tctcsupport@pls-mc.com** for extending the license.

First Starting of HighTec IDE

Starting HighTec IDE

1. From the Windows' **Start** menu, select **All Programs – AURIX(TM) TC3xx - Free Entry Tool Chain v4.9.3.0-infineon-1.0 – HighTec IDE** or use the Desktop icon **HighTec IDE**.
2. Now the Eclipse Launcher dialog appears (Figure 8).




Figure 8 Workspace Launcher

3. Enter the path to the workspace directory e.g. `D:\Workspace\htc-workspace`. If the directory doesn't exist, new directory will be created; otherwise existing directory will be used as eclipse workspace. New created projects will be saved in the selected workspace directory.
4. You can enable the option **Use this as the default and do not ask again**. By next start last used workspace will be used, skipping the **Eclipse Launcher** dialog. If you want to use other or new workspace. Select from the **File** menu **Switch Workspace**.
5. Click **OK** to proceed.

The **Welcome view** appears. Initially, the HighTec IDE opens with a workbench displaying the C/C++ perspective with only the Welcome view visible. This view provides some general information and alternative ways to access the online documentation.

HighTec IDE opens with the perspective which was last used before closing, except when starting up for the very first time showing the Welcome view. Click **Get to work** to close the Welcome Screen.

6. Click the **Get to Work** on the left side of the view to go to the workbench. Assuming first start of eclipse, **HighTec perspective** (Figure 9) appears, otherwise last saved workbench layout.




Figure 9 HighTec IDE perspective

Content Manager

The HighTec Content Manager provides easy access to the HighTec's resource cloud repository. You find there project examples, templates and other documents that help you to get up to the speed quickly. You can open the HighTec Content Manager as the separated window from the menu **Help – HighTec Content Manager**.

HighTec IDE Documentation

The documentation about the HighTec IDE is available in the Eclipse menu **Help – Help Content**.

Create an AURIX/TriCore Project

C/C++ Project wizard

This tutorial shows how to create an embedded software project with the AURIX/TriCore toolset. It lets you create your own project with an example of an analogue clock on the display of the AURIX application kit.

Set the HighTec C/C++ perspective

Before creating an AURIX/TriCore project, it is necessary to have the **HighTec C/C++** perspective on the workbench (Figure 10). By default, this should be the case when you start HighTec Development Platform, but if it is not, do the following.

To open the **HighTec C/C++** perspective

1. From the **Window** menu select **Open Perspective - Other... - HighTec**. The name of the perspective is displayed in the title bar of the workbench window.

Import a sample Project

1. From the **File** menu select **New - Example** (Figure 10). The New Example wizard appears (Figure 11).




Figure 10 Menu File / New / Example

2. Select **HighTec Examples** and press **Next**.




Figure 11 New Example Wizard

3. The next wizard page (Figure 12) shows a selection tree containing the TriCore boards supported by the toolchain. Expand the sample node e.g. **TimeDemo** and select **TriBoard TC26x A-Step**. Press **Next**.




Figure 12 Examples – Hardware Selection

4. Click **Finish** to finish the wizard and to import the example. Figure 13 shows HighTec perspective with the new created project. To see the generated project files you may need to expand the hello project structure on the left pane. To open one generated file double-click the file in the **src folder** of the project structure.






Figure 13 HighTec C/C++ Perspective with the new imported example

Start with an empty Project

To start from an empty project following the steps from the previous section Import a sample project and simply remove all header files from the `h` folder and the file `timer.c` from the `src` folder and delete the content of the file `timedemo.c` except an empty `main()` function.

Build the Project

When you build an AURIX/TriCore C/C++ project in HighTec Development Environment, the HighTec TriCore compiler, assembler and linker are used to compile and link all the source code and the libraries associated with the project.

The wizard generates different build targets like **iROM** (default). You can choose a build configuration by clicking the arrow of the build icon  and build a target by clicking the build icon .

Meaning of build targets

- iROM Code will be located in the internal flash (default)

During the build process the sources belonging to the project will be compiled and linked. The messages occurring during the build process are displayed in the **Console window** (Figure 14). The build process should terminate without giving any errors or warnings.




Figure 14 HighTec C/C++ Perspective: Build button and Console window

Connecting the Target

TriBoard with mounted TC38xA, TC39xA, TC39xB processor

1. Configure the DIP switches (1,2,3=OFF 4=ON but for A step (!) 1=ON 2,3,4=OFF)
2. Connect a DC power supply (5.5V – 60V) to the TriBoard.
3. Connect the TriBoard to the PC via a USB cable (a cable is supplied with the Starter Kit).
4. Three Power Supply PS-LEDs should be on.
5. Press the **Reset button** (see picture below)






Figure 15 AURIX – TriBoard

Application Kit AURIX TC387, TC397 TFT with TC38xA, TC397A, TC397A (ADAS), TC397B

1. Connect a DC power supply (5.5V – 60V) to the Application Kit.
2. Connect the Application Kit TC397 to the PC via a USB cable (a cable is supplied with the Starter Kit).
3. The Power Supply LED should be on.
4. Press the **Reset button** (see picture below)



Back side



Top side

Figure 16 AURIX Application Kit TC397 TFT

TriBoard with mounted TC2D5T, TC21xA, TC22xA, TC23xA, TC26xA, TC26xB, TC27xA, TC27xB, TC27xC, TC27xD, TC29xA, TC29xB processor

1. Configure the DIP switches (1,2,3=OFF 4=ON but for A step (!) 1=ON 2,3,4=OFF)
2. Connect a DC power supply (5.5V – 60V) to the TriBoard.
3. Connect the TriBoard to the PC via a USB cable (a cable is supplied with the Starter Kit).
4. Three Power Supply PS-LEDs should be on.
5. Press the **Reset button** (see picture below)






Figure 17 AURIX – TriBoard

Application Kit AURIX TC2X4 TFT with TC224, TC234 (TLF35584A, TLF35584B, TLF35584C)

1. Connect a DC power supply (5.5V – 60V) to the Application Kit.
2. Connect the Application Kit TC2X4 to the PC via a USB cable (a cable is supplied with the Starter Kit).
3. The Power Supply LED should be on.
4. Press the **Reset button** (see picture below)



Back side




Top side


Figure 18 AURIX Application Kit TC2X4 TFT

Application Kit AURIX TC2X5 TFT with TC265B, TC275A, TC275B, TC275C

1. Connect a DC power supply (5.5V – 60V) to the Application Kit.
2. Connect the Application Kit TC2X5 to the PC via a USB cable (a cable is supplied with the Starter Kit).
3. The Power Supply LED should be on.
4. Press the **Reset** button (see picture below)



Back side




Top side


Figure 19 AURIX Application Kit TC2X5

Application Kit AURIX TC2X7 TFT with TC237, TC267B, TC277C, TC277D, TC297B

1. Connect a DC power supply (5.5V – 60V) to the Application Kit.
2. Connect the Application Kit TC2X7 to the PC via a USB cable (a cable is supplied with the Starter Kit).
3. The Power Supply LED should be on.
4. Press the **Reset button** (see picture below)



Back side



Top side

Figure 20 AURIX Application Kit TC2X7

ShieldBuddy TC275C, TC275D

1. Configure the Power Supply Jumper to VUSB.
2. Connect the ShieldBuddy to the PC via a USB cable (a cable is supplied with the Starter Kit).
3. Three Power Supply LEDs should be on.
4. Press the **Reset button** (see picture below).




Figure 21 ShieldBuddyTC275

phyCORE-TC29xB with baseboard

1. Connect a DC power supply (5.5V – 60V) to the baseboard
2. Connect the baseboard to the PC via a USB cable (a cable is supplied with the Starter Kit).
3. The Power Supply LED should be on.
4. Press the **Reset button** (see picture below).




Figure 22 phyCORE – TC29xB with baseboard

phyCORE-TC39xB with baseboard

1. Connect a DC power supply (5.5V – 60V) to the baseboard
2. Connect the baseboard to the PC via a USB cable (a cable is supplied with the Starter Kit).
3. The Power Supply LED should be on.
4. Press the **Reset button** (see picture below).




Figure 23 phyCORE – TC39xB with baseboard

TriBoard with mounted TC1767 processor

5. Configure the DIP switches (default all OFF - boot from internal flash)
6. Connect a DC power supply (5.5V – 60V) to the TriBoard.
7. Connect the TriBoard to the PC via a USB cable (a cable is supplied with the Starter Kit).
8. Three Power Supply PS-LEDs should be on.
9. Press the **Reset button** (see picture below).




Figure 24 TC1767 - TriBoard

TriBoard with mounted TC1797 processor

1. Configure the DIP switches (default all OFF - boot from internal flash)
2. Connect a DC power supply (5.5V – 60V) to the TriBoard.
3. Connect the TriBoard to the PC via a USB cable (a cable is supplied with the Starter Kit).
4. Three Power Supply PS-LEDs should be on.
5. Press the **Reset button** (see picture below).




Figure 25 TC1797 - TriBoard

TriBoard with mounted TC1782 processor

1. Configure the DIP switches (default all OFF - boot from internal flash)
2. Connect a DC power supply (5.5V – 60V) to the TriBoard.
3. Connect the TriBoard to the PC via a USB cable (a cable is supplied with the Starter Kit).
4. Three Power Supply PS-LEDs should be on.
5. Press the **Reset button** (see picture below).




Figure 26 TC1782 - TriBoard

TriBoard with mounted TC1724 processor

1. Configure the DIP switches (default all OFF - boot from internal flash)
2. Connect a DC power supply (5.5V – 60V) to the TriBoard.
3. Connect the TriBoard to the PC via a USB cable (a cable is supplied with the Starter Kit).
4. Three Power Supply PS-LEDs should be on.
5. Press the **Reset button** (see picture below).




Figure 27 TC1724 - TriBoard

TriBoard with mounted TC1791 processor

1. Configure the DIP switches (default all OFF - boot from internal flash)
2. Connect a DC power supply (5.5V – 60V) to the TriBoard.
3. Connect the TriBoard to the PC via a USB cable (a cable is supplied with the Starter Kit).
4. Three Power Supply PS-LEDs should be on.
5. Press the **Reset button** (see picture below).




Figure 28 TC1791 - TriBoard

TriBoard with mounted TC1793 processor

1. Configure the DIP switches (default all OFF - boot from internal flash)
2. Connect a DC power supply (5.5V – 60V) to the TriBoard.
3. Connect the TriBoard to the PC via a USB cable (a cable is supplied with the Starter Kit).
4. Three Power Supply PS-LEDs should be on.
5. Press the **Reset button** (see picture below).




Figure 29 TC1793 - TriBoard

TriBoard with mounted TC1798 processor

1. Configure the DIP switches (default all OFF - boot from internal flash)
2. Connect a DC power supply (5.5V – 60V) to the TriBoard.
3. Connect the TriBoard to the PC via a USB cable (a cable is supplied with the Starter Kit).
4. Three Power Supply PS-LEDs should be on.
5. Press the **Reset button** (see picture below).




Figure 30 TC1798 - TriBoard

phyCORE-TC1793 with baseboard

1. Connect a DC power supply (5.5V – 60V) to the baseboard
2. Connect the baseboard to the PC via a USB cable (a cable is supplied with the Starter Kit).
3. The Power Supply LED should be on.
4. Press the **Reset button** (see picture below).





Figure 31 phyCORE - TC1793 with baseboard

Debugging your Application

Start a Debug Session

1. Click at the debug button  and select **Debug Configurations ...** (Figure 32).




Figure 32 Select Debug Configurations dialog via Debug button

2. The **Debug Configurations** dialog appears. Select **Universal Debug Engine** as debug type (Figure 33).




Figure 33 Debug Configurations dialog

3. Press the **New launch configuration** button to create a new debug launch configuration for Universal Debug Engine (Figure 34).




Figure 34 Create new debug launch configuration for Universal Debug Engine

4. A new debug configuration **TimeDemo_ApplicationKitTC224(TLF35584A-Step) iRom** is created. All input fields are pre-filled with appropriate values (Figure 35).





Figure 35 Create new debug launch configuration for Universal Debug Engine

5. Push **Debug** to start UDE perspective. Later you can use the Debug icon  from the menu.

Note: If a **problem occurred** pop-up window appears, click **OK**, check the USB cable connection, reset the board with the reset button, and start again the Debug session

6. If you built an **iROM** version of your application, the **UDE Memory Programming Tool** will appear after launching the **UDE perspective** (Figure 36).




Figure 36 UDE Memory Programming Tool

7. Start flashing with the **Program** button. A progress dialog appears (Figure 37). After successful programming close both dialogs.





Figure 37 FLASH programming progress dialog

From the **Debug** menu, select **Step over subroutine**, or click on the **Step over** button  in the toolbar. At this moment your application is executing but stopped on the function `main()`. This means the C startup code has been executed completely. The Editor view shows the C source files of your application and a yellow arrow shows the line where the execution has stopped (Figure 38).







Figure 38 First step to `main()` function

Stepping through the Application

1. From the **Debug** menu select **Step over subroutine** or click on the **Step over** button  in the toolbar. The yellow arrow in the Program view moves to the next statement.
2. To set or clear breakpoints click on the markers in the info margin of program window.
3. To see watch or local variables please open the accordingly window via the **View** menu.
4. To run your application, select **Start Program Execution** from the **Debug** menu or click on the Start Program button  in the toolbar. **Now an analogue clock should be visible on the display of the application kit.**
5. To restart your application, select **Restart Program Execution** from the **Debug** menu, or press **F7** or click on the Restart button  in the toolbar.

Using the UDE debugger

The main() and further features of UDE are described in the UDE Manual, available via **UDE Welcome Page**. Open it via menu **Window - Show View - Other ... - Universal Debug Engine - UDE Welcome Page** and push the **UDE Manual** button.

Figure 39 shows an UDE example configuration with Peripheral Registers, Call stack, Watch window, and Memory window. All features are described in the **UDE Manual**.




Figure 39 Universal Debug Engine perspective

End the Debug Session

From the **File** menu select **Close Workspace** or click on the Close Workspace button in the toolbar. The current perspective is switched back to the HighTec C/C++ perspective.

Summary

Having followed the step-by-step instructions the development environment comprising AURIX TC3xx Free Entry Tool Chain and AURIX/TriCore Family Evaluation Board will have now been installed. After creating and compiling a simple program, it is successfully executed on the Evaluation Board.

You now have a running environment that could be used for further development or evaluation work.

Index

A

- Access rights 6
- Application Kit TC2X4 TFT 20
- Application Kit TC2X7 TFT 22
- Application Kit TC38XA TFT 18
- Application Kit TC397 TFT 18
- Application Kit TC397B TFT 18
- AURIX TriBoard 17, 19

B

- Breakpoint 38
- Build 15

C

- C Source File 38
- C/C++ perspective 12
- C/C++ Perspective 11, 13
- Close Workspace 39
- Console window 16

D

- Debug Configuration 35
- Debug Launch Configuration 35
- Debugging 34
- DIP Switch 17, 19, 26, 27, 28, 29, 30, 31, 32

E

- Eclipse 11
- Editor view 38
- Evaluation Board 5
- Example 13

F

- FLASH programming 37
- FLASH Programming 36
- Free TriCore Entry Tool Chain 5

H

- Hardware selection 14

I

- Infineon 5
- Installing 6
- iROM 16

J

- Java 32-bit 6

L

- Launcher 11
- License Agreement 7
- Limitations 10

M

- main() 15, 38, 39
- MCDS 10
- Memory Programming Tool 36

O

- On-board Wiggler 10
- Operating System 6

P

- PCP 10
- Perspective 11, 12
- phyCORE-TC1793 with baseboard 33
- phyCORE-TC29xB with baseboard 24
- phyCORE-TC39xB with baseboard 25
- Power Supply 6, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33
- Problem 36
- Program view 38
- Project 13, 15
- Project Wizard 13

R

- Reset Button 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33
- Restart 38
- Restrictions 10

S

- Scripting Support 10
- ShieldBuddyTC275 23
- Starter Kit 5
- Stepping 38

T

- Target 5
- TC1724 TriBoard 29
- TC1767 TriBoard 26
- TC1782 TriBoard 28
- TC1791 TriBoard 30
- TC1793 phyCORE 33
- TC1793 TriBoard 31
- TC1797 TriBoard 27
- TC1798 TriBoard 32
- TC224 TFT 20
- TC234 TFT 20
- TC237 TFT 22
- TC265 TFT 21
- TC267 TFT 22
- TC275 ShieldBuddy 23
- TC275 TFT 21
- TC277 TFT 22
- TC297 TFT 22
- TC29xB phyCORE 24
- TC2X4 Application Kit TFT 20
- TC2X5 Application Kit TFT 21
- TC2X7 TFT 22
- TC2XX TriBoard 19

TC38X TriBoard 17
TC397A TFT 18
TC397ADAS TFT 18
TC39X TriBoard 17
TC39xB phyCORE 25
TriBoard 5
TriBoard AURIX 17, 19

U

UDE 36
UDE Manual 39
USB 6

W

Windows 6
Workspace launcher 11

Y

Yellow Arrow 38