

BRAKE SYSTEM

SECTION **BR**

CONTENTS

PRECAUTIONS AND PREPARATION	BR- 2
CHECK AND ADJUSTMENT	BR- 3
BRAKE HYDRAULIC LINE	BR- 4
BRAKE PEDAL AND BRACKET	BR- 7
BRAKE BOOSTER	BR- 9
VACUUM PIPING	BR-10
MASTER CYLINDER	BR-12
LOAD SENSING VALVE	BR-13
FRONT DISC BRAKE (CL28VA and CL28VD) – Caliper	BR-16
FRONT DISC BRAKE (CL28VA and CL28VD) – Rotor	BR-20
REAR DRUM BRAKE (DS22, DS25B, DS25C and LT26B)	BR-21
REAR DISC BRAKE (AD14VB) – Caliper	BR-26
REAR DISC BRAKE (AD14VB) – Rotor	BR-30
PARKING BRAKE CONTROL	BR-31
PARKING DRUM BRAKE (DS19HB) – Rear Disc Brake (AD14VB) Model	BR-34
SERVICE DATA AND SPECIFICATIONS (S.D.S.)	BR-36


PRECAUTIONS AND PREPARATION

Precautions

- Recommended fluid is brake fluid "DOT 3".
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted areas.
- To clean or wash all parts of master cylinder, disc brake caliper and wheel cylinder, use clean brake fluid.
- Never use mineral oils such as gasoline or kerosene. They will ruin the rubber parts of the hydraulic system.

WARNING:


- Clean pad and shoe dust using a dust collector after cleaning with waste cloth.




- Use Tool when removing and installing brake tube.

Preparation

SPECIAL SERVICE TOOL


Tool number (Kent-Moore No.) Tool name	Description
GG94310000 (-) Flare nut torque wrench	 Removing and installing each brake piping

CHECK AND ADJUSTMENT




Checking Brake Fluid Level

- Check fluid level in reservoir tank. It should be between Max. and Min. lines on reservoir tank.
- If fluid level is extremely low, check brake system for leaks.



Checking Brake System

- Check brake lines (tubes and hoses) for evidence of cracks, deterioration or other damage. Replace any damaged parts. If leakage occurs around joints, retighten or, if necessary, replace damaged parts.
- Be sure to check for oil leakage by fully depressing brake pedal.




Changing Brake Fluid


1. Drain brake fluid in each air bleeder valve.
 2. Refill until new brake fluid comes out of each air bleeder valve.
- Use same procedure as in bleeding hydraulic system to refill brake fluid.
Refer to Bleeding Procedure of BRAKE HYDRAULIC LINE.
- Refill with recommended brake fluid "DOT 3".
 - Never reuse drained brake fluid.
 - Be careful not to splash brake fluid on painted areas.

BRAKE HYDRAULIC LINE

Model equipped with proportioning valve



Model equipped with L.S.V. (A-type)




Primary line
Secondary line
: N·m (kg·m, ft·lb)

SBR344A


BRAKE HYDRAULIC LINE

Model equipped with L.S.V. (B-type)



SBR169A

BRAKE HYDRAULIC LINE




Bleeding Procedure

Model not equipped with L.S.V.


- Bleed air according to the following procedure:
Left rear wheel cylinder → Right rear wheel cylinder → Left front caliper → Right front caliper

Model equipped with L.S.V.

- Bleed air according to the following procedure:
L.S.V. air bleeder → Left rear wheel cylinder → Right rear wheel cylinder → Left front caliper → Right front caliper



- Connect a transparent vinyl tube to air bleeder valve of L.S.V., caliper or wheel cylinder.
- Carefully monitor brake fluid level at master cylinder during bleeding operation.
- Tighten air bleeder to the specified torque.



Removal and Installation

CAUTION:

- a. Use Tool when removing and installing brake tube.

- b. Cover openings to prevent entrance of dirt whenever disconnecting hydraulic line.

- To remove brake hose, first remove flare nut securing brake tube to hose, then withdraw lock spring. Next disconnect the other side.
- All hoses must be free from excessive bending, twisting and pulling.
- After installing brake lines, be sure to check for oil leakage by fully depressing brake pedal.


Inspection

Check brake lines (tubes and hoses) for evidence of cracks, deterioration or other damage. Replace any damaged parts.

If leakage occurs around joints, retighten or, if necessary, replace damaged parts.

BRAKE PEDAL AND BRACKET

Removal and Installation





Inspection

Check brake pedal for the following items.

- Brake pedal bend
- Clevis pin deformation
- Crack of any welded portion

BRAKE PEDAL AND BRACKET



Adjustment

Check brake pedal free height from melt sheet. Adjust if necessary.

H: Free height

Refer to S.D.S.

D: Depressed height

Refer to S.D.S.

Under force of 490 N (50 kg, 110 lb) with engine running

C₁: Clearance between pedal stopper and threaded end of stop lamp switch

0.3 - 1.0 mm (0.012 - 0.039 in)

C₂: Clearance between pedal stopper and threaded end of A.S.C.D. switch

0.3 - 1.0 mm (0.012 - 0.039 in)

A: Pedal free play

1 - 3 mm (0.04 - 0.12 in)

1. Adjust pedal free height with brake booster input rod. Then tighten lock nut.

Make sure that the tip of input rod stays inside.



2. Adjust clearance "C₁" and "C₂" with stop lamp switch and A.S.C.D. switch respectively. Then tighten lock nuts.
3. Check pedal free play.

Make sure that stop lamp is off when pedal is released.

4. Check brake pedal depressed height with engine running. If depressed height is below the specified value, check brake system for leaks, accumulation of air or any damage components such as master cylinder, wheel cylinder, etc. Make the necessary repairs, if necessary.

BRAKE BOOSTER

Removal and Installation



Inspection

OPERATING CHECK

- Depress brake pedal several times with engine off, then check that there is no change in pedal stroke.
- Depress brake pedal, then start engine. If pedal goes down slightly, operation is normal.

AIRTIGHT CHECK


- Start engine, then stop it in one or two minutes. Depress brake pedal several times slowly. If pedal goes further down the first time and gradually rises after second or third time, the booster is airtight.
- Depress brake pedal while engine is running, then stop engine with pedal depressed. If there is no change in pedal stroke for thirty seconds, brake booster is airtight.

OUTPUT ROD LENGTH CHECK

1. Supply brake booster with vacuum of -66.7 kPa (-500 mmHg, -19.69 inHg) using a handy vacuum pump.
2. Check output rod length.

Specified length:

10.275 - 10.525 mm (0.4045 - 0.4144 in)




VACUUM PIPING


Removal and Installation

Gasoline engine models

(4 way type)



(2 way type)




CAUTION:

Do not apply any oil or lubricants to vacuum hose and check valve.

SBR496A


- Insert vacuum tube into vacuum hose more than 24 mm (0.94 in).



More than 24 mm (0.94 in)

SBR004A

4 way type




Brake
booster
side

Intake manifold or
vacuum pump side

SBR134A

- Install check valve properly paying attention to its direction.

2 way type




Brake
booster
side

Intake manifold
side

SBR277A


VACUUM PIPING



Inspection

HOSES AND CONNECTORS



- Check condition of vacuum hoses and connectors.
- Check vacuum hoses for air tightness.




CHECK VALVE

- If valve does not open, replace check valve with a new one when pressure is applied to the brake booster side of check valve.

MASTER CYLINDER




- Replace stopper if the claw is damaged or deformed.
- Bend claws inside when installing stopper.



- Replace piston assembly when disassembled.
- Pay attention to the direction of piston cups.
- Check parts for wear or damage. Replace if any of the above conditions are observed.


LOAD SENSING VALVE

Load Sensing Valve (A-type)



SBR122A


- Do not reuse Load Sensing Valve once it is disassembled.
- Replace damaged Load Sensing Valve as an assembly.



- When installing Load Sensing Valve to bracket, secure it to area above oblong hole.

LOAD SENSING VALVE



Load Sensing Valve (B-type)



SBR123A

- Do not reuse Load Sensing Valve once it is disassembled.
- Replace damaged Load Sensing Valve as an assembly.
- When disassembling, apply multi-purpose grease to all rubbing areas.

LOAD SENSING VALVE



Inspection (L.S.V. B-type)

1. Set weight slowly on axle center.
Weight: 100 kg (221 lb)
2. Install pressure gauge to front and rear brake.

3. Raise front brake pressure to 4,904 kPa (50 kg/cm², 711 psi) and check rear brake pressure.

Rear brake pressure:

2,256 - 3,236 kPa

(23 - 33 kg/cm², 327 - 469 psi)


4. Raise front brake pressure to 9,807 kPa (100 kg/cm², 1,422 psi) and check rear brake pressure.

Rear brake pressure:

3,138 - 4,511 kPa

(32 - 46 kg/cm², 455 - 654 psi)


If rear brake pressure is not within specification, adjust bracket as follows:



5. Adjust bracket to direction of L when rear brake pressure is above specification.
 6. Adjust bracket to direction of R when rear brake pressure is below specification.
- Repeat steps (3) and (4) until rear brake pressure is within specification.


FRONT DISC BRAKE (CL28VA and CL28VD) — Caliper

CL28VA




SBR272A

CL28VD




SBR273A

FRONT DISC BRAKE (CL28VA and CL28VD) — Caliper



Pad Replacement


1. Remove pin bolt.



2. Swing cylinder body upward. Then remove pad retainers, and inner and outer shims.


CAUTION:

- When cylinder body is swung up, do not depress brake pedal because piston will pop out.
- Be careful not to damage dust cover or get oil on rotor. Always replace shims when replacing pads.




Removal and Installation

- Remove torque member fixing bolts and union bolt.



- Install brake hose to caliper securely.


FRONT DISC BRAKE (CL28VA and CL28VD) — Caliper



Disassembly

Push out piston with dust cover with compressed air.


For CL28VD (2-piston type), use a wooden block so that the 2 pistons come out evenly.



Inspection

INSPECTION OF BRAKE DRAG FORCE


- (1) Swing cylinder body upward.
- (2) Make sure that wheel bearing is adjusted properly. Refer to section FA.
- (3) Measure rotating force (F_1).



- (4) Install caliper with pads to the original position.
- (5) Depress brake pedal for 5 seconds.
- (6) Release brake pedal, rotate disc rotor 10 revolutions.
- (7) Measure rotating force (F_2).
- (8) Calculate brake drag force by subtracting F_1 from F_2 .


Maximum brake drag force ($F_2 - F_1$):

103.0 N (10.5 kg, 23.2 lb)



If it is not within specification, check pins and pin boots in caliper.

- Make sure that wheel bearing is adjusted properly.
- Disc pads and disc rotor must be dried.



DISC PAD

Check disc pad for wear or damage.

Pad wear limit (A):

2.0 mm (0.079 in)

FRONT DISC BRAKE (CL28VA and CL28VD) — Caliper

Inspection (Cont'd)

CYLINDER BODY

- Check inside surface of cylinder for score, rust, wear, damage or presence of foreign materials. If any of the above conditions are observed, replace cylinder body.
- Minor damage from rust or foreign materials may be eliminated by polishing the surface with a fine emery paper. Replace cylinder body if necessary.

CAUTION:

Use brake fluid to clean. Never use mineral oil.

PISTON



Check piston for score, rust, wear, damage or presence of foreign materials. Replace if any of the above conditions are observed.

CAUTION:

Piston sliding surface is plated. Do not polish with emery paper even if rust or foreign materials are stuck to sliding surface.

PIN, PIN BOLT AND PIN BOOT

Check for wear, cracks or other damage. Replace if any of the above conditions are observed.



Assembly

- Insert piston seal into groove on cylinder body.
- With dust seal fitted to piston, install piston into cylinder body.

CAUTION:


- Secure dust seal properly.

FRONT DISC BRAKE (CL28VA and CL28VD) — Rotor

Inspection

RUBBING SURFACE

Check rotor for roughness, cracks or chips.



RUNOUT


Make sure that axial end play is within the specifications before measuring. Refer to section FA.

Rotor repair limit:

Maximum runout

(Total indicator reading at center of rotor pad contact surface)

0.07 mm (0.0028 in)




THICKNESS

Rotor repair limit:


Minimum thickness

CL28VA 20.0 mm (0.787 in)

CL28VD 24.0 mm (0.945 in)





SBR091A




SBR092A

REAR DRUM BRAKE (DS22, DS25B, DS25C and LT26B)



Brake Drum Removal

- Release parking brake control lever fully.
- Tighten two bolts gradually if brake drum is hard to remove.



Shoe Replacement

- Measure lining thickness.

Lining wear limit (A):

1.5 mm (0.059 in)



Before installing new shoes, rotate nut until adjuster rod is at its shortest point.

After installation is completed, adjust shoe-to-drum clearance. Refer to Removal and Installation of Adjuster.

REAR DRUM BRAKE (DS22, DS25B, DS25C and LT26B)

Wheel Cylinder Inspection

Check parts for score, wear or damage. Replace if any of the above conditions are observed.



Removal and Installation of Adjuster

When installing, measure inner diameter of the drum and adjust so that shoe outer diameter at its center is smaller than drum inner diameter by 0.25 to 0.4 mm (0.0098 to 0.0157 in) by rotating the adjuster. Then operate parking brake lever to adjust shoe clearance.

Drum Inspection

Standard inner diameter:

DS22	220.0 mm (8.66 in)
DS25B, DS25C	254.0 mm (10.00 in)
LT26B	260.0 mm (10.24 in)

Maximum inner diameter:

DS22	221.5 mm (8.72 in)
DS25B, DS25C	255.5 mm (10.06 in)
LT26B	261.5 mm (10.30 in)

Out-of-roundness (ellipticity):


0.03 mm (0.0012 in) or less

Radial runout (Total indicator reading):

0.05 mm (0.0020 in) or less


- Contact surface should be finefinished with No. 120 to 150 emery paper.
- Using a drum racer, lathe brake drum if it shows score marks, partial wear or stepped wear.
- After brake drum has been completely reconditioned or replaced, check drum and shoes for proper contact pattern.

REAR DRUM BRAKE (DS22, DS25B, DS25C and LT26B)



Shoe Installation

- Place adjuster cable by pulling adjusting lever upward.





- Install return springs.

REAR DRUM BRAKE (DS22, DS25B, DS25C and LT26B)

Shoe Installation (Cont'd)



- Install all the parts by referring to the figure below.



DS25C model


- After installing crank lever on back plate, make sure that there is no play between crank lever and back plate when pulling crank lever. If play exists, adjust bolt **A** and lock nut **B**.

REAR DISC BRAKE (AD14VB) — Caliper



Pad Replacement

1. Remove guide pin.




2. Swing cylinder body upward. Then remove pad retainer and inner and outer shims.

CAUTION:


- When cylinder body is swung up, do not depress brake pedal because piston will pop out.
- Be careful not to damage dust seal or get oil on rotor. Always replace shims when replacing pads.

REAR DISC BRAKE (AD14VB) — Caliper




Removal and Installation


- Remove torque member fixing bolts and eye bolt.



- Install brake hose to caliper securely.




- Remove retainer with a screwdriver.



- Push out piston with dust seal with compressed air.


REAR DISC BRAKE (AD14VB) — Caliper



Inspection

INSPECTION OF BRAKE DRAG FORCE


- (1) Swing cylinder body upward.
- (2) Make sure that wheel bearing is adjusted properly. Refer to section RA.
- (3) Measure rotating force (F_1).



- (4) Install caliper with pads to the original position.
- (5) Depress brake pedal for 5 seconds.
- (6) Release brake pedal, rotate disc rotor 10 revolutions.
- (7) Measure rotating force (F_2).
- (8) Calculate brake drag force by subtracting F_1 from F_2 .


Maximum brake drag force ($F_2 - F_1$):

103.0 N (10.5 kg, 23.2 lb)



If it is not within specification, check pins and pin boots in caliper.

- Make sure that wheel bearing is adjusted properly.
- Disc pads and disc rotor must be dried.



DISC PAD

Check disc pad for wear or damage.

Pad wear limit (A):

2.0 mm (0.079 in)

CYLINDER BODY

- Check inside surface of cylinder body for score, rust, wear, damage or presence of foreign materials. If any of the above conditions are observed, replace cylinder body.
- Minor damage from rust or foreign materials may be eliminated by polishing surface with a fine emery paper. Replace cylinder body if necessary.

CAUTION:

Use brake fluid to clean. Never use mineral oil.

REAR DISC BRAKE (AD14VB) — Caliper

Inspection (Cont'd)

PISTON

Check piston for score, rust, wear, damage or presence of foreign materials. Replace if any of the above conditions are observed.

CAUTION:


Piston sliding surface is plated. Do not polish with emery paper even if rust or foreign materials are stuck to sliding surface.

PIN, PIN BOLT, RETAINER, PISTON SEAL, DUST SEAL AND PIN BOOT

Check for wear, cracks or other damage. Replace if any of the above conditions are observed.

Assembly

- With dust seal fitted to piston, insert dust seal into groove on cylinder body and install piston.
- Properly secure dust seal.




REAR DISC BRAKE (AD14VB) — Rotor

Inspection

RUBBING SURFACE

Check rotor for roughness, cracks or chips. Repair or replace if necessary.



RUNOUT

Make sure that axial end play is within the specifications before measuring. Refer to section RA.


Then check runout with a dial gauge.

Rotor repair limit

Maximum runout

(Total indicator reading at center of rotor pad contact surface)

0.07 mm (0.0028 in)



THICKNESS


Rotor repair limit:

Minimum thickness

9.0 mm (0.354 in)


PARKING BRAKE CONTROL

TRUCK-2WD




TRUCK-4WD

Stick lever type



Center lever type




: N·m (kg-m, ft-lb)

SBR100A

PARKING BRAKE CONTROL

VAN & WAGON



SBR380A

Removal and Installation

- Be careful not to damage cable.
- Make sure there is no free play after installation.

Inspection

1. Check control lever for wear or other damage. Replace if necessary.
2. Check wires for discontinuity or deterioration. Replace if necessary.
3. Check warning lamp and switch. Correct if necessary.
4. Check parts at each connecting portion and, if found deformed or damaged, replace.




Adjustment

Adjust control lever stroke as follows:

PARKING BRAKE CONTROL

Adjustment (Cont'd)

1. Loosen lock nut (A) , rotate adjuster (B) .
2. Tighten lock nut (A) .



3. Pull control lever with specified amount of force. Check lever stroke and ensure smooth operation.

Number of notches:

Truck

Center lever type	10 - 12
Stick lever type	10 - 12 (2WD) 9 - 11 (4WD)

Van & Wagon

Center lever type	7 - 9
-------------------	-------

4. Bend parking brake warning lamp switch plate so that brake warning light comes on when ratchet at parking brake lever is pulled "A" notches and goes out when fully released.

Number of notches "A":



Truck

Center lever type	1
Stick lever type	2

Van & Wagon


Center lever type	2
-------------------	---

PARKING DRUM BRAKE (DS19HB) — Rear Disc Brake (AD14VB) Model



Shoe Replacement

1. Remove disc rotor (With parking drum brake).
Tighten two bolts gradually if disc rotor is hard to remove.





2. After removing retainer, remove spring by rotating shoes.
Be careful not to damage parking brake cable when separating it.

PARKING DRUM BRAKE (DS19HB) — Rear Disc Brake (AD14VB) Model

Shoe Replacement (Cont'd)

3. Apply brake grease to the contact areas shown at left.



Shoe Clearance Adjustment


1. Remove adjuster hole plug, and turn down adjuster wheel with a screwdriver until shoe touches brake drum.

Make sure that parking control lever is released completely.

2. Return adjuster wheel 7 to 8 latches.
3. Install adjuster hole plug, and make sure that there is no drag between shoes and brake drum when rotating disc rotor.

Breaking in Drum and Lining

1. Set transfer lever in the "2H" position. Using either low or 2nd transmission speed, drive the unloaded vehicle at approximately 30 km/h (19 MPH) on a safe, level and dry road.
2. Depress the release button of parking brake lever, then pull the lever with a force of 98 N (10 kg, 22 lb).
3. While holding the lever back, continue to drive the vehicle 100 m (328 ft).
4. Repeat steps 1 through 3 two or three times.



Drum Inspection

Standard inner diameter:

190.0 mm (7.48 in)

Maximum inner diameter:

191.0 mm (7.52 in)

Out-of-roundness (ellipticity):

0.04 mm (0.0016 in)

Radial runout (Total indicator reading):

0.1 mm (0.004 in)

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

General Specifications

	Model	2WD				4WD	4WD and 2WD
	Engine	Z24i		VG30i		VG30i, Z24i	
	Grade	Except STD Regular Bed	STD Regular Bed	Except Heavy Duty Cab & Chassis	Heavy Duty	Truck	Van & Wagon
Front brake							
Brake model		CL28VA		CL28VD			
Pad dimensions Width x thickness x length mm (in)		IN 43 x 11 x 126.5 (1.69 x 0.43 x 4.98) OUT 43 x 11 x 129 (1.69 x 0.43 x 5.08)		48.5 x 10 x 146.6 (1.909 x 0.39 x 5.77)			
Rotor outer diameter mm (in)		250 (9.84)		260 (10.24)		277 (10.91)	
Cylinder inner diameter mm (in)		60.6 (2.386)		42.8 (1.685) x 2			
Rear brake							
Brake model		LT26B		DS25B	DS25C	LT26B AD14VB*4 DS19HB*4	
Cylinder inner diameter mm (in)		22.22 (7/8)		23.81 (15/16)	17.46 (11/16)		20.64 (13/16), 42.83 (1.6862) *4
Lining dimensions Width x thickness x length mm (in)		50 x 5.5 x 249.6 (1.97 x 0.217 x 9.83)		45 x 3.9 x 265.9 (1.77 x 0.154 x 10.47)	60 x 6 x 265.9 (2.36 x 0.24 x 10.47)	50 x 5.5 x 249.6 (1.97 x 0.217 x 9.83), 25.3 x 10 x 100.8 (0.996 x 0.39 x 3.97)*4, 30.0 x 3.0 x 182.3 (1.181 x 0.118 x 7.18)*4	
Drum inner diameter /Rotor outer diameter mm (in)		260 (10.24)		254 (10.00)		260 (10.24), 286 (11.26)*4, 190 (7.48)*4	
Master cylinder Inner diameter mm (in)		23.81 (15/16)		25.4 (1)	23.81 (15/16)		
Brake booster							
Model		M20T M195T	G23, M23	M195T, M20T			M195T M215T*4
Diaphragm diameter mm (in)		Pri 205 (8.07), 205 (8.07)*5 Sec 180 (7.09), 201 (7.91)*5	230 (9.06)	Pri 205 (8.07), 205 (8.07)*5 Sec 180 (7.09), 201 (7.91)*5			Pri 205 (8.07), 230 (9.06)*4 Sec 201 (7.91), 205 (8.07)*4
Control valve Type		P.V.*3		L.S.V.*1	L.S.V.*2	P.V.*3	
Split point x Reducing ratio kPa (kg/cm ² , psi) x ratio		2,452 (25, 356) x 0.1		(Variable) x 0.1	(Variable) x 0.23	1,961 (20, 284) x 0.1	2,942 (30, 427) x 0.2, 3,923 (40, 569) x 0.4*4

*1: Load sensing valve (A-type)

*2: Load sensing valve (B-type)

*3: Proportioning valve (within master cylinder)

*4: Option as sports package

DS19HB for parking brake

*5: Model M20T type

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Inspection and Adjustment

BRAKE PEDAL

Model	A/T	M/T
Free height "H" mm (in)	212 - 222 (8.35 - 8.74)	209 - 219 (8.23 - 8.62)
Depressed height "D" [Under force of 490 N (50 kg, 110 lb) with engine running] mm (in)	120 (4.72) or more	
Clearance between pedal stopper and threaded end of stop lamp switch "C ₁ " mm (in)	0.3 - 1.0 (0.012 - 0.039)	
Clearance between pedal stopper and threaded end of A.S.C.D. switch "C ₂ " mm (in)	0.3 - 1.0 (0.012 - 0.039)	
Pedal free play "A" mm (in)	1 - 3 (0.04 - 0.12)	

PARKING BRAKE

Type	Center lever type	Stick lever type
Number of notches when warning lamp switch comes on	2*1 2*2	1
Number of notches [When pulled under force of 196 N (20 kg, 44 lb)]	10 - 12*1 7 - 9*2	10 - 12 (2WD) 9 - 11 (4WD)

*1: Truck model

*2: Van & Wagon model

DRUM BRAKE

Brake model	DS25B, DS25C	DS22	LT26B	DS19HB
Lining replacement limit Minimum thickness mm (in)	1.5 (0.059)			
Drum repair limit Inner diameter (Max.) mm (in)	255.5 (10.06)	221.5 (8.72)	261.5 (10.30)	191.0 (7.52)
Out-of-round mm (in)	0.03 (0.0012) or less			0.04 (0.0016)
Runout mm (in)	0.05 (0.0020) or less			0.1 (0.004)

DISC BRAKE

Brake model	CL28VA	CL28VD	AD14VB
Pad replacement limit Minimum thickness mm (in)	2.0 (0.079)		
Rotor repair limit Maximum runout mm (in)	0.07 (0.0028)		
Minimum thickness mm (in)	20.0 (0.787)	24.0 (0.945)	16.0 (0.630)

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Tightening Torque

Item	N·m	kg·m	ft·lb	Item	N·m	kg·m	ft·lb
Brake pedal				Crank lever support fixing bolt	19 - 25	1.9 - 2.5	14 - 18
Pedal bracket to body	8 - 11	0.8 - 1.1	5.8 - 8.0	L.S.V. (A-type)			
Stop lamp switch lock nut	12 - 15	1.2 - 1.5	9 - 11	L.S.V. bracket to side member	16 - 22	1.6 - 2.2	12 - 16
Brake booster				L.S.V. mounting bolt	10 - 15	1.0 - 1.5	7 - 11
Brake booster to body	8 - 11	0.8 - 1.1	5.8 - 8.0	Air bleeder	3 - 10	0.3 - 1.0	2.2 - 7.2
Input rod lock nut	16 - 22	1.6 - 2.2	12 - 16	L.S.V. (B-type)			
Brake booster to master cylinder	8 - 11	0.8 - 1.1	5.8 - 8.0	L.S.V. bracket to axle case	17 - 21	1.7 - 2.1	12 - 15
Three-way connector				L.S.V. mounting bolt	17 - 21	1.7 - 2.1	12 - 15
Three-way connector to brake tube	17 - 20	1.7 - 2.0	12 - 14	Air bleeder	6 - 9	0.6 - 0.9	4.3 - 6.5
Three-way connector mounting bolt	5 - 7	0.5 - 0.7	3.6 - 5.1				
Brake tube flare nut	15 - 18	1.5 - 1.8	11 - 13				
Wheel cylinder air bleeder	7 - 9	0.7 - 0.9	5.1 - 6.5				
Front disc brake							
Union bolt	17 - 20	1.7 - 2.0	12 - 14				
Disc rotor to wheel hub	49 - 69	5.0 - 7.0	36 - 51				
Torque member fixing bolt	72 - 97	7.3 - 9.9	53 - 72				
Torque member to cylinder body	22 - 31	2.2 - 3.2	16 - 23				
Baffle plate fixing bolt							
DS22	3.4 - 4.9	0.35 - 0.5	2.5 - 3.6				
DS25B, LT26B, DS25C	6 - 11	0.6 - 1.1	4.3 - 8.0				
Rear drum brake							
Wheel cylinder to back plate	5.3 - 7.3	0.54 - 0.74	3.9 - 5.4				
Rear drum anchor block fixing bolt	50 - 68	5.1 - 6.9	37 - 50				
Back plate fixing							
Single tire model	53 - 63	5.4 - 6.4	39 - 46				
Dual tire model	84 - 108	8.6 - 11.0	62 - 80				
Lock nut of crank lever	2.5 - 4.4	0.25 - 0.45	1.8 - 3.3				
Rear disc brake							
Torque member fixing bolt	54 - 64	5.5 - 6.5	40 - 47				
Torque member to cylinder body	22 - 31	2.2 - 3.2	16 - 23				
Union bolt	17 - 20	1.7 - 2.0	12 - 14				
Parking brake							
Control lever to body							
Center lever type	8 - 11	0.8 - 1.1	5.8 - 8.0				
Stick lever type	8 - 11	0.8 - 1.1	5.8 - 8.0				
Adjuster lock nut							
2WD	8 - 11	0.8 - 1.1	5.8 - 8.0				
4WD (Truck)	3.1 - 4.3	0.32 - 0.44	2.3 - 3.2				
(Van & Wagon)	8 - 11	0.8 - 1.1	5.8 - 8.0				
Front cable clamp to body							
Center lever type	8 - 11	0.8 - 1.1	5.8 - 8.0				
Stick lever type	8 - 11	0.8 - 1.1	5.8 - 8.0				
Parking brake assembly fixing bolt	53 - 63	5.4 - 6.4	39 - 46				