

CLUTCH


SECTION **CL**

CONTENTS

PRECAUTIONS	CL- 2
PREPARATION	CL- 3
CLUTCH SYSTEM	CL- 4
INSPECTION AND ADJUSTMENT	CL- 6
HYDRAULIC CLUTCH CONTROL	CL- 8
CLUTCH RELEASE MECHANISM	CL-11
CLUTCH DISC AND CLUTCH COVER	CL-13
SERVICE DATA AND SPECIFICATIONS (S.D.S.)	CL-15

CL

PRECAUTIONS








- Recommended fluid is brake fluid "DOT 3".
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted areas.
- When removing and installing clutch piping, use Tool.
- To clean or wash all parts of master cylinder, operating cylinder and clutch damper, use clean brake fluid.
- Never use mineral oils such as gasoline or kerosene.
It will ruin the rubber parts of the hydraulic system.

WARNING:



Remove all dust from clutch disc with a dust collector after cleaning with waste cloth.

PREPARATION


SPECIAL SERVICE TOOLS

Tool number (Kent-Moore No.) Tool name	Description
ST20050010 (—) Base plate	 Inspecting diaphragm spring of clutch cover
ST20050100 (—) Distance piece	
GG94310000 (—) Flare nut torque wrench	 Removing and installing each clutch piping
ST20600000 (J26366) Clutch aligning bar	 Installing clutch cover and clutch disc
ST20050240 (—) Diaphragm spring adjusting wrench	 Adjusting unevenness of diaphragm spring of clutch cover

COMMERCIAL SERVICE TOOLS


Tool name	Description
Bearing puller	 Removing release bearing
Bearing drift	 Installing release bearing a = 50 mm (1.97 in) dia.

CLUTCH SYSTEM



CLUTCH SYSTEM

Clutch Pedal





SCL282


INSPECTION AND ADJUSTMENT

Adjusting Clutch Pedal

1. Adjust pedal height with pedal stopper or clutch switch.
2. Adjust pedal free play with push rod.



INSPECTION AND ADJUSTMENT



Bleeding Procedure


Bleed air according to the following procedure.

Clutch damper → Clutch operating cylinder

- Carefully monitor fluid level at master cylinder during bleeding operation.
1. Top up reservoir with recommended brake fluid.
 2. Connect a transparent vinyl tube to air bleeder valve.
 3. Fully depress clutch pedal several times.
 4. With clutch pedal depressed, open bleeder valve to release air.
 5. Close bleeder valve.
 6. Repeat steps 3 through 5 above until brake fluid comes out of air bleeder valve without air bubbles.


HYDRAULIC CLUTCH CONTROL

Clutch Master Cylinder



DISASSEMBLY AND ASSEMBLY

- Push piston in cylinder body with screwdriver when removing and installing valve stopper.



- Align groove of piston assembly and valve stopper portion when installing valve stopper.
- Check direction of piston caps.


HYDRAULIC CLUTCH CONTROL

Clutch Master Cylinder (Cont'd)

INSPECTION

- Check cylinder and piston rubbing surface for uneven wear, rust or damage. Replace if necessary.
- Check piston with piston cup for wear or damage. Replace if necessary.
- Check return spring for wear or damage. Replace if necessary.
- Check reservoir for deformation or damage. Replace if necessary.
- Check dust cover for cracks, deformation or damage. Replace if necessary.

Operating Cylinder




INSPECTION

- Check rubbing surface of cylinder for wear, rust or damage. Replace if necessary.
- Check piston with piston cup for wear or damage. Replace if necessary.
- Check piston spring for wear or damage. Replace if necessary.
- Check dust cover for cracks, deformation or damage. Replace if necessary.

HYDRAULIC CLUTCH CONTROL


Clutch Damper



INSPECTION


- Check cylinder and piston rubbing surface for uneven wear, rust or damage. Replace if necessary.
- Check damper rubber and piston cup for cracks, deformation or damage. Replace if necessary.

CLUTCH RELEASE MECHANISM




REMOVAL AND INSTALLATION


- Install retainer spring and holder spring.



- Remove release bearing.




- Install release bearing with suitable drift.



CLUTCH RELEASE MECHANISM

INSPECTION


- Check release bearing to see that it rolls freely and is free from noise, crack, pitting or wear. Replace if necessary.
- Check release sleeve and withdrawal lever rubbing surface for wear, rust or damage. Replace if necessary.



LUBRICATION

- Apply recommended grease to contact surface and rubbing surface.

Too much lubricant might cause clutch disc facing damage.





WATERPROOF — for 4WD model

- Apply recommended sealant to contact surface of dust cover to transmission case and withdrawal lever and then install dust cover clip.

Recommended sealant: Nissan genuine part (KP115-00100) or equivalent.

CLUTCH DISC AND CLUTCH COVER




Clutch Disc

INSPECTION

Check clutch disc for wear of facing.

Wear limit of facing surface to rivet head:
0.3 mm (0.012 in)



- Check clutch disc for backlash of spline and runout of facing.

Maximum backlash of spline (at outer edge of disc):

240TBL 1.0 mm (0.039 in)

250TBL 1.0 mm (0.039 in)

Runout limit:

1.0 mm (0.039 in)

Distance of runout check point (from hub center)

240TBL 115 mm (4.53 in)

250TBL 115 mm (4.53 in)


- Check clutch disc for burns, discoloration or oil or grease leakage. Replace if necessary.

INSTALLATION

- Apply recommended grease to contact surface of spline portion.

Too much lubricant might cause clutch disc facing damage.

CLUTCH DISC AND CLUTCH COVER



Clutch Cover and Flywheel

INSPECTION AND ADJUSTMENT

- Set Tool and check height and unevenness of diaphragm spring. Set 0.2 mm (0.008 in) feeler gauges on distance pieces (ST20050100) when checking C240S or C250S.

Diaphragm spring height "A":

C240S 37.5 - 39.5 mm (1.476 - 1.555 in)



C250S 36.5 - 38.5 mm (1.437 - 1.516 in)

- Check thrust rings for wear or damage by shaking cover assembly and listening for a chattering noise, or by lightly hammering on rivets and listening for a cracking noise. Replace clutch cover assembly if necessary.
- Check pressure plate and clutch disc contact surface for slight burns or discoloration. Repair pressure plate with emery paper.
- Check pressure plate and clutch disc contact surface for deformation or damage. Replace if necessary.

- Adjust unevenness of diaphragm spring height with Tool.

Uneven limit:

0.5 mm (0.020 in)




FLYWHEEL INSPECTION

- Check contact surface of flywheel for slight burns or discoloration. Repair flywheel with emery paper.
- Check flywheel runout.

Runout (Total indicator reading):

Less than 0.15 mm (0.0059 in)



INSTALLATION

- Insert Tool into clutch disc hub when installing clutch cover and disc.

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

General Specifications

CLUTCH MASTER CYLINDER

Inner diameter	mm (in)	15.87 (5/8)
----------------	---------	-------------

CLUTCH OPERATING CYLINDER

Inner diameter	mm (in)	17.46 (11/16)
----------------	---------	---------------

CLUTCH DAMPER

Inner diameter	mm (in)	19.05 (3/4)
----------------	---------	-------------

CLUTCH DISC

Model	240TBL	250TBL
Engine	Z24i	VG30i
Facing size mm (in) (Outer dia. x inner dia. x thickness)	240 x 150 x 3.5 (9.45 x 5.91 x 0.138)	250 x 160 x 3.5 (9.84 x 6.30 x 0.138)
Thickness of disc assembly With load mm (in)	7.8 - 8.2 (0.307 - 0.323) with 4,904 N (500 kg, 1,103 lb)	7.9 - 8.3 (0.311 - 0.327) with 5,884 N (600 kg, 1,323 lb)

CLUTCH COVER

Model	C240S	C250S
Engine	Z24i	VG30i
Full load N (kg, lb)	3,923 (400, 882)	4,904 (500, 1,103)

Inspection and Adjustment

CLUTCH PEDAL

Unit: mm (in)

Pedal height "H"	
Z24i engine model	236 - 246 (9.29 - 9.69)
VG30i engine model	227 - 237 (8.94 - 9.33)
Pedal free play	1 - 1.5 (0.039 - 0.059)
Clearance between pedal stopper bracket and threaded end of clutch interlock switch (when depressing clutch pedal fully.)	0.3 - 1.0 (0.012 - 0.039)

*: Measured from surface of melt sheet to pedal pad

CLUTCH DISC

Unit: mm (in)

Model	240TBL	250TBL
Wear limit of facing surface to rivet head	0.3 (0.012)	
Runout limit of facing	1.0 (0.039)	
Distance of runout check point (from the hub center)	115 (4.53)	
Maximum backlash of spline (at outer edge of disc)	1.0 (0.039)	

CLUTCH COVER

Unit: mm (in)

Model	C240S	C250S
Diaphragm spring height	37.5 - 39.5 (1.476 - 1.555)	36.5 - 38.5 (1.437 - 1.516)
Uneven limit of diaphragm spring toe height	0.5 (0.020)	

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Tightening Torque

Unit	N·m	kg·m	ft·lb
Pedal stopper lock nut	16 - 22	1.6 - 2.2	12 - 16
Clutch switch lock nut	12 - 15	1.2 - 1.5	9 - 11
A.S.C.D. switch lock nut	12 - 15	1.2 - 1.5	9 - 11
Interlock switch lock nut	12 - 15	1.2 - 1.5	9 - 11
Fulcrum pin securing nut	16 - 22	1.6 - 2.2	12 - 16
Clutch pedal bracket securing nut and bolt	8 - 11	0.8 - 1.1	5.8 - 8.0
Master cylinder push rod lock nut	8 - 11	0.8 - 1.1	5.8 - 8.0
Master cylinder securing nut	8 - 11	0.8 - 1.1	5.8 - 8.0
Valve stopper	1.5 - 2.9	0.15 - 0.3	1.1 - 2.2
Reservoir band	2.5 - 3.9	0.25 - 0.4	1.8 - 2.9
Operating cylinder securing bolt	30 - 40	3.1 - 4.1	22 - 30
Damper cover to cylinder body	3.7 - 5.0	0.38 - 0.51	2.7 - 3.7
Clutch tube flare nut	15 - 18	1.5 - 1.8	11 - 13
Bleeder screw	7 - 9	0.7 - 0.9	5.1 - 6.5
Clutch hose to operating cylinder or clutch tube	17 - 20	1.7 - 2.0	12 - 14
Clutch hose eye bolt	17 - 20	1.7 - 2.0	12 - 14
Clutch hose cramp to body	8 - 11	0.8 - 1.1	5.8 - 8.0
Clutch cover securing bolt	22 - 29	2.2 - 3.0	16 - 22