

G510 MATONE 命令说明手册

文档版本: V1.0.0

更新日期: 2014-07-08

版权声明


版权所有©深圳市广和通实业发展有限公司 2013。保留一切权利。

非经本公司书面许可，任何单位和个人不得擅自摘抄、复制本文档内容的部分或全部，并不得以任何形式传播。

注意

由于产品版本升级或其他原因，本文档内容会不定期进行更新。除非另有约定，本文档仅作为使用指导，本文档中的所有陈述、信息和建议不构成任何明示或暗示的担保。

商标申明

 **FIBOCOM** 深圳市广和通实业发展有限公司的注册商标，由所有人拥有。

版本记录

文档版本	更新日期	说明
V1.0.0	2014-07-08	初始版本

适用型号

序号	型号	说明
1	G510	
2		
3		

目录

1 +MATONE, Start or stop the tone play,and the tone plays only once.....	4
--	---

1 +MATONE, Start or stop the tone play, and the tone plays only once.

Command	Syntax	Response/Action
Set	+MATONE=<state>, <tone_id>, <mix_fac tor>	OK or: +CME ERROR: <err>
Read	+MATONE?	+CME ERROR: <err>
Test	+MATONE=?	+ MATONE: <state>,<tone_id>,<mix_factor> OK

The following table shows the +MATONE parameters.

<Parameter>	Description
<state>	0 : stop When state=0, means the tone is stop 1 : start
<tone_id>	<tone_id> integer indicating the audio tone ID and may be: 0: aud_tone_DTMF_0 1: aud_tone_DTM F_1 2: aud_tone_DTMF_2 3: aud_tone_DTMF_3 4: aud_tone_DTMF_4 5: aud_tone_DTMF_5 6: aud_tone_DTMF_6 7: aud_tone_DTMF_7 8: aud_tone_DTMF_8 9: aud_tone_DTMF_9 10: aud_tone_DTM F_a 11: aud_tone_DTMF_b 12: aud_tone_DTMF_c 13: aud_tone_DTMF_d 14: aud_tone_DTMF_s, ".*"

	<p>15: aud_tone_DTMF_p ;"#"</p> <p>16: aud_tone_dial_tone</p> <p>17: aud_tone_sv_subscriber_busy</p> <p>18: aud_tone_sv_congestion</p> <p>19: aud_tone_sv_radio_path_ack</p> <p>20: aud_tone_info_call_dropped</p> <p>21: aud_tone_special_info</p> <p>22: aud_tone_sv_call_waiting</p> <p>23: aud_tone_sv_call_ringing</p> <p>24: aud_tone_info_test</p>
< mix_factor >	<mix_factor> integer indicating the kind of volume for tone generation; range 0 .. 7